Урок 2. Обзор доступных сенсоров. АЦП. Считывание данных. Получение данных с потенциометра и оценка угла поворота его ручки. Простая фильтрация

Задание 1. Необходимо подключить потенциометр и несколько светодиодов. Затем написать программу, в которой крутя ручку потенциометра, мы включали и выключали светодиоды. Например: светодиод светится только тогда, когда достигнуто максимальное значение, то есть ручка максимально повернута в одну из сторон. В остальных случаях он не светится. Будет здорово, если будут стоять несколько светодиодов, которые будут загораться и гаснуть, чтобы получилась "бегущая строка".

Задание 2*. Необходимо подключить фоторезистор и вывести показания в монитор порта. Почти наверняка будет присутствовать шум. Отфильтруйте его любым из способов, и посмотрите в каком диапазоне значений работает фоторезистор. Отмасштабируйте его от 0 до 10.


Задание 1:

Код программы:

```
int sensorPin = A2; // select the input pin for the potentiometer
int sensorValue = 0; // variable to store the value coming from the sensor
void setup() {
  // declare the ledPin as an OUTPUT:
  pinMode(2, OUTPUT);
  pinMode(3, OUTPUT);
  pinMode(4, OUTPUT);
  pinMode(5, OUTPUT);
  pinMode(6, OUTPUT);
  pinMode(7, OUTPUT);
  pinMode(8, OUTPUT);
  pinMode(9, OUTPUT);
}
void loop() {
  // read the value from the sensor:
  sensorValue = analogRead(sensorPin);
  if (sensorValue==(0*128))
  {digitalWrite(2, LOW);
  digitalWrite(3, LOW);
  digitalWrite(4, LOW);
  digitalWrite(5, LOW);
  digitalWrite(6, LOW);
  digitalWrite(7, LOW);
  digitalWrite(8, LOW);
  digitalWrite(9, LOW);}
  else if (sensorValue<=(1*128))</pre>
  {digitalWrite(2, HIGH);
  digitalWrite(3, LOW);
```

```
digitalWrite(4, LOW);
digitalWrite(5, LOW);
digitalWrite(6, LOW);
digitalWrite(7, LOW);
digitalWrite(8, LOW);
digitalWrite(9, LOW);}
else if (sensorValue<=(2*128))</pre>
{digitalWrite(2, HIGH);
digitalWrite(3, HIGH);
digitalWrite(4, LOW);
digitalWrite(5, LOW);
digitalWrite(6, LOW);
digitalWrite(7, LOW);
digitalWrite(8, LOW);
digitalWrite(9, LOW);}
else if (sensorValue<=(3*128))</pre>
{digitalWrite(2, HIGH);
digitalWrite(3, HIGH);
digitalWrite(4, HIGH);
digitalWrite(5, LOW);
digitalWrite(6, LOW);
digitalWrite(7, LOW);
digitalWrite(8, LOW);
digitalWrite(9, LOW);}
else if (sensorValue<=(4*128))</pre>
{digitalWrite(2, HIGH);
digitalWrite(3, HIGH);
digitalWrite(4, HIGH);
digitalWrite(5, HIGH);
digitalWrite(6, LOW);
digitalWrite(7, LOW);
digitalWrite(8, LOW);
digitalWrite(9, LOW);}
else if (sensorValue<=(5*128))</pre>
{digitalWrite(2, HIGH);
digitalWrite(3, HIGH);
digitalWrite(4, HIGH);
digitalWrite(5, HIGH);
digitalWrite(6, HIGH);
digitalWrite(7, LOW);
digitalWrite(8, LOW);
digitalWrite(9, LOW);}
else if (sensorValue<=(6*128))</pre>
{digitalWrite(2, HIGH);
digitalWrite(3, HIGH);
digitalWrite(4, HIGH);
digitalWrite(5, HIGH);
digitalWrite(6, HIGH);
digitalWrite(7, HIGH);
digitalWrite(8, LOW);
digitalWrite(9, LOW);}
```


```
else if (sensorValue<=(7*128))</pre>
  {digitalWrite(2, HIGH);
  digitalWrite(3, HIGH);
  digitalWrite(4, HIGH);
  digitalWrite(5, HIGH);
  digitalWrite(6, HIGH);
  digitalWrite(7, HIGH);
  digitalWrite(8, HIGH);
  digitalWrite(9, LOW);}
  else if (sensorValue<=(8*128))</pre>
  {digitalWrite(2, HIGH);
  digitalWrite(3, HIGH);
  digitalWrite(4, HIGH);
  digitalWrite(5, HIGH);
  digitalWrite(6, HIGH);
  digitalWrite(7, HIGH);
  digitalWrite(8, HIGH);
  digitalWrite(9, HIGH);}
Фото бегущей строки:
```



Работа устройства показана на видео string.mp4

Задание 2:

Фоторезистор с резистором 10 кОм.




Код измерителя:

```
const int analogInPin = A2;  // Analog input pin that the potentiometer is
attached to
int sensorValue = 0;  // value read from the pot

void setup() {
    // initialize serial communications at 9600 bps:
    Serial.begin(9600);
}

void loop() {
    // read the analog in value:
    sensorValue = analogRead(analogInPin);
    // print the results to the Serial Monitor:
    Serial.println(sensorValue);
    // wait 2 milliseconds before the next loop for the analog-to-digital
    // converter to settle after the last reading:
    delay(2);
}
```

График с шумами:



Код с усредняющим фильтром:

```
const int analogInPin = A2; // Analog input pin that the potentiometer is
attached to
int sensorValue = 0; // value read from the pot
int outputValue = 0; // value output to the PWM (analog out)
void setup() {
 // initialize serial communications at 9600 bps:
  Serial.begin(9600);
}
void loop() {
 // read the analog in value:
  sensorValue = analogRead(analogInPin);
  outputValue = sensorValue;
  for (int i = 0; i < 1000; i++)</pre>
  { sensorValue = analogRead(analogInPin);
  outputValue = (outputValue+sensorValue)/2;}
  Serial.println(outputValue);
}
```

Диапазон входных значений:



Код с масштабированием выходных значений:

```
const int analogInPin = A2; // Analog input pin that the potentiometer is
attached to
int sensorValue = 0; // value read from the pot
int outputValue = 0; // value output to the PWM (analog out)
void setup() {
 // initialize serial communications at 9600 bps:
 Serial.begin(9600);
}
void loop() {
 // read the analog in value:
  sensorValue = analogRead(analogInPin);
 outputValue = sensorValue;
 for (int i = 0; i < 1000; i++)
  { sensorValue = analogRead(analogInPin);
  outputValue = (outputValue+sensorValue)/2;}
  // map it to the range of the analog out:
 outputValue = map(outputValue, 700, 950, 0, 10);
 // print the results to the Serial Monitor:
 Serial.println(outputValue);
Работа кода показана на видео graph.mp4
```