

**Remove capacitors: C15, C16,
C32, C33, C49, C50, C66, C67
with 0 Ohm resistors**

**Remove terminations: R11, R12,
R23, R24, R35, R36, R47, R78**