

Title: Vibrator and LDR Sensor

Aim: To vibrate during day time.

Hardware Required: Anduiro Board, Bread Board,

Transistor, Vibrator, Multimeter, Photoresistor, Resistor.

arcuit Diagram:

Code:

int motorpin = 3;

int sensorpin = A1;

int threshold = 400;

void setup C)

I pinMode Cmotorpin, Output).

Serial. Legin (9600);

```
void loop ()
    int value = analog Read (nensorpin);
    Serial println (value);
    if (value) threshold)
        digitalWrite (motorpin, HIGH);
    else
       oligital Write (motorpin, LOW);
    delay (1000).
Observation/Conclusion:
The vibrator starts vibrating when the it is there
 is surlight.
```