Pearlz Installation Guide — AquaPearl Series

Version 2026.1

1. Pre-installation checklist

Confirm water pressure 0.1–0.4 MPa, a grounded 3-pin socket, and at least 10 cm clearance on each side for ventilation. Do not install outdoors or in direct sun.

2. Tools required

Adjustable spanner, PTFE tape, bucket, clean cloth, spirit level.

3. Wall-mount installation (summary)

Mark bracket holes, drill suitable anchors, hang the unit level, connect inlet tubing with PTFE tape, connect drain where required, and plug in only after leak-check with water on and power still off.

4. Under-sink installation (summary)

Shut municipal supply, install the saddle or adapter valve on the cold line, route tubing without kinks, secure the unit upright, and restore supply slowly while watching for drips.

5. First-run flushing procedure (required)

After installation or after changing carbon/RO filters, flush before drinking: (1) Fill and discard the first full tank. (2) Fill again and discard a second full tank. (3) On AquaPearl 500 Pro, run continuous dispense for 5 minutes on the third fill. This removes carbon fines and preservative taste. Skipping flush is the most common cause of “weird taste after I changed the filter.”

6. Professional installation

Book SKU SVC-INSTALL. Standard professional installation includes bracket mounting or under-sink hookup within 3 metres of the cold inlet and a basic leak check. Extra plumbing beyond that is quoted separately. List price is in the Pricing Guide.

7. What voids warranty during self-installation

Cracked fittings from overtightening, use of incompatible tubing, bypassing the leak sensor, or powering the unit while submerged connections are leaking may void warranty coverage for the resulting damage. See Warranty Policy exclusions.