AquaPearl 500 Pro — Product Manual

Pearlz Home Systems (Pvt.) Ltd. · Version 2026.1 · Fictional training document

1. Box contents

• AquaPearl 500 Pro main unit

• Sediment pre-filter cartridge (installed)

• Carbon block filter (installed)

• RO membrane (installed)

• Remineralisation cartridge (installed)

• Inlet valve adapter kit and tubing

• Power adapter (220–240 V AC)

• Quick-start card and warranty card

2. Technical specifications

Parameter	Value
Flow rate (purified)	Up to 1.8 L/min
Tank capacity	6.0 L
Dimensions (W×D×H)	38 × 22 × 42 cm
Power	220–240 V, 50 Hz, 60 W max
Filter stages	Sediment → Carbon → RO → Remineralisation (+ UV)
Inlet pressure range	0.1–0.4 MPa

3. Control panel and indicator lights

Power LED (white): solid = on. Wi-Fi LED (blue): blinking = pairing, solid = connected. Filter LED (amber): on when a filter is due. Fault LED (red): blinks with audible alert codes.

4. Operating instructions

Open the inlet valve, plug in the adapter, and press Power. Allow the tank to fill before first draw. Use only potable municipal or bore water within the pressure range in §2.

5. Filter replacement intervals

Filter	Typical interval
Sediment pre-filter	3–6 months
Carbon block	6–12 months
RO membrane	24 months
Remineralisation	12 months
UV lamp (service)	As indicated / ~9000 hours

6. Cleaning and descaling schedule

Wipe exterior monthly with a damp cloth. Descale the tank every 6 months using Pearlz descaling solution only. Do not use abrasive cleaners on the control panel.

7. Safety warnings

Do not immerse the unit. Disconnect power before filter changes. Do not open the UV bay. This appliance improves aesthetic water quality per its design; it is not a medical device and does not diagnose or treat disease. Follow local public-health guidance for drinking water safety.

8. Audible alert codes (E-01 to E-08)

Code	Pattern	Meaning	First action
E-01	1 long beep repeating	No inlet water	Open inlet valve
E-02	2 beeps repeating	Tank full sensor fault	Power cycle; clean contacts
E-03	3 short beeps then stop	Sediment pre-filter saturation	Replace pre-filter; hold RESET 5s
E-04	4 beeps	Carbon filter due (fw ≥2.4)	Replace carbon; reset
E-05	Blinking red LED	Leak sensor wet	Power off; dry sensor
E-06	5 beeps	Pump overcurrent	Power off; contact support
E-07	6 beeps	UV lamp fault	Do not open UV bay; contact support
E-08	7 beeps	System fault	Power off; contact support

9. Filter maintenance (page reference section)

To replace the sediment pre-filter: close inlet, depressurise, twist the sediment housing counter-clockwise, insert a new Pearlz AP500-SED cartridge, reseal, open inlet, and flush per the Installation Guide. After E-03, press and hold RESET for five seconds to clear the alert.