به نام خدا


# شبکه مخابرات داده

تمرین ۱


ياسمن حقيقي

941.5101

۱\_در ابتدا کد صورت سوال پیاده سازی شده است خروجی فایل nam. مطابق شکل زیر است:



برای رسم نتایج در متلب با استفاده از import data در Home به صورت Numeric Matrix به سرای رسم workspace اضافه کرده و پس از تقسیم ستون دوم بر ۲MB نمودار زیر را با دستور plot متلب رسم میکنیم:



با افزایش طول فریم مطابق فرمول میزان استفاده از کانال افزایش می یابد و به دنبال آن  $oldsymbol{\mathsf{U}}$  افزایش می یابد.

```
set ns [new Simulator]
set namf [open out.nam w]
set tracef [open trace.tr w]
$ns namtrace-all $namf
$ns trace-all $tracef
set bandwidth [open part \.txt w]
proc finish {} {
global ns namf bandwidth tracef
#define global variables for this procedure
$ns flush-trace
close $bandwidth
close Stracef
close $namf
exec nam out.nam
exit ·
$ns namtrace-all $namf
$ns trace-all $tracef
set n(⋅) [$ns node]
set n(1) [$ns node]
n(\cdot) color "red"
$n(1) color "blue"
$ns at \cdot, "$n(\cdot) label Sender"
$ns at .,. "$n(\) label Receiver"
set LineBW ۲Mb
set LineDelay \ms
ns duplex-link (\cdot) (\cdot)  LineBW $LineDelay DropTail
no(1) \sin duplex-link-op (1) \sin(1) orient right-up
set tcp [new Agent/TCP]
ns attach-agent (\cdot) cp
$tcp set window_ \
$tcp set maxcwnd_ \
$tcp set maxseq_ a \cdot \cdot \cdot \cdot \cdot \cdot
set ftp [new Application/FTP]
$ftp attach-agent $tcp
set tcpsnk [new Agent/TCPSink]
$ns attach-agent $n(\) $tcpsnk
$ns connect $tcp $tcpsnk
$ns color \ Blue
$tcp set fid_ \
set headersize *•
set framelen ٣٠
set timeinterval 1 \cdot , \cdot
set firstacknum [$tcp set ack_]
set lastacknum [$tcp set ack_]
$tcp set packetSize_ $framelen
proc record {} {
global bandwidth framelen tcp ns firstacknum lastacknum headersize timeinterval n
#get the ack number of the current frame
set lastacknum [$tcp set ack_]
#compares this ACK number with the one from \. second before in order to determine
set bw [expr ( \frac{1}{2} | \frac
set now [$ns now]
$tcp set packetSize_ $framelen
#fill the text file:
puts $bandwidth "[expr ($framelen + $headersize)] [expr (($bw)/($timeinterval))]
```

```
$now*"
#record this ack number for next loop:
set firstacknum [$tcp set ack_]
#record this ack number for next loop:
set firstacknum $lastacknum
#increasing the frame length for next packet:
set framelen [expr ($framelen+\))]
$tcp set packetSize_ $framelen
#execute this proc every \(\cdot\) second (timeinterval=\(\cdot\))
$ns at [expr $now+$timeinterval] "record"
}
$ns at \(\cdot\). ""fftp start"
$ns at \(\cdot\). "record"
$ns at \(\cdot\). ""finish"
$ns run
```

نمونه ای از فایل trace.

```
- 1 0 1 tcp 40 ----- 1 0.0 1.0 0 0
r 1.00116 0 1 tcp 40 ----- 1 0.0 1.0 0 0
+ 1.00116 1 0 ack 40 ----- 1 1.0 0.0 0 1
- 1.00116 1 0 ack 40 ----- 1 1.0 0.0 0 1
r 1.00232 1 0 ack 40 ----- 1 1.0 0.0 0 1
+ 1.00232 0 1 tcp 70 ----- 1 0.0 1.0 1 2
- 1.00232 0 1 tcp 70 ----- 1 0.0 1.0 1 2
r 1.0036 0 1 tcp 70 ----- 1 0.0 1.0 1 2
+ 1.0036 1 0 ack 40 ----- 1 1.0 0.0 1 3
- 1.0036 1 0 ack 40 ----- 1 1.0 0.0 1 3
r 1.00476 1 0 ack 40 ----- 1 1.0 0.0 1 3
+ 1.00476 0 1 tcp 70 ----- 1 0.0 1.0 2 4
- 1.00476 0 1 tcp 70 ----- 1 0.0 1.0 2 4
r 1.00604 0 1 tcp 70 ----- 1 0.0 1.0 2 4
+ 1.00604 1 0 ack 40 ----- 1 1.0 0.0 2 5
- 1.00604 1 0 ack 40 ----- 1 1.0 0.0 2 5
r 1.0072 1 0 ack 40 ----- 1 1.0 0.0 2 5
+ 1.0072 0 1 tcp 70 ----- 1 0.0 1.0 3 6
- 1.0072 0 1 tcp 70 ----- 1 0.0 1.0 3 6
r 1.00848 0 1 tcp 70 ----- 1 0.0 1.0 3 6
+ 1.00848 1 0 ack 40 ----- 1 1.0 0.0 3 7
- 1.00848 1 0 ack 40 ----- 1 1.0 0.0 3 7
r 1.00964 1 0 ack 40 ----- 1 1.0 0.0 3 7
+ 1.00964 0 1 tcp 70 ----- 1 0.0 1.0 4 8
- 1.00964 0 1 tcp 70 ----- 1 0.0 1.0 4 8
r 1.01092 0 1 tcp 70 ----- 1 0.0 1.0 4 8
+ 1.01092 1 0 ack 40 ----- 1 1.0 0.0 4 9
- 1.01092 1 0 ack 40 ----- 1 1.0 0.0 4 9
r 1.01208 1 0 ack 40 ----- 1 1.0 0.0 4 9
+ 1.01208 0 1 tcp 70 ----- 1 0.0 1.0 5 10
```

برای قسمت دوم تغییراتی در کد ایجاد کردم:

با توجه به شماره دانشجویی مقدار اولیه اینگونه تغییر دادم:

set LineDelay •,••1

بعد از تعریف duplex-link ، دستور زیر اضافه شده است:

set myLink [[\$ns link \$n(.) \$n()] link]


سپس به متغیر های global متغیر myLink,LindBW,LineDelay اضافه شده و در فایل txt. اطلاعات به فرم زیر نوشته میشود:

puts \$bandwidth " \$LineDelay [expr ((\$bw)/(\$timeinterval\*\$LineBW))] " سپس مقدار LineDelay مطابق زیر تغییر دادم:

set LineDelay [expr (\$LineDelay + ·,··٩٠)]
\$myLink set delay\_ \$LineDelay

و تغییرات فریم را از کد حذف کردم.

سپس همانطور که در قسمت قبل توضیح دادم نمودار مربوطه را رسم میکنیم:



مشاهده میشود که با افزایش تاخیر میزان U کاهش می یابد چون در بازه زمانی مشخص کمتر از کانال استفاده میشود و اگر تاخیر کانال زیاد باشد استفاده از Stop and Wait مناسب نمیباشد.

برای قسمت سوم مطابق زیر عمل کردم:

با توجه به شماره دانشجویی مقادیر اولیه کد قسمت قبل را مطابق زیر تغییر دادم:

set LineBW • · · · · ·
set LineDelay • , · · )


در فایل txt. اطلاعات به فرم زیر نوشته میشود:

puts \$bandwidth " \$LineBW [expr ((\$bw)/(\$timeinterval\*\$LineBW))] "

سپس مطابق زیر پهنای باند را تغییر دادم و تغییرات مربوط به تاخیر را حذف کردم:

set LineBW [expr (\$LineBW + o · · · · · )]
\$myLink set bandwidth\_ \$LineBW

سپس همانطور که توضیح داده شد نمودار را رسم کردم:




همان طور که از فرمول هم انتظار میرفت(چون پهنای باند در مخرج است) با افزایش پهنای باند U کاهش می یابد چون میزان استفاده از کانال تغییری نکرده ولی ظرفیت کانال بیشتر هم شده است.

### نتيجه گيرى:

با توجه به تعریف U اگر میزان استفاده از کانال افزایش یابد U هم افزایش می یابد و برعکس. همانطور که مشاهده شد با افزایش طول فریم این مقدار افزایش یافته و به دنبال آن U هم افزایش می یابد.همچنین اگر تاخیر افزایش یابد این میزان کاهش می یابد.

و اگر پهنای باند کانال افزایش یابد چون در مخرج U قرار دارد، مقدار U را کاهش می دهد.

در ابتدا کد را مانند آنچه در صورت سوال گفته شده تغییر دادم نتیجه با استفاده از داده های سوال ۱ به فرم زیر است:



هدف نهایی این است که کانال همیشه پرباشد برای این کار باید مدت زمانی که طول میکشد تا Ack مربوط به پنجره اول برسد برابر با مدت زمانی باشد که طول میکشد تا Window Size-۱ ارسال شود یعنی:

۲\*Line Delay + Ack/BW = (Window Size -۱) \*Frame Length/BW

با توجه به فایل ۲۰۰۰ بایت و مقدار Frame Length Window برابر با ۲۰ بایت و مقدار Ack

اگر مقدار تاخیر برابر با ۱ میلی ثانیه و پهنای باند برابر با Mb۲ باشد حداقل مقدار صحیح برابر طول پنجره برابر با ۹ است که در نمودار نیز مشاهده میشود.

پس میتوان نتیجه گرفت که متناسب با پهنای باند و تاخیر میتوان Windowsize را تعیین کرد.

```
set ns [new Simulator]
set namf [open outr.nam w]
set tracef [open tracer.tr w]
$ns namtrace-all $namf
$ns trace-all $tracef
set bandwidth [open partY.txt w]
proc finish {} {
global ns namf bandwidth tracef
#define global variables for this procedure
$ns flush-trace
close $bandwidth
close $tracef
close $namf
exec nam out.nam
\mathtt{exit} \; \cdot \;
$ns namtrace-all $namf
$ns trace-all $tracef
set n(·) [$ns node]
set n(1) [$ns node]
$n(⋅) color "red"
$n(1) color "blue"
ns at ·,· "n(\cdot) label Sender"
$ns at ., "$n(1) label Receiver"
set LineBW MMb
set LineDelay \ms
ns duplex-link n(\cdot) n(\cdot) LineBW LineDelay DropTail
ns duplex-link-op n(\cdot) n(\cdot) orient right-up
```


```
set tcp [new Agent/TCP]
$ns attach-agent $n(.) $tcp
$tcp set window_ \u00e4
$tcp set maxcwnd \
$tcp set maxseq_ \delta \cdots
set ftp [new Application/FTP]
$ftp attach-agent $tcp
set tcpsnk [new Agent/TCPSink]
$ns attach-agent $n(1) $tcpsnk
$ns connect $tcp $tcpsnk
$ns color \ Blue
$tcp set fid_ \
set headersize f \cdot
set framelen {\bf r}\cdot
set timeinterval 1.,
set firstacknum [$tcp set ack_]
set lastacknum [$tcp set ack_]
$tcp set packetSize_ $framelen
proc record {} {
{\tt global} \ {\tt bandwidth} \ {\tt framelen} \ {\tt tcp} \ {\tt ns} \ {\tt firstacknum} \ {\tt lastacknum} \ {\tt headersize} \ {\tt timeinterval} \ {\tt n}
#get the ack number of the current frame
set lastacknum [$tcp set ack_]
#compares this ACK number with the one from 1\cdot second before in order to determine
#transmitter bandwidth
set bw [expr ( \$lastacknum - \$firstacknum +1)*(\$framelen + \$headersize )*\Lambda ]
set now [$ns now]
set windowsize [$tcp set window_]
set maxwind [$tcp set maxcwnd_]
$tcp set packetSize_ $framelen
#fill the text file:
puts $bandwidth "$windowsize [expr (($bw)/($timeinterval))]"
```

```
#record this ack number for next loop:
set firstacknum [$tcp set ack_]
#record this ack number for next loop:
set firstacknum $lastacknum
#increasing the window_ and maxcwnd_ for next packet:
$tcp set window_ [expr ($windowsize+1)]
$tcp set maxcwnd_ [expr ($maxwind+1)]
#$tcp set packetSize_ $framelen
#execute this proc every 1. second (timeinterval=1.)
$ns at [expr $now+$timeinterval] "record"
}
$ns at 1... "$ftp start"
$ns at 1... "finish"
$ns run
```


نمونه ای از فایل trace.

```
|+ 1 0 1 tcp 40 ----- 1 0.0 1.0 0 0
- 1 0 1 tcp 40 ----- 1 0.0 1.0 0 0
г 1.00116 0 1 tcp 40 ----- 1 0.0 1.0 0 0
+ 1.00116 1 0 ack 40 ----- 1 1.0 0.0 0 1
- 1.00116 1 0 ack 40 ----- 1 1.0 0.0 0 1
r 1.00232 1 0 ack 40 ----- 1 1.0 0.0 0 1
+ 1.00232 0 1 tcp 70 ----- 1 0.0 1.0 1 2
- 1.00232 0 1 tcp 70 ----- 1 0.0 1.0 1 2
r 1.0036 0 1 tcp 70 ----- 1 0.0 1.0 1 2
+ 1.0036 1 0 ack 40 ----- 1 1.0 0.0 1 3
- 1.0036 1 0 ack 40 ----- 1 1.0 0.0 1 3
r 1.00476 1 0 ack 40 ----- 1 1.0 0.0 1 3
+ 1.00476 0 1 tcp 70 ----- 1 0.0 1.0 2 4
- 1.00476 0 1 tcp 70 ----- 1 0.0 1.0 2 4
r 1.00604 0 1 tcp 70 ----- 1 0.0 1.0 2 4
+ 1.00604 1 0 ack 40 ----- 1 1.0 0.0 2 5
- 1.00604 1 0 ack 40 ----- 1 1.0 0.0 2 5
r 1.0072 1 0 ack 40 ----- 1 1.0 0.0 2 5
+ 1.0072 0 1 tcp 70 ----- 1 0.0 1.0 3 6
- 1.0072 0 1 tcp 70 ----- 1 0.0 1.0 3 6
r 1.00848 0 1 tcp 70 ----- 1 0.0 1.0 3 6
+ 1.00848 1 0 ack 40 ----- 1 1.0 0.0 3 7
- 1.00848 1 0 ack 40 ----- 1 1.0 0.0 3 7
r 1.00964 1 0 ack 40 ----- 1 1.0 0.0 3 7
+ 1.00964 0 1 tcp 70 ----- 1 0.0 1.0 4 8
- 1.00964 0 1 tcp 70 ----- 1 0.0 1.0 4 8
```

۳\_ابتدا کد را مطابق آنچه در سوال گفته شده تغییر می دهیم و ۵ بار که در هر بار مقدار drop rate را تغییر می دهیم اجرا میکنیم و نمودار را مطابق زیر رسم میکنیم:



## نمودار به فرم زیر است:



همان طور که مشاهده میشود با افزایش مقدار  $drop\ rate$  مقدار U به شدت کاهش می یابد تا حدی که برای حالتی که برابر با U, است تقریبا U میشود و کانال کاربردی نیست. که این نتیجه با فرمول ارائه در اسلاید ها نیز مطابقت دارد.

## كد اين سوال:

#### قسمت قرمز شده را تغییر میدهیم

```
set ns [new Simulator]
set namf [open out r.nam w]
set tracef [open trace .tr w]
$ns namtrace-all $namf
$ns trace-all $tracef
set bandwidth [open part^{v}_{-},\\.txt w]
proc finish {} {
global ns namf bandwidth tracef
#define global variables for this procedure
$ns flush-trace
close $bandwidth
close $tracef
close $namf
exec nam out.nam
\mathtt{exit} \; \cdot \;
$ns namtrace-all $namf
$ns trace-all $tracef
set n(·) [$ns node]
set n(1) [$ns node]
$n(⋅) color "red"
$n(\) color "blue"
ns at ·,· "n(\cdot) label Sender"
$ns at ., "$n(1) label Receiver"
set LineBW YMb
set LineDelay \ms
ns duplex-link (n(\cdot) (n(t) LineBW LineDelay DropTail
```

```
ns duplex-link-op n(\cdot) n(\cdot) orient right-up
set tcp [new Agent/TCP]
ns attach-agent n(\cdot) $tcp
$tcp set window \
$tcp set maxcwnd_ \u00e4
$tcp set maxseq_ a \cdot \cdot \cdot \cdot \cdot
set ftp [new Application/FTP]
$ftp attach-agent $tcp
set tcpsnk [new Agent/TCPSink]
$ns attach-agent $n(1) $tcpsnk
$ns connect $tcp $tcpsnk
$ns color \ Blue
$tcp set fid_ \lambda
#Loss parameters
set loss module [new ErrorModel]
#set Drop rate
$loss module set rate .,\\
something somethin something
loss_module set max_l
#Uniform random variable (means choosing a packet for dropping is uniform in #time):
$loss_module ranvar [new RandomVariable/Uniform]
$loss_module drop-target [new Agent/Null]
#a complete packet should be dropped not bytes or bits , etc:
$loss_module unit pkt
#Loss module starts working at "time = \cdot,\cdot1 (s)" between node \cdot and 1:
$ns at ... "$ns lossmodel $loss_module $n(\) $n(\)"
#Constant Window Size For Lossy Channel
proc windconst {} {
global tcp ns file)
```

```
$tcp set maxcwnd_ &
# maximum congestion window
$tcp set windowinit_ &
# initial window size
$tcp set window_ &
# window size
$tcp set cwnd_ \Delta
#congestion window
set now [$ns now]
ns at [expr now+\cdot,\cdot1] "windconst"
set headersize *.
set framelen {f r}\cdot
set timeinterval \cdot\cdot,\cdot
set firstacknum [$tcp set ack_]
set lastacknum [$tcp set ack ]
$tcp set packetSize_ $framelen
proc record {} {
{\tt global} \ {\tt bandwidth} \ {\tt framelen} \ {\tt tcp} \ {\tt ns} \ {\tt firstacknum} \ {\tt lastacknum} \ {\tt headersize} \ {\tt timeinterval} \ {\tt n}
#get the ack number of the current frame
set lastacknum [$tcp set ack_]
#compares this ACK number with the one from \iota second before in order to determine
#transmitter bandwidth
set bw [expr ( \$lastacknum - \$firstacknum +1)*(\$framelen + \$headersize )*\Lambda ]
set now [$ns now]
set windowsize [$tcp set window_]
set maxwind [$tcp set maxcwnd_]
$tcp set packetSize_ $framelen
#fill the text file:
puts $bandwidth "$framelen [expr (($bw)/($timeinterval))]
$now*"
#record this ack number for next loop:
```

```
#record this ack number for next loop:
set firstacknum $lastacknum
#increasing the window_ and maxcwnd_ for next packet:
#$tcp set window [expr ($windowsize+1)]
#$tcp set maxcwnd_ [expr ($maxwind+1)]
set framelen [expr (framelen+1.))
$tcp set packetSize_ $framelen
#execute this proc every 1 \cdot \text{second (timeinterval} = 1 \cdot )}
$ns at [expr $now+$timeinterval] "record"
$ns at \, "$ftp start"
$ns at \,.\ "windconst"
ns at r, "record"
$ns at \.f. "finish"
$ns run
                                                                            نمونه ای از فایل trace.
+ 1 0 1 tcp 40 ----- 1 0.0 1.0 0 0
- 1 0 1 tcp 40 ----- 1 0.0 1.0 0 0
r 1.00116 0 1 tcp 40 ----- 1 0.0 1.0 0 0
d 1.00116 1 0 ack 40 ----- 1 1.0 0.0 0 1
+ 4 0 1 tcp 40 --- A--- 1 0.0 1.0 0 2
- 4 0 1 tcp 40 ---A--- 1 0.0 1.0 0 2
r 4.00116 0 1 tcp 40 --- A--- 1 0.0 1.0 0 2
d 4.00116 1 0 ack 40 ----- 1 1.0 0.0 0 3
+ 10 0 1 tcp 40 --- A--- 1 0.0 1.0 0 4
- 10 0 1 tcp 40 ---A--- 1 0.0 1.0 0 4
r 10.00116 0 1 tcp 40 --- A--- 1 0.0 1.0 0 4
 10.00116 1 0 ack 40 ----- 1 1.0 0.0 0 5
- 10.00116 1 0 ack 40 ----- 1 1.0 0.0 0 5
r 10.00232 1 0 ack 40 ----- 1 1.0 0.0 0 5
+ 10.00232 0 1 tcp 80 ----- 1 0.0 1.0 1 6
 10.00232 0 1 tcp 80 ----- 1 0.0 1.0 1 6
r 10.00364 0 1 tcp 80 ----- 1 0.0 1.0 1 6
+ 10.00364 1 0 ack 40 ----- 1 1.0 0.0 1 7
- 10.00364 1 0 ack 40 ----- 1 1.0 0.0 1 7
r 10.0048 1 0 ack 40 ----- 1 1.0 0.0 1 7
+ 10.0048 0 1 tcp 80 ----- 1 0.0 1.0 2 8
- 10.0048 0 1 tcp 80 ----- 1 0.0 1.0 2 8
+ 10.0048 0 1 tcp 80 ----- 1 0.0 1.0 3 9
- 10.00512 0 1 tcp 80 ----- 1 0.0 1.0 3 9
г 10.00612 0 1 tcp 80 ----- 1 0.0 1.0 2 8
+ 10.00612 1 0 ack 40 ----- 1 1.0 0.0 2 10
- 10.00612 1 0 ack 40 ----- 1 1.0 0.0 2 10
r 10.00644 0 1 tcp 80 ----- 1 0.0 1.0 3 9
+ 10.00644 1 0 ack 40 ----- 1 1.0 0.0 3 11
```

set firstacknum [\$tcp set ack\_]