Pre-Start Checklist

Parking Brake SET
Throttle IDLE

BATT Master Switch ON (Shift-M)
Panel Light AS REQUIRED

Gear Lever CHECK DOWN

Flaps UP

Spoiler RETRACTED

FMC / FSNAV Flight Plan GENERATE / LOAD /

ACTIVATE - IF FMC IS AVAILABLE

Fuel Quantity CALC / LOAD

Engine Instruments CHECK
Aircraft Lighting OFF
Flight controls CHECK

Check Weather (Atis, Flight Services)

Request Clearance

Transponder SET
Beacon ON

Startup Checklist

Thrust Levers IDLE

Engine Area CLEAR

Mode Selector IGN/START

Eng 1 starts immediately

at N2 = 20% Fuel Flow ON
Fuel Flow CHECK
N1 increasing as N2 incr. CHECK

Eng 2 starts after Eng 1 is running

at N2 = 20% Fuel Flow ON

Fuel Flow CHECK

N1 increasing as N2 incr. CHECK

Eng 3 starts after Eng 2 is running

at N2 = 20% Fuel Flow ON

Fuel Flow CHECK

N1 increasing as N2 incr. CHECK

Eng 4 starts after Eng 3 is running

at N2 = 20% Fuel Flow ON

Fuel Flow CHECK

N1 increasing as N2 incr. CHECK

Before Taxi Checklist

Strobe Light ON
Nav Lights ON
Taxi Lights ON
Heading Indicator/Altimeters SET
Standby Instruments SET

Avionics SET FOR DEPARTURE

Autopilot SET and OFF

FD ON

Yaw Damper ON AS REQUIRED

Autobrake RTO

Elevator Trim SET for takeoff

Request Taxi Clearance

Taxi Checklist

Passenger Signs ON

Brakes RELEASED

Taxi to assigned runway SPEED Max. 20 KIAS

Before Take-off Checklist

Brakes SET
Throttle IDLE

Flaps Pos 2

Spoilers RETRACTED

Landing Lights ON

Engine Instruments, Nav Equipment CHECK

Takeoff Data (V1, VR, V2) CHECK

Request Takeoff Clearance

Take-off Checklist

Vr =

Smoothly increase thrust to 40% N1 let spool up Takeoff Thrust FULL or TO/GA

Brakes RELEASE

V1 = 145 KIAS (descision)

Pitch 10-15 deg. nose up

V2 = 160 KIAS (safety speed)

150 KIAS (rotate)

At Positive Climb Rate Touch Brakes

Landing Gear RETRACT

At 180 KIAS RETRACT Flaps to Pos 1

At 210 KIAS RETRACT flaps up

Climb-out Checklist

Trim for 250 KIAS

Autothrottle ARM

Autopilot ON

Below 10000' max. speed 250 KIAS

Autobrake OFF

After 10000 feet:

Taxi Lights OFF
Landing Lights OFF

ATC AS REQUIRED

Above 10000' speed 280 KIAS

Fasten Seat Belts OFF ; if pilot feels necessary
No Smoking Sign ON ; if pilot feels necessary

Cruise Checklist (above FL 180)

At Transition Altitude (FL180) set Altimeter to 29,92" (1013mb)

Accelerate to cruise speed FL180 0.70 M 345 KIAS

FL240 0.77 M 343 KIAS

FL280 0.82 M 335 KIAS

FL330 0.84 M 305 KIAS

Engine+Instruments CHECK
Fuel Quantity CHECK

Radios TUNED and SET
Autopilot CHECK and SET

Lights as required

Descent Checklist

Atis/Airport Information CHECK
Altimeter CHECK
Radios SET

Descent Speed to FL240 280 KIAS; unless given specific speed by ATC

to FL180 " " "

At Transition Altitude (FL180) reset Altimeter to local

to FL120 260 KIAS

below 10'000ft 240 KIAS

Fuel Quantities and Balance CHECK

Approach Checklist

Localizer Level Flight:

Fasten Seat Belts ON
No Smoking Sign ON
ND OFF
LS ON
Avionics + Radios SET

Speed: Establish 210 KIAS

Landing Lights ON

Auto Spoilers ARM

Autobrake SET

Flaps Pos 1

Speed: Establish 180 KIAS

Flaps Pos 2

Speed: Establish 160 KIAS

Landing Gear DOWN

Turning toward runway: set flaps Pos 3 / FULL

Final Glideslope Descent :

Speed Establish 150 KIAS
Park Brakes VERIFY OFF
Anti-lce - AS REQUIRED

Landing Checklist

Landing Gear - CHECK DOWN

Autopilot - OFF

Autothrottle - OFF and SPD Deactivated

Landing Speed - 150 KIAS

After Touchdown - Apply Reverse Thrust
At 70 KIAS - Cancel Reverse Thrust
Spoilers - VERIFY EXTENDED

Brakes - AS REQUIRED

Autobrake - OFF

Taxi to Ramp

Strobe Lights - OFF Flaps - UP

Spoilers - RETRACTED

Taxi Lights – ON

Landing Lights – OFF Taxi to Assigned Gate/Parking (Speed Max 20 knots)

Transponder – 1200

Elevator Trim - TAKEOFF SETTING

Lights - AS DESIRED

Shutdown Checklist

Brake -**SET** Throttle -**IDLE** OFF Passenger Signs -Anti-Ice -OFF Taxi Lights -OFF Nav Lights -**OFF** Flight Director -OFF Avionics -OFF Fuel Flow -**CUTOFF** OFF Beacon -

BATT Master Switch - OFF (Shift-M)