
802.15.4 Superframe

802.15.4 Superframe 구조



SO = Superframe order

BO = Beacon order

Superframe 계산

$$\begin{split} \mathit{SlotD} = \mathit{aBaseSlotDuration} \times 2^{\mathit{SO}}[\mathit{symbols}] \\ = 60 \times 2^{\mathit{SO}}[\mathit{symbols}] = 0.96 \times 2^{\mathit{SO}}[\mathit{ms}] \end{split}$$

$$SD \\ = aBaseSuperframeDuration \times 2^{SO}[symbols] \\ = 960 \times 2^{SO}[symbols] = 15.36 \times 2^{SO}[ms]$$

$$\begin{split} BI = aBaseSuperframeDuration \times 2^{SO}[symbols] \\ = 960 \times 2^{SO}[symbols] = 15.36 \times 2^{SO}[ms] \end{split}$$