
Host to Endpoint Sequence Diagram (We combined our AHB slave and Data buffer to be one functional block)



^{*} Data not porperly stored or not valid means during data-receiving process, if


⁽¹⁾ buffer is reserved

⁽²⁾ Buffer Occupancy greater than 64

⁽³⁾ CRC checksum does not pass

^{*} Everytime a NAK signal been sent out, Protocol Controller asserts **RX_ERROR** to the AHB_SLAVE

Endpoint to HOST Sequence Diagram (We combined our AHB slave and Data buffer to be one functional block)



^{*} Finish Loading means **TX_PACKET_DATA_SIZE** equal to **BUFFER_OCCUPANCY** Everytime a NAK signal been sent out, Protocol Controller asserts **RX_ERROR** to the AHB_SLAVE