Table 4.8: Transition Dependent Anchor Points of Advanced Nodes




Figure 1 tikz-timing-advnodes 示意图




Figure 2.1: Timing Shape Anchors. The start and end anchors mark the start and end of the timing signal.

Figure 2 tikz-timing-anchor 示意图

Table 2.1: Timing Characters

Character	Description	Diagram	Transition Example	
Н	High	\blacksquare	<u> </u>	
L	Low	\blacksquare	\coprod	
Z	High Impedance		\blacksquare	
Х	Undefined / Don't Care	\blacksquare	\blacksquare	
D	Data / Double	\blacksquare	(A)(
U	Unknown Data		X	
T	Toggle	oxplus or $oxplus$		
C	Clock (no slope)	oxplus or $oxplus$		
М	Metastable Condition	MM.	WW.	
G	Glitch (zero width)	ı		
S	Space (nothing)	\blacksquare		

Table 2.2: Overview over all transitions.

from	Н	L	Z	Χ	М	D	U	Т	С
Н		Ш			₩		$\boxplus \Box$	Ш	
L	▥				₩				
Z	==		===				#		
Χ	₩	III			WW	+(#(#
М	WW.	W.	WW	WW	WWW	ww(WW(ww	WW
D				—) ww				
U				—	WW				
Т	▥		-						
С	⊞⊞	Ш		III	<u></u> ////			ш	

Figure 3 tikz-timing-char 示意图