

---

# Vicon DataStream SDK

## Developer's Manual

---

### Contents

About the Vicon DataStream Software Development Kit (SDK).....	4
Installing on Windows .....	5
Installing on Linux .....	5
Installing on Mac OSX .....	5
Application Linking and Redistribution .....	6
Windows – C++ .....	6
Windows – .NET .....	6
Windows – MATLAB .....	6
Linux – C++ .....	6
Mac OSX – C++ .....	7
What's New in Version 1.4.0 .....	8
Requirements .....	8
Function <i>Result</i> Return Values.....	9
Conventions.....	9
Units.....	9
Vectors and Matrices .....	9
Euler Angles .....	9
List of all SDK Functions .....	10
Construction and Destruction .....	10
Result .....	11
GetVersion.....	14
Connect .....	15
ConnectToMulticast .....	16
Disconnect.....	17
IsConnected.....	18
StartTransmittingMulticast.....	19

---

© Copyright 2014 Vicon Motion Systems Limited. All rights reserved.

*Vicon DataStream SDK Developer's Manual* March 2014.  
For use with Vicon DataStream SDK 1.4.0 and later.

Vicon® is a registered trademark of OMG plc. Vicon Blade™, Vicon Nexus™, Vicon Tracker™, Bonita™, Vicon MX™, and Vicon MX T-Series™ are trademarks of OMG plc. Other product and company names herein may be the trademarks of their respective owners. Vicon Motion Systems is an OMG plc company.

Email: [support@vicon.com](mailto:support@vicon.com). Web: [www.vicon.com](http://www.vicon.com).

StopTransmittingMulticast .....	20
EnableSegmentData.....	21
EnableMarkerData.....	22
EnableUnlabeledMarkerData.....	23
EnableDeviceData .....	24
DisableSegmentData.....	25
DisableMarkerData.....	26
DisableUnlabeledMarkerData.....	27
DisableDeviceData .....	28
IsSegmentDataEnabled .....	29
IsMarkerDataEnabled .....	30
IsUnlabeledMarkerDataEnabled .....	31
IsDeviceDataEnabled .....	32
SetStreamMode .....	33
SetApexDeviceFeedback .....	35
SetAxisMapping .....	36
GetAxisMapping .....	37
GetFrame .....	38
GetFrameNumber .....	39
GetLatencyTotal.....	40
GetLatencySampleCount.....	41
GetLatencySampleName.....	42
GetLatencySampleValue .....	43
GetTimecode .....	44
GetFrameRate .....	46
GetSubjectCount .....	47
GetSubjectName .....	48
GetSubjectRootSegmentName .....	50
GetSegmentCount.....	51
GetSegmentName.....	53
GetSegmentParentName .....	55
GetSegmentChildCount.....	57
GetSegmentChildName.....	59
GetSegmentStaticTranslation .....	61
GetSegmentStaticRotationHelical .....	62
GetSegmentStaticRotationMatrix .....	63
GetSegmentStaticRotationQuaternion .....	64
GetSegmentStaticRotationEulerXYZ.....	65
GetSegmentGlobalTranslation .....	66
GetSegmentGlobalRotationHelical .....	68
GetSegmentGlobalRotationMatrix .....	69
GetSegmentGlobalRotationQuaternion .....	70
GetSegmentGlobalRotationEulerXYZ.....	72
GetSegmentLocalTranslation .....	73
GetSegmentLocalRotationHelical.....	75
GetSegmentLocalRotationMatrix .....	76

GetSegmentLocalRotationQuaternion .....	77
GetSegmentLocalRotationEulerXYZ .....	79
GetMarkerCount .....	80
GetMarkerName .....	82
GetMarkerParentName .....	84
GetMarkerGlobalTranslation .....	85
GetUnlabeledMarkerCount .....	87
GetUnlabeledMarkerGlobalTranslation .....	88
GetDeviceCount .....	89
GetDeviceName .....	90
GetDeviceOutputCount .....	92
GetDeviceOutputName .....	94
GetDeviceOutputValue .....	96
GetDeviceOutputSubsamples .....	98
GetDeviceOutputValue <sub>2</sub> .....	100
GetForcePlateCount .....	102
GetGlobalForceVector .....	103
GetGlobalMomentVector .....	105
GetGlobalCentreOfPressure .....	107
GetForcePlateSubsamples .....	109
GetGlobalForceVector <sub>2</sub> .....	111
GetGlobalMomentVector <sub>2</sub> .....	113
GetGlobalCentreOfPressure <sub>2</sub> .....	115
GetEyeTrackerCount .....	117
GetEyeTrackerGlobalPosition .....	118
GetEyeTrackerGlobalGazeVector .....	120
Appendix A – What's New .....	122
What's New in Version 1.0 .....	122
What's New in Version 1.0.1 .....	122
What's New in Version 1.1.0 .....	122
What's New in Version 1.2.0 .....	123
What's New in Version 1.3.0 .....	123

## About the Vicon DataStream Software Development Kit (SDK)

The Vicon DataStream Software Development Kit (SDK) allows easy programmable access to the information contained in the Vicon DataStream. The function calls within the SDK allow users to connect to and request data from the Vicon DataStream. The following combinations of platforms and technologies are supported:

	Windows x86 (32-bit)	Windows x64 (64-bit)	Linux x86 (32-bit)	Linux x64 (64-bit)	Mac OSX (64&32-bit)
C++	✓	✓	✓	✓	✓
.NET	✓	✓			
MATLAB	✓ (can be run on Windows 64-bit OS)	✓ (requires Microsoft Professional compiler)			

### Important Notes:

- Not all function calls contained within the SDK will return data when connected to certain Vicon Applications. For example, Vicon Blade does not support analog devices, and therefore will not output device information into the DataStream.
- The current DataStream format is supported by Vicon Nexus 1.4+, Vicon Blade 1.6+, and Tracker 1.0+. These applications may also output an additional stream in the legacy Tarsus format. This DataStream SDK only accesses the DataStream format.
- The current intention is that all future Vicon applications will support the DataStream format.
- Example files are supplied as *unsupported* examples only.
- The SDK only supports axis transformations into right handed co-ordinate systems.
- The SDK is designed to allow multiple instances of a Client within a single process which can connect to multiple DataStreams.

The SDK is supplied as shared libraries – DLLs on Windows, SOs on Linux, and DYLIBs on MacOS. The shared libraries and supporting files are required to be copied alongside your client executable.

## Installing on Windows

There are separate installers for the 32-bit and 64-bit SDKs. The 64-bit installer will only work on a 64-bit version of Windows. The default install directories are:

### 64-bit Windows

- 32-bit SDK : C:\Program Files (x86)\Vicon\DataStream SDK\Win32
- 64-bit SDK : C:\Program Files\Vicon\DataStream SDK\Win64

### 32-bit Windows

- 32-bit SDK : C:\Program Files\Vicon\DataStream SDK\Win32

## Installing on Linux

The SDK is provided as a compressed archive. Extract the archive into a convenient location on your system.

## Installing on Mac OSX

The dylibs should be placed in /usr/lib and marked as executable:

```
sudo cp libViconDataStreamSDK_CPP.dylib /usr/lib
sudo cp libDebugServices.dylib /usr/lib
sudo chmod 755 /usr/lib/libViconDataStreamSDK_CPP.dylib
sudo chmod 755 /usr/lib/ libDebugServices.dylib
```

## Application Linking and Redistribution

### Windows – C++

Your application should

- #include "Client.h"
- Link against "ViconDataStreamSDK\_CPP.lib"
- Redistribute:
  - "ViconDataStreamSDK\_CPP.dll"
  - "Microsoft.VC8.CRT" (x86) or "Microsoft.VC9.CRT" (x64).

### Windows – .NET

Your application should

- Link against the assembly "ViconDataStreamSDK\_DotNET.dll".
- Redistribute:
  - "ViconDataStreamSDK\_DotNET.dll"
  - "ViconDataStreamSDK\_CPP.dll"
  - "Microsoft.VC8.CRT" (x86) or "Microsoft.VC9.CRT" (x64).
- Have the .NET Framework 2.0 or later installed.

The managed code in this assembly requires the unmanaged code in the C++ SDK

### Windows – MATLAB

Your application M file should be in the same directory as

- "Client.m"
- "DeviceType.m"
- "Direction.m"
- "Result.m"
- "StreamMode.m"
- "TimecodeStandard.m"
- "Unit.m"
- "ViconDataStreamSDK\_MATLAB.dll"
- "ViconDataStreamSDK\_MATLAB.h"
- "Microsoft.VC8o.CRT"

### Linux – C++

Your application should

- #include "Client.h"
- Link against libViconDataStreamSDK\_CPP.so and libDebugServices.so
- Redistribute libViconDataStreamSDK\_CPP.so and libDebugServices.so
- To compile ViconDataStreamSDK\_CPPTest.cpp test application:
  - Execute "g++ ViconDataStreamSDK\_CPPTest.cpp -L. -lViconDataStreamSDK\_CPP – lDebugServices"

- (-L. assumes the libraries LibViconDataStreamSDK\_CPP.so and libDebugServices.so are in the current directory)
- || To run ViconDataStreamSDK\_CPPTest test application:
  - Set LD\_LIBRARY\_PATH to location of LibViconDataStreamSDK\_CPP.so and libDebugServices.so:
    - (on bash shell) export LD\_LIBRARY\_PATH=.
  - Execute ViconDataStreamSDK\_CPPTest
- || N.B. To build and run with LibViconDataStreamSDK\_CPP.so and libDebugServices.so in a different directory (e.g./foo/bar), change -L.in compile line to -L/foo/bar, and set LD\_LIBRARY\_PATH to /foo/bar

#### Mac OSX – C++

Requirements are

- || Intel 64 or 32 bit

Your application should

- || #include "Client.h"
- || Link against "libViconDataStreamSDK\_CPP.dylib" and "libDebugServices.dylib"
- || Redistribute "libViconDataStreamSDK\_CPP.dylib" and "libDebugServices.dylib"
- || To compile ViconDataStreamSDK\_CPPTest.cpp test application:
  - Execute "g++ ViconDataStreamSDK\_CPPTest.cpp -L. -lViconDataStreamSDK\_CPP -lDebugServices"
  - (-L. assumes the libraries libViconDataStreamSDK\_CPP.dylib and libDebugServices.dylib are in the current directory)
- || To run ViconDataStreamSDK\_CPPTest test application:
  - Set DYLD\_LIBRARY\_PATH to location of libViconDataStreamSDK\_CPP.dylib and libDebugServices.dylib:
    - (on bash shell) export DYLD\_LIBRARY\_PATH=.
  - Execute ViconDataStreamSDK\_CPPTest
- || N.B. To build and run with libViconDataStreamSDK\_CPP.dylib and libDebugServices.dylib in a different directory (e.g./foo/bar), change -L.in compile line to -L/foo/bar, and set DYLD\_LIBRARY\_PATH to /foo/bar

The SDK was compiled with gcc version 4.2.1 (Apple Inc. Build 5646) using flags:

```
-mmacosx-version-min=10.4 -isysroot /Developer/SDKs/MacOSX10.6.sdk -arch i386 -arch x86_64 -O2
```

## What's New in Version 1.4.0

- New function calls:
  - SetApexDeviceFeedback.

## Requirements

- A compatible licensed version of Vicon Blade, Vicon Nexus, or Vicon Tracker must be present.
  - LabVIEW will make use of the .NET dll, and has been found to function in versions 7.1 and 8.
- The MATLAB dll has been found to function in versions 7 and 8.
- The SDK has not been designed to allow access from Simulink.
- The Linux SDK has been specifically verified on CentOS 5.5, Ubuntu 8.04, Ubuntu 9.04, Fedora 9, and Fedora 11. It should also work on any platform supporting glibc 2.5 or later.

## Function *Result* Return Values

Every function returns a data structure containing elements specified in the "Output" section of each method reference. Most functions return a "Result" item, which indicates the success or cause of failure for the function and useful for debugging purposes.

When a function has returned false, the output arguments are set to an appropriate default value:

- Booleans will be set to false.
- Integers will be set to zero.
- Doubles will be set to zero.
- Strings will be set to zero length.

When the output argument is an array, all elements are set in this manner.

## Conventions

By default the global coordinate system matches the server application; Z-Up, Y-Left. This can be changed by using Client::SetAxisMapping.

### Units

Positions are expressed in millimeters. Rotation is expressed in radians.

### Vectors and Matrices

Positions are passed as 3 elements corresponding to (x,y,z).

A 3 matrix is passed row-wise as a vector of 9 elements:

$$\begin{vmatrix} x_0 & x_1 & x_2 \\ x_3 & x_4 & x_5 \\ x_6 & x_7 & x_8 \end{vmatrix}$$

Matrices are assumed to pre-multiply:

$$ABC = A(BC)$$

### Euler Angles

When used an XYZ Euler angle (x,y,z) is constructed:

$$R_x \ R_y \ R_z$$

$$R_x(R_y \ R_z)$$

$$\begin{vmatrix} 1 & 0 & 0 \\ 0 & \cos x & -\sin x \\ 0 & \cos x & \sin x \end{vmatrix} \begin{vmatrix} \cos y & 0 & \sin y \\ 0 & 1 & 0 \\ -\sin y & 0 & \cos y \end{vmatrix} \begin{vmatrix} \cos z & -\sin z & 0 \\ \sin z & \cos z & 0 \\ 0 & 0 & 1 \end{vmatrix} \begin{vmatrix} \cos y \cos z & -\cos y \sin z & \sin y \\ \cos x \sin z + \sin x \sin y \cos z & \cos x \cos z - \sin x \sin y \sin z & -\sin x \cos y \\ \sin x \sin z - \cos x \sin y \cos z & \sin x \cos z + \cos x \sin y \sin z & \cos x \cos y \end{vmatrix}$$

## List of all SDK Functions

### Construction and Destruction

*You can create many instances of the Vicon DataStream Client which can connect to multiple Vicon DataStream Servers.*

C++	<p>C++ is object oriented, so use the class constructor.</p> <pre>{     ViconDataStreamSDK::CPP::Client StackClient;     Output_SomeFunction Output = StackClient.SomeFunction();     ... } // Client is implicitly destroyed as it goes out of scope</pre> <p>ViconDataStreamSDK::CPP::Client * pHeapClient =     new ViconDataStreamSDK::CPP::Client(); Output_SomeFunction Output = pHeapClient-&gt;SomeFunction( Input ); delete pHeapClient;</p>
MATLAB	The MATLAB SDK is object oriented, and needs to be explicitly loaded and unloaded.  Client.LoadViconDataStreamSDK();  pHeapClient = Client(); Output = pHeapClient.SomeFunction( Input );  Client.UnloadViconDataStreamSDK();
.NET	<p>.NET is object oriented, so use the class constructor. Because objects are lazily garbage collected, your instance may outlive the last reference to it for some time. If the instance is pre-fetching frame data for you, then it can still use CPU and network bandwidth. Consider explicitly disconnecting prior to destruction.</p> <pre>C# ViconDataStreamSDK.DotNET.Client pHeapClient =     new ViconDataStreamSDK.DotNET.Client(); Output_SomeFunction Output = pHeapClient.SomeFunction( InputParam );  // Signal to the garbage collector that it can clean up pHeapClient.Disconnect(); pHeapClient = null;</pre>

## Result

*The Result code indicates the success or failure of a function.*

	Unknown	The result is unknown. Treat it as a failure.
	NotImplemented	The function called has not been implemented in this version of the SDK.
	Success	The function call succeeded.
	InvalidHostName	The "HostName" parameter passed to Connect() is invalid.
	InvalidMulticastIP	The "MulticastIP" parameter was not in the range "224.0.0.0" – "239.255.255.255"
	ClientAlreadyConnected	Connect() was called whilst already connected to a DataStream.
	ClientConnectionFailed	Connect() could not establish a connection to the DataStream server.
	ServerAlreadyTransmittingMulticast	StartTransmittingMulticast() was called when the current DataStream server was already transmitting multicast on behalf of this client.
	ServerNotTransmittingMulticast	StopTransmittingMulticast() was called when the current DataStream server was not transmitting multicasts on behalf of this client.
	NotConnected	You have called a function which requires a connection to the DataStream server, but do not have a connection.
	NoFrame	You have called a function which requires a frame to be fetched from the DataStream server, but do not have a frame.
	InvalidIndex	An index you have passed to a function is out of range.
	InvalidSubjectName	The Subject Name you passed to a function is invalid in this frame.
	InvalidSegmentName	The Segment Name you passed to a function is invalid in this frame.
	InvalidMarkerName	The Marker Name you passed to a function is invalid in this frame.
	InvalidDeviceName	The Device Name you passed to a function is invalid in this frame.
	InvalidDeviceOutputName	The Device Output Name you passed to a function is invalid in this frame.

	InvalidLatencySampleName	The Latency Sample Name you passed to a function is invalid in this frame.
	CoLinearAxes	The directions passed to SetAxisMapping() contain input which would cause two or more axis to lie along the same line, e.g. "Up" and "Down" are on the same line.
	LeftHandedAxes	The directions passed to SetAxisMapping() would result in a left handed co-ordinate system. This is not supported in the SDK.
C++	<pre>namespace ViconDataStreamSDK { namespace CPP { namespace Result {     enum Enum     {         Unknown,         NotImplemented,         Success,         InvalidHostName,         InvalidMulticastIP,         ClientAlreadyConnected,         ClientConnectionFailed,         ServerAlreadyTransmittingMulticast,         ServerNotTransmittingMulticast,         NotConnected,         NoFrame,         InvalidIndex,         InvalidSubjectName,         InvalidSegmentName,         InvalidMarkerName,         InvalidDeviceName,         InvalidDeviceOutputName,         InvalidLatencySampleName,         CoLinearAxes,         LeftHandedAxes     }; } }</pre>	
MATLAB	<pre>classdef Result properties (Constant = true)     Unknown          = 0;     NotImplemented   = 1;     Success          = 2;     InvalidHostName  = 3;     InvalidMulticastIP = 4;     ClientAlreadyConnected = 6;     ClientConnectionFailed = 7;     ServerAlreadyTransmittingMulticast = 8;     ServerNotTransmittingMulticast = 9;     NotConnected      = 10;     NoFrame           = 11;     InvalidIndex       = 12;     InvalidSubjectName = 13;     InvalidSegmentName = 14;     InvalidMarkerName  = 15;     InvalidDeviceName  = 16;     InvalidDeviceOutputName = 17;     InvalidLatencySampleName = 18;     CoLinearAxes       = 19;     LeftHandedAxes     = 20; end  properties     Value</pre>	

	<pre>end  methods     function obj = Result( value )         obj.Value = value;     end% Constructor     end% methods  end% classdef</pre>
.NET	<pre>namespace ViconDataStreamSDK {     namespace DotNET     {         public enum class Result         {             Unknown,             NotImplemented,             Success,             InvalidHostName,             InvalidMulticastIP,             ClientAlreadyConnected,             ClientConnectionFailed,             ServerAlreadyTransmittingMulticast,             ServerNotTransmittingMulticast,             NotConnected,             NoFrame,             InvalidIndex,             InvalidSubjectName,             InvalidSegmentName,             InvalidMarkerName,             InvalidDeviceName,             InvalidDeviceOutputName,             InvalidLatencySampleName,             CoLinearAxes,             LeftHandedAxes         };     } // End of namespace DotNET } // End of namespace ViconDataStreamSDK</pre>

## GetVersion

*Get the version of the Vicon DataStream SDK*

Get the version of the Vicon DataStream SDK			
Input			
Output	Major	unsigned int	The major version number. When this number increases we break backwards compatibility with previous major versions.
	Minor	unsigned int	The minor version number. When this number increases we have probably added new functionality to the SDK without breaking backwards compatibility with previous versions.
	Point	unsigned int	The point version number. When this number increases, we have introduced a bug fix or performance enhancement without breaking backwards compatibility with previous versions.
C++	<pre>// class Output_GetVersion // { // public: //     unsigned int Major; //     unsigned int Minor; //     unsigned int Point; // }; // // Output_GetVersion GetVersion() const;  ViconDataStreamSDK::CPP::Client MyClient; Output_GetVersion Output = MyClient.GetVersion();</pre>		
MATLAB	<pre>% [Output] = GetVersion()  MyClient = Client(); Output = MyClient.GetVersion();</pre>		
.NET	<pre>// class Output_GetVersion // { //     public uint Major; //     public uint Minor; //     public uint Point; // }; // // Output_GetVersion GetVersion();  ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); Output_GetVersion Output = MyClient.GetVersion();</pre>		

## Connect

*Establish a dedicated connection to a Vicon DataStream Server*

*See also:* [ConnectToMulticast](#), [Disconnect](#), [IsConnected](#)

<b>Input</b>	Host Name	string	The DNS identifiable name, or IP address of the PC hosting the DataStream server. The function defaults to connecting on port 801. You can specify an alternate port number after a colon.  "localhost" "MyViconPC:804" "10.0.0.2"
<b>Output</b>	<b>Result</b>	<b>Result</b>	Result.Success Result.InvalidHostName Result.ClientAlreadyConnected Result.ClientConnectionFailed
<b>C++</b>	<pre>// class Output_Connect // { // public: //     Result::Enum Result; // }; // // Output_Connect Connect( const String &amp; HostName );  ViconDataStreamSDK::CPP::Client MyClient; Output_Connect Output = MyClient.Connect( "localhost:801" );</pre>		
<b>MATLAB</b>	<pre>% [Output] = Connect()  MyClient = Client(); Output = MyClient.Connect( 'localhost:801' );</pre>		
<b>.NET</b>	<pre>// class Output_Connect // { //     public Result Result; // }; // // Output_Connect Connect( string HostName );  ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); Output_Connect Output = MyClient.Connect( "localhost:801" );</pre>		

## ConnectToMulticast

*Connect to a Vicon DataStream Server's Multicast stream. The stream content is managed by a client who calls StartTransmittingMulticast().*

*See also:* [Connect](#), [Disconnect](#), [IsConnected](#), [StartTransmittingMulticast](#), [StopTransmittingMulticast](#)

Input	LocalIP	string	The DNS identifiable name, or IP address of the local Ethernet interface on which you wish to receive multicast data. You should not specify a port (any port specified will be ignored). e.g.  "localhost" "10.0.0.2"
	Multicast IP	string	The IP Address of the Multicast group on which data will be received. The address should be in the range "224.0.0.0" – "239.255.255.255" You may also specify a port by appending it to the end of the IP Address after a colon. e.g. 224.0.0.0:30001. If you do not specify a port it will default to 44801.
Output	Result	Result	Result.Success Result.InvalidHostName Result.InvalidMulticastIP Result.ClientAlreadyConnected Result.ClientConnectionFailed
C++	<pre>// class Output_ConnectToMulticast // { // public: //     Result::Enum Result; // }; // // Output_ConnectToMulticast // ConnectToMulticast ( const String &amp; LocalIP, //                     const String &amp; MulticastIP ); ViconDataStreamSDK::CPP::Client MyClient; Output_ConnectToMulticast Output =     MyClient.ConnectToMulticast( "localhost", "224.0.0.0" );</pre>		
MATLAB	<pre>% [Output] = ConnectToMulticast()  MyClient = Client(); Output = MyClient.ConnectToMulticast( 'localhost', '224.0.0.0' );</pre>		
.NET	<pre>// class Output_ConnectToMulticast // { //     public Result Result; // }; // // Output_ConnectToMulticast ConnectToMulticast ( string LocalIP, //   string MulticastIP );  ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); Output_ConnectToMulticast Output =     MyClient.ConnectToMulticast( "localhost", "224.0.0.0" );</pre>		

## Disconnect

*Disconnect from the Vicon DataStream Server.*

*See also:* [Connect](#), [IsConnected](#)

Input			
Output	Result	Result	Result.Success Result.NotConnected
C++	// class Output_Disconnect // { //   public: //     Result::Enum Result; //   }; // // Output_Disconnect Disconnect();  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); Output_Disconnect Output = MyClient.Disconnect();		
MATLAB	% [Output] = Connect()  MyClient = Client(); MyClient.Connect( "localhost" ); Output = MyClient.Disconnect();		
.NET	// public class Output_Disconnect // { //   public Result Result; // }; // // Output_Disconnect Disconnect()  ViconDataStreamSDK.DotNET.Client MyClient = new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect( "localhost" ); Output_Disconnect Output = MyClient.Disconnect();		

## IsConnected

*Discover whether client is connected to the Vicon DataStream Server.*

*See also:* Connect, Disconnect

Input			
Output	Connected	boolean	True if you are connected to the stream, otherwise false.
C++	<pre>// class Output_IsConnected // { // public: //     bool Connected; // }; // // Output_IsConnected IsConnected() const;  ViconDataStreamSDK::CPP::CPP::Client MyClient; Output_IsConnected Output = MyClient.IsConnected()                                 // Output.Connected == false MyClient.Connect( "localhost" ); Output_IsConnected Output = MyClient.IsConnected()                                 // Output.Connected == true                                 // (assuming localhost is serving)</pre>		
MATLAB	<pre>% [Output] = IsConnected()  MyClient = Client(); Output = MyClient.IsConnected()    // Output.Connected == false MyClient.Connect( "localhost" ); Output = MyClient.IsConnected()    // Output.Connected == true                                 // (assuming localhost is serving)</pre>		
NET	<pre>// public class Output_IsConnected // { //     public bool Connected; // }; // // Output_IsConnected IsConnected();  ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); Output_IsConnected Output = MyClient.IsConnected()                                 // Output.Connected == false MyClient.Connect( "localhost" ); Output_IsConnected Output = MyClient.IsConnected()                                 // Output.Connected == true                                 // (assuming localhost is serving)</pre>		

**StartTransmittingMulticast**

*Ask the DataStream Server to start transmitting the data you are receiving directly to a Multicast address as well. This allows multiple clients to connect to your stream (via ConnectToMulticast()) whilst minimizing network bandwidth use and frame delivery latency.*

*See also:* [Connect](#), [ConnectToMulticast](#), [Disconnect](#), [StopTransmittingMulticast](#)

<b>Input</b>	ServerIP	string	The IP Address of the server Ethernet interface from which the Multicast data will be sent. You should not specify a port number (any port number specified will be ignored)
	MulticastIP	string	The IP Address of the Multicast group to which multicast data will be sent. The address should be in the range "224.0.0.0" – "239.255.255.255" You may also specify the port the data will be sent to by appending it to the IP Address after a colon e.g. 224.0.0.0:30001. If you do not specify a port it will default to 44801.
<b>Output</b>	<b>Result</b>	<b>Result</b>	Result.Success Result.NotConnected Result.InvalidMulticastIP Result.ServerAlreadyTransmittingMulticast
<b>C++</b>	<pre>// class Output_StartTransmittingMulticast // { // public: //     Result::Enum Result; // }; // // Output_StartTransmittingMulticast // StartTransmittingMulticast ( const String &amp; ServerIP, //                             const String &amp; MulticastIP ) const;  ViconDataStreamSDK::CPP::CPP::Client MyClient; MyClient.Connect( "localhost" ); MyClient.StartTransmittingMulticast( "10.0.0.1", "224.0.0.0" );</pre>		
<b>MATLAB</b>	<pre>% [Output] = StartTransmittingMulticast ()  MyClient = Client(); MyClient.Connect( "localhost" ); MyClient.StartTransmittingMulticast( '10.0.0.1', '224.0.0.0' );</pre>		
<b>.NET</b>	<pre>// public class Output_StartTransmittingMulticast // { //     public Result Result; // }; // // Output_StartTransmittingMulticast // StartTransmittingMulticast( string ServerIP, string MulticastIP );  ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect( "localhost" ); MyClient.StartTransmittingMulticast("10.0.0.1", "224.0.0.0" );</pre>		

## StopTransmittingMulticast

*Ask the DataStream Server to stop transmitting the data you are receiving directly to a Multicast address as well. You must previously have started a transmission via StartTransmittingMulticast.*

*See also:* [Connect](#), [ConnectToMulticast](#), [Disconnect](#), [StartTransmittingMulticast](#)

Input			
Output	Result	Result	Result.Success Result.NotConnected Result.ServerNotTransmittingMulticast
C++	<pre>// class Output_StopTransmittingMulticast // { //     public: //         Result::Enum Result; //     }; // //     Output_StopTransmittingMulticast //     StopTransmittingMulticast () const;  ViconDataStreamSDK::CPP::CPP::Client MyClient; MyClient.Connect( "localhost" ); MyClient.StartTransmittingMulticast( "10.0.0.1", "224.0.0.0" ); // Do some stuff MyClient.StopTransmittingMulticast();</pre>		
MATLAB	<pre>% [Output] = StopTransmittingMulticast ()  MyClient = Client(); MyClient.Connect( "localhost" ); MyClient.StartTransmittingMulticast( '10.0.0.1', '224.0.0.0' ); % Do some stuff MyClient.StopTransmittingMulticast();</pre>		
.NET	<pre>// public class Output_StopTransmittingMulticast // { //     public Result Result; // }; // // Output_StopTransmittingMulticast // StopTransmittingMulticast();  ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect( "localhost" ); MyClient.StartTransmittingMulticast( "10.0.0.1", "224.0.0.0" ); // Do some stuff MyClient.StopTransmittingMulticast();</pre>		

## EnableSegmentData

*Enable kinematic segment data in the Vicon DataStream. You should call this function on startup, after connecting to the server, and before trying to read local or global segment data.*

*See also:* IsSegmentDataEnabled, DisableSegmentData, EnableMarkerData, EnableUnlabeledMarkerData, EnableDeviceData, GetSegmentCount, GetSegmentName, GetSegmentGlobalTranslation, GetSegmentGlobalRotationXXX, GetSegmentLocalTranslation, GetSegmentLocalRotationXXX

Input			
Output	Result	Result	Result.NotConnected Result.Success
C++	<pre>// class Output_EnableSegmentData // { //     public: //         Result::Enum Result; //     }; // // Output_EnableSegmentData EnableSegmentData();  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); Output_EnableSegmentData Output = MyClient.EnableSegmentData();</pre>		
MATLAB	<pre>% [Output] = EnableSegmentData()  MyClient = Client(); MyClient.Connect( "localhost" ); Output = MyClient.EnableSegmentData();</pre>		
.NET	<pre>// public class Output_EnableSegmentData // { //     public Result Result; // }; // // Output_EnableSegmentData EnableSegmentData();  ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect( "localhost" ); Output_EnableSegmentData Output = MyClient.EnableSegmentData();</pre>		

## EnableMarkerData

*Enable labeled reconstructed marker data in the Vicon DataStream. You should call this function on startup, after connecting to the server, and before trying to read labeled marker data.*

*See also:* [IsMarkerDataEnabled](#), [DisableMarkerData](#), [EnableSegmentData](#), [EnableUnlabeledMarkerData](#), [EnableDeviceData](#), [GetMarkerCount](#), [GetMarkerName](#), [GetSegmentGlobalTranslation](#)

Input			
Output	Result	Result	Result.NotConnected Result.Success
C++	<pre>// class Output_EnableMarkerData // { //     public: //         Result::Enum Result; //     }; // // Output_EnableMarkerData EnableMarkerData();  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); Output_EnableMarkerData Output = MyClient.EnableMarkerData();</pre>		
MATLAB	<pre>% [Output] = EnableMarkerData()  MyClient = Client(); MyClient.Connect( "localhost" ); Output = MyClient.EnableMarkerData();</pre>		
.NET	<pre>// public class Output_EnableMarkerData // { //     public Result Result; // }; // // Output_EnableMarkerData EnableMarkerData();  ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect( "localhost" ); Output_EnableMarkerData Output = MyClient.EnableMarkerData();</pre>		

## EnableUnlabeledMarkerData

*Enable unlabeled reconstructed marker data in the Vicon DataStream. You should call this function on startup, after connecting to the server, and before trying to read global unlabeled marker data.*

*See also:* [IsUnlabeledMarkerDataEnabled](#), [DisableUnlabeledMarkerData](#), [EnableSegmentData](#), [EnableMarkerData](#), [EnableDeviceData](#), [GetUnlabeledMarkerCount](#), [GetUnlabeledMarkerGlobalTranslation](#)

Input			
Output	Result	Result	Result.NotConnected Result.Success
C++	<pre>// class Output_EnableUnlabeledMarkerData // { //     public: //         Result::Enum Result; //     }; // // Output_EnableUnlabeledMarkerData EnableUnlabeledMarkerData();  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); Output_EnableUnlabeledMarkerData Output =     MyClient.EnableUnlabeledMarkerData();</pre>		
MATLAB	<pre>% [Output] = EnableUnlabeledMarkerData()  MyClient = Client(); MyClient.Connect( "localhost" ); Output = MyClient.EnableUnlabeledMarkerData();</pre>		
.NET	<pre>// public class Output_EnableUnlabeledMarkerData // { //     public Result Result; // }; // // Output_EnableUnlabeledMarkerData EnableUnlabeledMarkerData();  ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect( "localhost" ); Output_EnableUnlabeledMarkerData Output =     MyClient.EnableUnlabeledMarkerData();</pre>		

## EnableDeviceData

*Enable ForcePlate, EMG, and other device data in the Vicon DataStream. You should call this function on startup, after connecting to the server, and before trying to read device information.*

*See also:* [IsDeviceDataEnabled](#), [DisableDeviceData](#), [EnableSegmentData](#), [EnableMarkerData](#), [EnableUnlabeledMarkerData](#), [GetDeviceCount](#), [GetDeviceName](#), [GetDeviceOutputCount](#), [GetDeviceOutputName](#), [GetDeviceOutputValue](#)

Input			
Output	Result	Result	Result.NotConnected Result.Success
C++	<pre>// class Output_EnableDeviceData // { //     public: //         Result::Enum Result; //     }; // // Output_EnableDeviceData EnableDeviceData();  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); Output_EnableDeviceData Output = MyClient.EnableDeviceData();</pre>		
MATLAB	<pre>% [Output] = EnableDeviceData()  MyClient = Client(); MyClient.Connect( "localhost" ); Output = MyClient.EnableDeviceData();</pre>		
.NET	<pre>// public class Output_EnableDeviceData // { //     public Result Result; // }; // // Output_EnableDeviceData EnableDeviceData();  ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect( "localhost" ); Output_EnableDeviceData Output = MyClient.EnableDeviceData();</pre>		

## DisableSegmentData

*Disable kinematic segment data in the Vicon DataStream.*

*See also:* [IsSegmentDataEnabled](#), [EnableSegmentData](#), [EnableMarkerData](#), [EnableUnlabeledMarkerData](#), [EnableDeviceData](#), [GetSegmentCount](#), [GetSegmentName](#), [GetSegmentGlobalTranslation](#), [GetSegmentGlobalRotationXXX](#), [GetSegmentLocalTranslation](#), [GetSegmentLocalRotationXXX](#)

Input			
Output	Result	Result	Result.NotConnected Result.Success
C++	<pre>// class Output_DisableSegmentData // { //     public: //         Result::Enum Result; //     }; // // Output_DisableSegmentData DisableSegmentData();</pre> <pre>ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); Output_DisableSegmentData Output = MyClient.DisableSegmentData();</pre>		
MATLAB	<pre>% [Output] = DisableSegmentData()  MyClient = Client(); MyClient.Connect( "localhost" ); Output = MyClient.DisableSegmentData();</pre>		
.NET	<pre>// public class Output_DisableSegmentData // { //     public Result Result; // }; // // Output_DisableSegmentData DisableSegmentData();</pre> <pre>ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect( "localhost" ); Output_DisableSegmentData Output = MyClient.DisableSegmentData();</pre>		

## DisableMarkerData

*Disable labeled reconstructed marker data in the Vicon DataStream.*

*See also:* IsMarkerDataEnabled, EnableMarkerData, EnableSegmentData, EnableUnlabeledMarkerData, EnableDeviceData, GetMarkerCount, GetMarkerName, GetMarkerGlobalTranslation

Input			
Output	Result	Result	Result.NotConnected Result.Success
C++	<pre>// class Output_DisableMarkerData // { //     public: //         Result::Enum Result; //     }; // // Output_DisableMarkerData DisableMarkerData();  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); Output_DisableMarkerData Output = MyClient.DisableMarkerData();</pre>		
MATLAB	<pre>% [Output] = DisableMarkerData()  MyClient = Client(); MyClient.Connect( "localhost" ); Output = MyClient.DisableMarkerData();</pre>		
.NET	<pre>// public class Output_DisableMarkerData // { //     public Result Result; // }; // // Output_DisableMarkerData DisableMarkerData();  ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect( "localhost" ); Output_DisableMarkerData Output = MyClient.DisableMarkerData();</pre>		

## DisableUnlabeledMarkerData

*Disable unlabeled reconstructed marker data in the Vicon DataStream.*

*See also:* [IsUnlabeledMarkerDataEnabled](#), [EnableUnlabeledMarkerData](#), [EnableSegmentData](#), [EnableMarkerData](#), [EnableDeviceData](#), [GetUnlabeledMarkerCount](#), [GetUnlabeledMarkerGlobalTranslation](#)

Input			
Output	Result	Result	Result.NotConnected Result.Success
C++	<pre>// class Output_DisableUnlabeledMarkerData // { //     public: //         Result::Enum Result; //     }; // // Output_DisableUnlabeledMarkerData DisableUnlabeledMarkerData();  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); Output_DisableUnlabeledMarkerData Output =     MyClient.DisableUnlabeledMarkerData();</pre>		
MATLAB	<pre>% [Output] = DisableUnlabeledMarkerData()  MyClient = Client(); MyClient.Connect( "localhost" ); Output = MyClient.DisableUnlabeledMarkerData();</pre>		
.NET	<pre>// public class Output_DisableUnlabeledMarkerData // { //     public Result Result; // }; // // Output_DisableUnlabeledMarkerData DisableUnlabeledMarkerData();  ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect( "localhost" ); Output_DisableUnlabeledMarkerData Output =     MyClient.DisableUnlabeledMarkerData();</pre>		

## DisableDeviceData

*Disable ForcePlate, EMG, and other device data in the Vicon DataStream.*

*See also:* [IsDeviceDataEnabled](#), [EnableDeviceData](#), [EnableSegmentData](#), [EnableMarkerData](#), [EnableUnlabeledMarkerData](#), [GetDeviceCount](#), [GetDeviceName](#), [GetDeviceOutputCount](#), [GetDeviceOutputName](#), [GetDeviceOutputValue](#)

Input			
Output	Result	Result	Result.NotConnected Result.Success
C++	<pre>// class Output_DisableDeviceData // { //     public: //         Result::Enum Result; //     }; // // Output_DisableDeviceData DisableDeviceData();  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); Output_DisableDeviceData Output = MyClient.DisableDeviceData();</pre>		
MATLAB	<pre>% [Output] = DisableDeviceData()  MyClient = Client(); MyClient.Connect( "localhost" ); Output = MyClient.DisableDeviceData();</pre>		
.NET	<pre>// public class Output_DisableDeviceData // { //     public Result Result; // }; // // Output_DisableDeviceData DisableDeviceData();  ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect( "localhost" ); Output_DisableDeviceData Output = MyClient.DisableDeviceData();</pre>		

## IsSegmentDataEnabled

*Return whether kinematic segment data is enabled in the Vicon DataStream.*

*See also:* [EnableSegmentData](#), [DisableSegmentData](#), [IsMarkerDataEnabled](#), [IsUnlabeledMarkerDataEnabled](#), [IsDeviceDataEnabled](#)

Input			
Output	Enabled	boolean	Whether the data is enabled.
C++	<pre>// class Output_IsSegmentDataEnabled // { // public: //     bool Enabled; // }; // Output_IsSegmentDataEnabled IsSegmentDataEnabled() const;  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); Output_IsSegmentDataEnabled Output = MyClient.IsSegmentDataEnabled();  // Output.Enabled == false MyClient.EnableSegmentData(); Output_IsSegmentDataEnabled Output = MyClient.IsSegmentDataEnabled();  // Output.Enabled == true</pre>		
MATLAB	<pre>% [Output] = IsSegmentDataEnabled()  MyClient = Client(); MyClient.Connect( "localhost" ); Output = MyClient.IsSegmentDataEnabled(); % Output.Enabled == false MyClient.EnableSegmentData(); Output = MyClient.IsSegmentDataEnabled(); % Output.Enabled == true</pre>		
.NET	<pre>// public class Output_IsSegmentDataEnabled // { //     public bool Enabled; // }; // Output_IsSegmentDataEnabled IsSegmentDataEnabled();  ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect( "localhost" ); Output_IsSegmentDataEnabled Output = MyClient.IsSegmentDataEnabled();  // Output.Enabled == false MyClient.EnableSegmentData(); Output_IsSegmentDataEnabled Output = MyClient.IsSegmentDataEnabled();  // Output.Enabled == true</pre>		

**IsMarkerDataEnabled**

*Return whether labeled reconstructed marker data is enabled in the DataStream.*

*See also:* EnableMarkerData, DisableMarkerData, IsSegmentDataEnabled, IsUnlabeledMarkerDataEnabled, IsDeviceDataEnabled

<b>Input</b>			
<b>Output</b>	<b>Enabled</b>	<b>boolean</b>	Whether the data is enabled.
<b>C++</b>	<pre>// class Output_IsMarkerDataEnabled // { // public: //     bool Enabled; // }; // // Output_IsMarkerDataEnabled IsMarkerDataEnabled() const;  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); Output_IsMarkerDataEnabled Output = MyClient.IsMarkerDataEnabled(); // Output.Enabled == false MyClient.EnableMarkerData(); Output_IsMarkerDataEnabled Output = MyClient.IsMarkerDataEnabled(); // Output.Enabled == true</pre>		
<b>MATLAB</b>	<pre>% [Output] = IsMarkerDataEnabled()  MyClient = Client(); MyClient.Connect( "localhost" ); Output = MyClient.IsMarkerDataEnabled(); % Output.Enabled == false MyClient.EnableMarkerData(); Output = MyClient.IsMarkerDataEnabled(); % Output.Enabled == true</pre>		
<b>.NET</b>	<pre>// public class Output_IsMarkerDataEnabled // { //     public bool Enabled; // }; // // Output_IsMarkerDataEnabled IsMarkerDataEnabled();  ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect( "localhost" ); Output_IsMarkerDataEnabled Output = MyClient.IsMarkerDataEnabled(); // Output.Enabled == false MyClient.EnableMarkerData(); Output_IsMarkerDataEnabled Output = MyClient.IsMarkerDataEnabled(); // Output.Enabled == true</pre>		

## IsUnlabeledMarkerDataEnabled

*Return whether unlabeled marker data is enabled in the DataStream.*

*See also:* EnableUnlabeledMarkerData, DisableUnlabeledMarkerData, IsSegmentDataEnabled, IsMarkerDataEnabled, IsDeviceDataEnabled

Input			
Output	Enabled	boolean	Whether the data is enabled.
C++	<pre>// class Output_IsUnlabeledMarkerDataEnabled // { // public: //     bool Enabled; // }; // Output_IsUnlabeledMarkerDataEnabled //         IsUnlabeledMarkerDataEnabled() const;  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); Output_IsUnlabeledMarkerDataEnabled Output =     MyClient.IsUnlabeledMarkerDataEnabled(); // Output.Enabled == false MyClient.EnableUnlabeledMarkerData(); Output_IsUnlabeledMarkerDataEnabled Output =     MyClient.IsUnlabeledMarkerDataEnabled(); // Output.Enabled == true</pre>		
MATLAB	<pre>% [Output] = IsUnlabeledMarkerDataEnabled()  MyClient = Client(); MyClient.Connect( "localhost" ); Output = MyClient.IsUnlabeledMarkerDataEnabled(); % Output.Enabled == false MyClient.EnableUnlabeledMarkerData(); Output = MyClient.IsUnlabeledMarkerDataEnabled(); % Output.Enabled == true</pre>		
.NET	<pre>// public class Output_IsUnlabeledMarkerDataEnabled // { //     public bool Enabled; // }; // Output_IsUnlabeledMarkerDataEnabled IsUnlabeledMarkerDataEnabled();  ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect( "localhost" ); Output_IsUnlabeledMarkerDataEnabled Output =     MyClient.IsMarkerDataEnabled(); // Output.Enabled == false MyClient.EnableUnlabeledMarkerData(); Output_IsUnlabeledMarkerDataEnabled Output =     MyClient.IsUnlabeledMarkerDataEnabled(); // Output.Enabled == true</pre>		

## IsDeviceDataEnabled

*Return whether ForcePlate, EMG, and other device data is enabled in the data stream.*

*See also:* EnableDeviceData, DisableDeviceData, IsSegmentDataEnabled, IsMarkerDataEnabled, IsUnlabeledMarkerDataEnabled

Input			
Output	Enabled	boolean	Whether the data is enabled.
C++	<pre>// class Output_IsDeviceDataEnabled // { // public: //     bool Enabled; // }; // // Output_IsDeviceDataEnabled IsDeviceDataEnabled() const;  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); Output_IsDeviceDataEnabled Output = MyClient.IsDeviceDataEnabled(); // Output.Enabled == false MyClient.EnableDeviceData(); Output_IsDeviceDataEnabled Output = MyClient.IsDeviceDataEnabled(); // Output.Enabled == true</pre>		
MATLAB	<pre>% [Output] = IsDeviceDataEnabled()  MyClient = Client(); MyClient.Connect( "localhost" ); Output = MyClient.IsDeviceDataEnabled(); % Output.Enabled == false MyClient.EnableDeviceData(); Output = MyClient.IsDeviceDataEnabled(); % Output.Enabled == true</pre>		
.NET	<pre>// public class Output_IsDeviceDataEnabled // { //     public bool Enabled; // }; // // Output_IsDeviceDataEnabled IsDeviceDataEnabled();  ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect( "localhost" ); Output_IsDeviceDataEnabled Output = MyClient.IsDeviceDataEnabled(); // Output.Enabled == false MyClient.EnableDeviceData(); Output_IsDeviceDataEnabled Output = MyClient.IsDeviceDataEnabled(); // Output.Enabled == true</pre>		

## SetStreamMode

*There are three modes that the SDK can operate in. Each mode has a different impact on the Client, Server, and network resources used.*

- In "ServerPush" mode, the Server pushes every new frame of data over the network to the Client. The Server will try not to drop any frames. This results in the lowest latency we can achieve. If the Client is unable to read data at the rate it is being sent, then it is buffered, firstly in the Client, then on the TCP/IP connection, and then at the Server. Once all buffers have filled up then frames may be dropped at the Server and the performance of the Server may be affected.
- In "ClientPull" mode, the Client waits for a call to `GetFrame()`, and then request the latest frame of data from the Server. This increases latency, because we need to send a request over the network to the Server, the Server has to prepare the frame of data for the Client, and then we need to send the data back over the network. Network bandwidth is kept to a minimum, because the Server only sends what you need. We are very unlikely to fill up our buffers, and Server performance is unlikely to be affected. The `GetFrame()` method blocks the calling thread until the frame has been received.
- "ClientPullPreFetch" is an enhancement to "ClientPull" mode. A thread in the SDK continuously and preemptively does a "ClientPull" on your behalf, storing the latest requested frame in memory. When you next call `GetFrame()`, the SDK returns the last requested frame which we had cached in memory. `GetFrame()` does not need to block the calling thread. As with normal "ClientPull", buffers are unlikely to fill up, Server performance is unlikely to be affected. Latency is slightly reduced, but network traffic may increase if we request frames on behalf of the Client which are never used.

*The stream defaults to "ClientPull" mode as this is considered the safest option. If performance is a problem, then try "ClientPullPreFetch" followed by "ServerPush".*

*See also:* [GetFrame](#), [GetLatencyTotal](#)

Input	Mode	StreamMode	<code>StreamMode.ServerPush</code> <code>StreamMode.ClientPull</code> <code>StreamMode.ClientPullPreFetch</code>
Output	Result	Result	<code>Result.Success</code> <code>Result.NotConnected</code>
C++	<pre>// class Output_SetStreamMode // { // public: //     Result::Enum Result; // }; // // Output_SetStreamMode SetStreamMode( const StreamMode::Enum Mode );  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); MyClient.SetStreamMode( ViconDataStreamSDK::CPP::StreamMode::ServerPush ); MyClient.SetStreamMode( ViconDataStreamSDK::CPP::StreamMode::ClientPull ); MyClient.SetStreamMode( ViconDataStreamSDK::CPP::StreamMode::ClientPullPreFetch );</pre>		
MATLAB	<pre>% [Output] = SetStreamMode( Mode );  MyClient = Client(); MyClient.Connect( 'localhost' ); MyClient.SetStreamMode( StreamMode.ServerPush ); MyClient.SetStreamMode( StreamMode.ClientPull ); MyClient.SetStreamMode( StreamMode.ClientPullPreFetch );</pre>		
.NET	<pre>// class Output_SetStreamMode // { // public Result Result; // }; // // Output_SetStreamMode SetStreamMode( StreamMode Mode );</pre>		

```
ViconDataStreamSDK.DotNET.Client MyClient =  
    new ViconDataStreamSDK.DotNET.Client();  
MyClient.Connect( "localhost" );  
MyClient.SetStreamMode( ViconDataStreamSDK.DotNET.StreamMode.ServerPush );  
MyClient.SetStreamMode( ViconDataStreamSDK.DotNET.StreamMode.ClientPull );  
MyClient.SetStreamMode( ViconDataStreamSDK.DotNET.StreamMode.  
    ClientPullPreFetch );
```

## SetApexDeviceFeedback

*Turn haptic feedback on or off for requested Apex device.*

*When you turn the Apex device feedback on, the buzzer will vibrate until it is turned off. If there are multiple clients that have different settings for whether an Apex device feedback is on or off, the Apex feedback will be on as long as it is turned on in at least one of the clients.*

Input	DeviceName	Apex device name
	On	Boolean activates the haptic feedback.
Output	Result	<p><b>Result</b></p> <p>Result.Success Result.NotConnected Result.NoFrame Result.InvalidDeviceName Result.HapticAlreadySet</p>
C++	<pre>// class Output_SetApexDeviceFeedback // { // public: //   Result::Enum Result; // }; // // Output_SetApexDeviceFeedback SetApexDeviceFeedback //                               ( const String&amp; i_rDeviceName, bool i_bOn )  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); MyClient.EnableDeviceData(); MyClient.GetFrame();  MyClient.EnableDeviceData(); MyClient.GetFrame();  MyClient.SetApexDeviceHapticFeedback( "ViconAP_001", true );</pre>	
MATLAB	<pre>% [Output] = SetApexDeviceFeedback( DeviceName, bOn )  MyClient = Client(); MyClient.Connect( "localhost" ); MyClient.EnableDeviceData(); MyClient.GetFrame();  MyClient.SetApexDeviceFeedback ( "ViconAP_001", 1 );</pre>	
.NET	<pre>// public class Output_SetApexDeviceFeedback // { // public Result Result; // }; // // Output_SetApexDeviceDevice SetApexDeviceFeedback //                           ( String^ DeviceName, bool bOn ) ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect("localhost"); MyClient.EnableDeviceData(); MyClient.GetFrame(); MyClient.SeApexDeviceFeedback( "ViconAP_001", true );</pre>	

## SetAxisMapping

*Remaps the 3D axis.*

Vicon Data uses a right handed co-ordinate system, with +X forward, +Y left, and +Z up. Other systems use different co-ordinate systems. The SDK can transform its data into any valid right-handed co-ordinate system by re-mapping each axis.

Specify the direction of your X, Y, and Z axis relative to yourself as the observer. Valid directions are "Up", "Down", "Left", "Right", "Forward", and "Backward". Note that "Forward" means moving away from you, and "Backward" is moving towards you.

Common usages are

- Z-up : SetAxisMapping( Forward, Left, Up )
- Y-up : SetAxisMapping( Forward, Up, Right )

See also: GetAxisMapping

Input	XAxis	Direction
	YAxis	Direction
	ZAxis	Direction
Output	Result	<p>Result.Success            Result.CoLinearAxes            Result.LeftHandedAxes</p>
C++	<pre>// class Output_SetAxisMapping // { // public: //   Result::Enum Result; // }; // // Output_SetAxisMapping SetAxisMapping( const Direction::Enum XAxis, //                                     const Direction::Enum YAxis, //                                     const Direction::Enum ZAxis ) ViconDataStreamSDK::CPP::Client MyClient; MyClient.SetAxisMapping( ViconDataStreamSDK::CPP::Direction::Forward,                         ViconDataStreamSDK::CPP::Direction::Left,                         ViconDataStreamSDK::CPP::Direction::Up );</pre>	
MATLAB	<pre>% [Output] = SetAxisMapping( XAxis, %                           YAxis, %                           ZAxis ) MyClient = Client(); MyClient.SetAxisMapping( Direction.Forward, ...                         Direction.Left, ...                         Direction.Up );</pre>	
.NET	<pre>// public class Output_SetAxisMapping // { // public Result Result; // }; // // Output_SetAxisMapping SetAxisMapping( Direction XAxis, //                                     Direction YAxis, //                                     Direction ZAxis ); ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); MyClient.SetAxisMapping( ViconDataStreamSDK.DotNET.Direction.Forward,                         ViconDataStreamSDK.DotNET.Direction.Left,                         ViconDataStreamSDK.DotNET.Direction.Up );</pre>	

## GetAxisMapping

*Get the current Axis mapping.*

*See also:* SetAxisMapping

<b>Input</b>			
<b>Output</b>	XAxis	Direction	
	YAxis	Direction	
	ZAxis	Direction	
<b>C++</b>	<pre>// class Output_GetAxisMapping // { // public: //     Direction::Enum XAxis; //     Direction::Enum YAxis; //     Direction::Enum ZAxis; // }; // // Output_GetAxisMapping GetAxisMapping() const;  ViconDataStreamSDK::CPP::Client MyClient; Output_GetAxisMapping Output = MyClient.GetAxisMapping(); // Output.XAxis == ViconDataStreamSDK::CPP::Direction::Forward // Output.YAxis == ViconDataStreamSDK::CPP::Direction::Left // Output.ZAxis == ViconDataStreamSDK::CPP::Direction::Up</pre>		
<b>MATLAB</b>	<pre>% [Output] = GetAxisMapping()  MyClient = Client(); Output = MyClient.GetAxisMapping(); % Output.XAxis == Direction.Forward % Output.YAxis == Direction.Left % Output.ZAxis == Direction.Up</pre>		
<b>.NET</b>	<pre>// public class Output_GetAxisMapping // { //     public Direction XAxis; //     public Direction YAxis; //     public Direction ZAxis; // }; // // Output_GetAxisMapping GetAxisMapping();  ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); Output_GetAxisMapping Output = MyClient.GetAxisMapping(); // Output.XAxis == ViconDataStreamSDK.DotNET.Direction.Forward // Output.YAxis == ViconDataStreamSDK.DotNET.Direction.Left // Output.ZAxis == ViconDataStreamSDK.DotNET.Direction.Up</pre>		

## GetFrame

*Request a new frame to be fetched from the Vicon DataStream Server.*

*See also:* SetStreamMode

Input			
Output	Result	Result	Result.Success Result.NotConnected
C++	// class Output_GetFrame // { // public: //     Result::Enum Result; // }; // // Output_GetFrame GetFrame();  ViconDataStreamSDK::CPP::Client MyClient; Output_GetFrame Output; Output = MyClient.GetFrame(); // Output.Result == NotConnected MyClient.Connect( "localhost" ); Output = MyClient.GetFrame(); // Output.Result == Success		
MATLAB	% [Output] = GetFrame()  MyClient = Client(); Output = MyClient.GetFrame(); // Output.Result == NotConnected MyClient.Connect( "localhost" ); Output = MyClient.GetFrame(); // Output.Result == Success		
.NET	// public class Output_GetFrame // { // public Result Result; // }; // // Output_GetFrame GetFrame();  ViconDataStreamSDK.DotNET.Client MyClient = new ViconDataStreamSDK.DotNET.Client(); Output_GetFrame Output; Output = MyClient.GetFrame(); // Output.Result == NotConnected MyClient.Connect( "localhost" ); Output = MyClient.GetFrame(); // Output.Result == Success		

## GetFrameNumber

*Return the number of the last frame retrieved from the DataStream.*

*See also:* GetFrame, GetTimecode

Input			
Output	Result	Result	<code>Result.Success</code> <code>Result.NotConnected</code> <code>Result.NoFrame</code>
	Frame Number	unsigned integer	The frame number
C++	<pre>// class Output_GetFrameNumber // { //     public: //         Result::Enum Result; //         unsigned int FrameNumber; //     }; // // Output_GetFrameNumber GetFrameNumber() const; ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); Output_GetFrameNumber Output; Output = MyClient.GetFrameNumber(); // Output.Result == NoFrame                                     // Output.FrameNumber == 0 MyClient.GetFrame(); Output = MyClient.GetFrameNumber(); // Output.Result == Success                                     // Output.FrameNumber &gt;= 1</pre>		
MATLAB	<pre>% [Output] = GetFrameNumber()  MyClient = Client(); MyClient.Connect( "localhost" ); Output = MyClient.GetFrameNumber(); % Output.Result == NoFrame                                     % Output.FrameNumber == 0 MyClient.GetFrame(); Output = MyClient.GetFrameNumber(); % Output.Result == Success                                     % Output.FrameNumber &gt;= 1</pre>		
.NET	<pre>// class Output_GetFrameNumber // { //     public Result Result; //     public uint    FrameNumber; // }; // // Output_GetFrameNumber GetFrameNumber();  ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect( "localhost" ); Output_GetFrameNumber Output; Output = MyClient.GetFrameNumber(); // Output.Result == NoFrame                                     // Output.FrameNumber == 0 MyClient.GetFrame(); Output = MyClient.GetFrameNumber(); // Output.Result == Success                                     // Output.FrameNumber &gt;= 1</pre>		

## GetLatencyTotal

*Return the total latency in seconds introduced at various stages of the real-time pipeline. If no latency information is available then all latencies will be reported as 0.0.*

*See also:* [GetFrame](#), [GetTimecode](#), [GetLatencySampleCount](#), [GetLatencySampleName](#), [GetLatencySampleValue](#)

<b>Input</b>			
<b>Output</b>	<b>Result</b>	<b>Result</b>	<code>Result.Success</code> <code>Result.NotConnected</code> <code>Result.NoFrame</code>
	<b>Total</b>	<b>double</b>	The total latency in seconds made from summing the other latencies.
<b>C++</b>	<pre>// class Output_GetLatencyTotal // { //     public: //         Result::Enum Result; //         double        Total; //     }; // // Output_GetLatencyTotal GetLatencyTotal() const;  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); MyClient.GetFrame(); Output_GetLatencyTotal Output = MyClient.GetLatencyTotal();</pre>		
<b>MATLAB</b>	<pre>% [Output] = GetLatencyTotal()  MyClient = Client(); MyClient.Connect( 'localhost' ); MyClient.GetFrame(); Output = MyClient.GetLatencyTotal();</pre>		
<b>.NET</b>	<pre>// class Output_GetLatencyTotal // { //     public Result Result; //     public double Total; // }; // // Output_GetLatencyTotal GetLatencyTotal();  ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect( "localhost" ); MyClient.GetFrame(); Output_GetLatencyTotal Output = MyClient.GetLatencyTotal();</pre>		

**GetLatencySampleCount**

*Return the number of latency measurements that were taken at various stages of the real-time pipeline. This value can be passed into GetLatencySampleName().*

*See also:* [GetFrame](#), [GetTimecode](#), [GetLatencyTotal](#), [GetLatencySampleName](#), [GetLatencySampleValue](#)

<b>Input</b>			
<b>Output</b>	<b>Result</b>	<b>Result</b>	<code>Result.Success</code> <code>Result.NotConnected</code> <code>Result.NoFrame</code>
	<b>Count</b>	<code>unsigned int</code>	The number of samples taken.
<b>C++</b>	<pre>// class Output_GetLatencySampleCount // { //     public: //         Result::Enum Result; //         unsigned int Count; //     }; // // Output_GetLatencySampleCount GetLatencySampleCount() const;  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); MyClient.GetFrame(); Output_GetLatencySampleCount Output = MyClient.GetLatencySampleCount();</pre>		
<b>MATLAB</b>	<pre>% [Output] = GetLatencySampleCount()  MyClient = Client(); MyClient.Connect( 'localhost' ); MyClient.GetFrame(); Output = MyClient.GetLatencySampleCount();</pre>		
<b>.NET</b>	<pre>// class Output_GetLatencySampleCount // { //     public Result Result; //     public uint Count; // }; // // Output_GetLatencySampleCount GetLatencySampleCount();  ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect( "localhost" ); MyClient.GetFrame(); Output_GetLatencySampleCount Output =     MyClient.GetLatencySampleCount();</pre>		

**GetLatencySampleName**

*Return the name of a latency sample. This value can be passed into GetLatencySampleValue().*

*See also:* [GetFrame](#), [GetTimecode](#), [GetLatencyTotal](#), [GetLatencySampleCount](#), [GetLatencySampleValue](#)

Input	LatencySampleIndex	Unsigned int	The index of the name.
Output	Result	Result	Result.Success Result.NotConnected Result.NoFrame Result.InvalidIndex
	Name	string	The name of the latency sample.
C++	<b>A valid Latency Sample Index is between 0 and GetLatencySampleCount()-1</b> <pre>// class Output_GetLatencySampleName // { //   public: //     Result::Enum Result; //     String      Name; // }; // // Output_GetLatencySampleName //   GetLatencySampleName( const unsigned int LatencySampleIndex ) const;  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost" ); MyClient.GetFrame(); Output_GetLatencySampleName Output = MyClient.GetLatencySampleName( 0 ); // Output.Name == "Data Collected"</pre>		
MATLAB	<b>A valid Latency Sample Index is between 1 and GetLatencySampleCount()</b> <pre>% [Output] = GetLatencySampleName()  MyClient = Client(); MyClient.Connect('localhost' ); MyClient.GetFrame(); Output = MyClient.GetLatencySampleName( 1 ); % Output.Name == 'Data Collected'</pre>		
.NET	<b>A valid Latency Sample Index is between 0 and GetLatencySampleCount() -1</b> <pre>// class Output_GetLatencySampleName // { //   public Result Result; //   public string Name; // }; // // Output_GetLatencySampleName //   GetLatencySampleName( uint LatencySampleIndex );  ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect("localhost" ); MyClient.GetFrame(); Output_GetLatencySampleName Output = MyClient.GetLatencySampleName( 0 ); // Output.Name == "Data Collected"</pre>		

**GetLatencySampleValue**

*Return the duration of a named latency sample in seconds. This value can be passed into GetLatencySampleValue().*

*See also:* [GetFrame](#), [GetTimecode](#), [GetLatencyTotal](#), [GetLatencySampleCount](#), [GetLatencySampleValue](#)

Input	LatencySampleName	string	The name of the latency sample.
Output	Result	Result	Result.Success Result.NotConnected Result.NoFrame Result.InvalidLatencySampleName
	Value	double	The duration of the latency in seconds.
C++	<pre>// class Output_GetLatencySampleValue // { //     public: //         Result::Enum Result; //         double      Value; //     }; // // Output_GetLatencySampleValue //     GetLatencySampleValue( const String &amp; LatencySampleName ) const;  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); MyClient.GetFrame(); Output_GetLatencySampleValue Output =     MyClient.GetLatencySampleValue( "Data Collected" ); // Output.Value == 0.1</pre>		
MATLAB	<pre>% [Output] = GetLatencySampleValue()  MyClient = Client(); MyClient.Connect( 'localhost' ); MyClient.GetFrame(); Output = MyClient.GetLatencySampleValue( 'Data Collected' ); % Output.Value == 0.1</pre>		
.NET	<pre>// class Output_GetLatencySampleValue // { //     public Result Result; //     public double Value; // }; // // Output_GetLatencySampleValue //     GetLatencySampleValue( string LatencySampleName ); ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect( "localhost" ); MyClient.GetFrame(); Output_GetLatencySampleName Output =     MyClient.GetLatencySampleValue( "Data Collected" ); // Output.Value == 0.1</pre>		

## GetTimecode

*Return the timecode information for the last frame retrieved from the DataStream. If the stream is valid but timecode is not available the Output will be Result.Success and the Standard will be None.*

See also: [GetFrame](#), [GetFrameNumber](#)

Input			
Output	Result	Result	Result.Success Result.NotConnected Result.NoFrame
	Hours	Unsigned integer	
	Minutes	Unsigned integer	
	Seconds	Unsigned integer	
	Frames	Unsigned integer	
	SubFrame	Unsigned integer	
	FieldFlag	Boolean	
	Standard	TimecodeStandard	None PAL NTSC NTSCDrop Film
	SubFramesPerFrame	Unsigned integer	
	UserBits	Unsigned integer	
C++	<pre>// class Output_GetTimecode // { // public: //   Result::Enum      Result; //   unsigned int      Hours; //   unsigned int      Minutes; //   unsigned int      Seconds; //   unsigned int      Frames; //   unsigned int      SubFrame; //   bool              FieldFlag; //   TimecodeStandard::Enum Standard; //   unsigned int      SubFramesPerFrame; //   unsigned int      UserBits; // }; // // Output_GetTimecode GetTimecode() const;  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); MyClient.GetFrame(); Output_GetTimecode Output = MyClient.GetTimecode();</pre>		
MATLAB	<pre>% [Output] = GetTimecode()  MyClient = Client(); MyClient.Connect( "localhost" ); MyClient.GetFrame(); Output = MyClient.GetTimecode();</pre>		

**.NET**

```
// class Output_GetTimecode
// {
//     public Result           Result;
//     public uint              Hours;
//     public uint              Minutes;
//     public uint              Seconds;
//     public uint              Frames;
//     public uint              SubFrame;
//     public bool              FieldFlag;
//     public TimecodeStandard Standard;
//     public uint              SubFramesPerFrame;
//     public uint              UserBits;
// };
//
// Output_GetTimecode GetTimecode();

ViconDataStreamSDK.DotNET.Client MyClient =
    new ViconDataStreamSDK.DotNET.Client();
MyClient.Connect( "localhost" );
MyClient.GetFrame();
Output_GetTimecode Output = MyClient.GetTimecode();
```

## GetFrameRate

*Return the Vicon camera system frame rate (in Hz) at the time of the last frame retrieved from the DataStream.*

*See also:* [GetFrame](#), [GetFrameNumber](#), [GetTimecode](#)

Input			
Output	Result	Result	Result.Success Result.NotConnected Result.NoFrame
	FrameRateHz	double	
C++	<pre>// class Output_GetFrameRate // { // public: //     Result::Enum          Result; //     double                FrameRateHz; // }; // // Output_GetFrameRate GetFrameRate() const;  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); MyClient.GetFrame(); Output_GetFrameRate Output = MyClient.GetFrameRate();</pre>		
MATLAB	<pre>% [Output] = GetFrameRate()  MyClient = Client(); MyClient.Connect( "localhost" ); MyClient.GetFrame(); Output = MyClient.GetFrameRate();</pre>		
.NET	<pre>// class Output_GetFrameRate // { //     public Result          Result; //     public double          FrameRateHz; // }; // // Output_GetFrameRate GetFrameRate();  ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect( "localhost" ); MyClient.GetFrame(); Output_GetFrameRate Output = MyClient.GetFrameRate();</pre>		

## GetSubjectCount

*Return the number of subjects in the DataStream. This information can be used in conjunction with GetSubjectName*

*See also:* GetSubjectName

<b>Input</b>			
<b>Output</b>	<b>Result</b>	<b>Result</b>	<code>Result.Success</code> <code>Result.NotConnected</code> <code>Result.NoFrame</code>
	<b>Subject Count</b>	<b>unsigned integer</b>	<b>The number of subjects</b>
<b>C++</b>			
<pre>// class Output_GetSubjectCount // { // public: //   Result::Enum Result; //   unsigned int SubjectCount; // }; // // Output_GetSubjectCount GetSubjectCount() const;  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); Output_GetSubjectCount Output; Output = MyClient.GetSubjectCount(); // Output.Result == NoFrame // Output.SubjectCount == 0 MyClient.GetFrame(); Output = MyClient.GetSubjectCount(); // Output.Result == Success // Output.SubjectCount &gt;= 0</pre>			
<b>MATLAB</b>			
<pre>% [Output] = GetSubjectCount()  MyClient = Client(); MyClient.Connect( 'localhost' ); Output = MyClient.GetSubjectCount(); % Output.Result == NoFrame % Output.SubjectCount == 0 MyClient.GetFrame(); Output = MyClient.GetSubjectCount(); % Output.Result == Success % Output.SubjectCount &gt;= 0</pre>			
<b>.NET</b>			
<pre>// class Output_GetSubjectCount // { //   public Result Result; //   public uint SubjectCount; // }; // Output_GetSubjectCount GetSubjectCount(); // // Output_GetSubjectCount GetSubjectCount() // // ViconDataStreamSDK.DotNET.Client MyClient = //   new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect( "localhost" ); Output_GetSubjectCount Output; Output = MyClient.GetSubjectCount(); // Output.Result == NoFrame // Output.SubjectCount == 0 MyClient.GetFrame(); Output = MyClient.GetSubjectCount(); // Output.Result == Success // Output.SubjectCount &gt;= 0</pre>			

## GetSubjectName

*Return the name of a subject. This can be passed into segment and marker functions.*

*See also:* [GetSubjectCount](#)

Input	Subject Index	unsigned integer	The index of the subject.
Output	Result	Result	Result.Success Result.NotConnected Result.NoFrame Result.InvalidIndex
	Subject Name	string	The name of the subject
C++	<p>A valid Subject Index is between 0 and GetSubjectCount()-1</p> <pre>// class Output_GetSubjectName // { // public: //   Result::Enum Result; //   String      SubjectName; // }; // // Output_GetSubjectName GetSubjectName( //   const unsigned int SubjectIndex ) const;  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output_GetSubjectCount OutputGSC; OutputGSC = MyClient.GetSubjectCount(); // OutputGSC.Result == Success  // OutputGSC.SubjectCount == 2  Output_GetSubjectName OutputGSN; OutputGSN = MyClient.GetSubjectName(0); // OutputGSN.Result == Success  // OutputGSN.SubjectName == "A1" OutputGSN = MyClient.GetSubjectName(1); // OutputGSN.Result == Success  // OutputGSN.SubjectName == "Bob" OutputGSN = MyClient.GetSubjectName(2); // OutputGSN.Result == InvalidIndex  // OutputGSN.SubjectName == ""  </pre>		
MATLAB	<p>A valid Subject Index is between 1 and GetSubjectCount()</p> <pre>% [Output] = GetSubjectName( SubjectIndex )  MyClient = Client; MyClient.Connect( 'localhost' ); MyClient.GetFrame();  OutputGSC = MyClient.GetSubjectCount(); % OutputGSC.Result == Success  % OutputGSC.SubjectCount == 2  OutputGSN = MyClient.GetSubjectName(1); % OutputGSN.Result == Success  % OutputGSN.SubjectName == 'A1' OutputGSN = MyClient.GetSubjectName(2); % OutputGSN.Result == Success  % OutputGSN.SubjectName == 'Bob' OutputGSN = MyClient.GetSubjectName(3); % OutputGSN.Result == InvalidIndex  % OutputGSN.SubjectName == ''  </pre>		
.NET	<p>A valid Subject Index is between 0 and GetSubjectCount()-1</p> <pre>// public class Output_GetSubjectName // { //   public Result Result; //   public string SubjectName; // };  </pre>		

```
//  
// Output_GetSubjectName GetSubjectName( uint SubjectIndex );  
  
ViconDataStreamSDK.DotNET.Client MyClient =  
    new ViconDataStreamSDK.DotNET.Client();  
MyClient.Connect( "localhost" );  
MyClient.GetFrame();  
  
Output_GetSubjectCount OutputGSC;  
OutputGSC = MyClient.GetSubjectCount(); // OutputGSC.Result == Success  
// OutputGSC.SubjectCount == 2  
  
Output_GetSubjectName OutputGSN;  
OutputGSN = MyClient.GetSubjectName(0); // OutputGSN.Result == Success  
// OutputGSN.SubjectName == "Al"  
OutputGSN = MyClient.GetSubjectName(1); // OutputGSN.Result == Success  
// OutputGSN .SubjectName == "Bob"  
OutputGSN = MyClient.GetSubjectName(2); // OutputGSN.Result == InvalidIndex  
// OutputGSN.SubjectName == ""
```

## GetSubjectRootSegmentName

*Return the name of the root segment for a specified subject. This can be passed into segment functions. The root segment is the ancestor of all other segments in the subject.*

*See also:* [GetSegmentCount](#), [GetSegmentParentName](#), [GetSegmentChildCount](#), [GetSegmentChildName](#)

Input	Subject Name	string	The name of the subject
Output	Result	Result	Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName
	Segment Name	string	The name of the root segment
C++	<pre>// class Output_GetSubjectRootSegmentName // { // public: //     Result::Enum Result; //     String      SegmentName; // }; // // Output_GetSubjectRootSegmentName GetSubjectRootSegmentName( //     const String &amp; SubjectName ) const  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost" ); MyClient.EnableSegmentData(); MyClient.GetFrame();  Output_GetSubjectRootSegmentName Output; Output = MyClient.GetSubjectRootSegmentName("Bob" ); // Output.Result == Success // Output.SegmentName == "Pelvis"</pre>		
MATLAB	<pre>% [Output] = GetSubjectRootSegmentName( SubjectName )  MyClient = Client(); MyClient.Connect("localhost" ); MyClient.EnableSegmentData(); MyClient.GetFrame();  Output = MyClient.GetSubjectRootSegmentName("Bob" ); % Output.Result == Success % Output.SegmentName == "Pelvis"</pre>		
.NET	<pre>// public class Output_GetSubjectRootSegmentName // { //     public Result Result; //     public string SegmentName; // }; // // Output_GetSubjectRootSegmentName GetSubjectRootSegmentName( //     string SubjectName );  ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect("localhost" ); MyClient.EnableSegmentData(); MyClient.GetFrame();  Output_GetSubjectRootSegmentName Output; Output = MyClient.GetSubjectRootSegmentName("Bob" ); // Output.Result == Success // Output.SegmentName == "Pelvis"</pre>		

## GetSegmentCount

*Return the number of segments for a specified subject in the DataStream. This information can be used in conjunction with GetSegmentName*

*See also:* [GetSubjectName](#), [GetSegmentName](#)

Input	Subject Name	string	The name of the subject
Output	Result	Result	Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName
	Segment Count	unsigned integer	The number of segments
C++	<pre>// class Output_GetSegmentCount //{ // public: //     Result::Enum Result; //     unsigned int SegmentCount; // }; // // Output_GetSegmentCount GetSegmentCount( //     const String &amp; SubjectName ) const;  ViconDataStreamSDK::CPP::Client MyClient; MyClient.EnableSegmentData(); MyClient.Connect( "localhost" );  Output_GetSegmentCount Output; Output = MyClient.GetSegmentCount( "Bob" ); // Output.Result == NoFrame   // Output.SegmentCount == 0 MyClient.GetFrame();  Output = MyClient.GetSegmentCount( "Al" ); // Output.Result ==   // InvalidSubjectName   // Output.SegmentCount == 0  Output = MyClient.GetSegmentCount( "Bob" ); // Output.Result == Success   // Output.SegmentCount &gt;= 0</pre>		
MATLAB	<pre>% [Output] = GetSegmentCount( SubjectName )  MyClient = Client(); MyClient.EnableSegmentData(); MyClient.Connect( "localhost" );  Output = MyClient.GetSegmentCount( "Bob" ); % Output.Result == NoFrame   % Output.SegmentCount == 0 MyClient.GetFrame();  Output = MyClient.GetSegmentCount( "Al" ); % Output.Result ==   % InvalidSubjectName   % Output.SegmentCount == 0  Output = MyClient.GetSegmentCount( "Bob" ); % Output.Result == Success   % Output.SegmentCount &gt;= 0</pre>		
.NET	<pre>// public class Output_GetSegmentCount //{ //     public Result Result; //     public uint SegmentCount; // }; // // Output_GetSegmentCount GetSegmentCount( string SubjectName );  ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client();</pre>		

```
MyClient.EnableSegmentData();
MyClient.Connect( "localhost" );

Output_GetSegmentCount Output;
Output = MyClient.GetSegmentCount( "Bob" ); // Output.Result == NoFrame
                                              // Output.SegmentCount == 0
MyClient.GetFrame();

Output = MyClient.GetSegmentCount( "Al" ); // Output.Result ==
                                              // InvalidSubjectName
                                              // Output.SegmentCount == 0

Output = MyClient.GetSegmentCount( "Bob" ); // Output.Result == Success
                                              // Output.SegmentCount >= 0
```

## GetSegmentName

*Return the name of a segment for a specified subject. This can be passed into segment functions.*

*See also:* GetSegmentCount

<b>Input</b>  <b>Output</b>	<b>Subject Name</b>  <b>Result</b>	<b>string</b>  <b>Result</b>	<b>The name of the subject</b>  <b>Result.Success</b> <b>Result.NotConnected</b> <b>Result.NoFrame</b> <b>Result.InvalidSubjectName</b> <b>Result.InvalidIndex</b>
	<b>Segment Index</b>	<b>unsigned integer</b>	<b>The index of the segment.</b>
	<b>Segment Name</b>	<b>string</b>	<b>The name of the segment</b>
<b>C++</b>	<b>A valid Segment Index is between 0 and GetSegmentCount()-1</b> <pre>// class Output_GetSegmentName //{ // public: //     Result::Enum Result; //     String      SegmentName; // }; // // Output_GetSegmentName GetSegmentName( //     const String      &amp; SubjectName, //     const unsigned int SegmentIndex ) const  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); MyClient.EnableSegmentData(); MyClient.GetFrame();  Output_GetSegmentCount OutputGSC; OutputGSC = MyClient.GetSegmentCount( "Bob" ); // OutputGSC.Result == Success // OutputGSC.SegmentCount == 2  Output_GetSegmentName OutputGSN; OutputGSN = MyClient.GetSegmentName( "Alice", 0 ); // OutputGSN.Result == InvalidSubjectName // OutputGSN.SegmentName == ""  OutputGSN = MyClient.GetSegmentName( "Bob", 0 ); // OutputGSN.Result == Success // OutputGSN.SegmentName == "Head" OutputGSN = MyClient.GetSegmentName( "Bob", 1 ); // OutputGSN.Result == Success // OutputGSN.SegmentName == "Pelvis" OutputGSN = MyClient.GetSegmentName( "Bob", 2 ); // OutputGSN.Result == InvalidIndex // OutputGSN.SegmentName == "" // (no third segment)</pre>		
<b>MATLAB</b>	<b>A valid Segment Index is between 1 and GetSegmentCount()</b> <pre>% [Output] = GetSegmentName( SubjectName, SegmentIndex )  MyClient = Client(); MyClient.Connect( "localhost" ); MyClient.EnableSegmentData(); MyClient.GetFrame();  OutputGSC = MyClient.GetSegmentCount( "Bob" ); % OutputGSC.Result == Success % OutputGSC.SegmentCount == 2</pre>		

	<pre> OutputGSN = MyClient.GetSegmentName( "Alice", 1 );     % OutputGSN.Result == InvalidSubjectName     % OutputGSN.SegmentName == ""  OutputGSN = MyClient.GetSegmentName( "Bob", 1 );     % OutputGSN.Result == Success     % OutputGSN.SegmentName == "Head" OutputGSN = MyClient.GetSegmentName( "Bob", 2 );     % OutputGSN.Result == Success     % OutputGSN.SegmentName == "Pelvis" OutputGSN = MyClient.GetSegmentName( "Bob", 3 );     % OutputGSN.Result == InvalidIndex     % OutputGSN.SegmentName == ""     % (no third segment) </pre>
.NET	<p><b>A valid Segment Index is between 0 and GetSegmentCount()-1</b></p> <pre> // public class Output_GetSegmentName // { //     public Result Result; //     public string SegmentName; // } // // Output_GetSegmentName GetSegmentName( string SubjectName, //   uint    SegmentIndex );  ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect( "localhost" ); MyClient.EnableSegmentData(); MyClient.GetFrame();  Output_GetSegmentCount OutputGSC; OutputGSC = MyClient.GetSegmentCount( "Bob" );     // OutputGSC.Result == Success     // OutputGSC.SegmentCount == 2  Output_GetSegmentName OutputGSN; OutputGSN = MyClient.GetSegmentName( "Alice", 0 );     // OutputGSN.Result == InvalidSubjectName     // OutputGSN.SegmentName == ""  OutputGSN = MyClient.GetSegmentName( "Bob", 0 );     // OutputGSN.Result == Success     // OutputGSN.SegmentName == "Head" OutputGSN = MyClient.GetSegmentName( "Bob", 1 );     // OutputGSN.Result == Success     // OutputGSN.SegmentName == "Pelvis" OutputGSN = MyClient.GetSegmentName( "Bob", 2 );     // OutputGSN.Result == InvalidIndex     // OutputGSN.SegmentName == ""     // (no third segment) </pre>

## GetSegmentParentName

*Return the name of the parent segment for a specified subject segment. If the specified segment is the root segment of the subject then it will return an empty string.*

*See also:* GetSegmentCount, GetSegmentChildCount, GetSegmentChildName, GetSubjectRootSegmentName

Input	Subject Name	string	The name of the subject
	Segment Name	string	The name of the segment
Output	Result	Result	Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidSegmentName
	Segment Name	string	The name of the parent segment or an empty string if it is the root segment.
C++	<pre>// class Output_GetSegmentParentName //{ // public: //   Result::Enum Result; //   String      SegmentName; // }; // // Output_GetSegmentParentName GetSegmentParentName( //   const String &amp; SubjectName, //   const String &amp; SegmentName ) const  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); MyClient.EnableSegmentData(); MyClient.GetFrame();  Output_GetSegmentParentName Output; Output = MyClient.GetSegmentParentName( "Bob", "Pelvis" ); // Output.Result == Success // Output.SegmentName == "" // This is the root segment Output = MyClient.GetSegmentParentName( "Bob", "LFemur" ); // Output.Result == Success // Output.SegmentName == "Pelvis"</pre>		
MATLAB	<pre>% [Output] = GetSegmentParentName( SubjectName, SegmentName )  MyClient = Client(); MyClient.Connect( "localhost" ); MyClient.EnableSegmentData(); MyClient.GetFrame();  Output = MyClient.GetSegmentParentName( "Bob", "Pelvis" ); % Output.Result == Success % Output.SegmentCount == "" % This is the root segment Output = MyClient.GetSegmentParentName( "Bob", "LFemur" ); % Output.Result == Success % Output.SegmentCount == "Pelvis"</pre>		
.NET	<pre>// public class Output_GetSegmentParentName //{ //   public Result Result; //   public string SegmentName; // }; // // Output_GetSegmentParentName GetSegmentParentName(</pre>		

[About the SDK](#)**SDK Functions Listing:  
GetSegmentParentName**[Appendix A: What's New](#)

```
//  
//  
//  
string SubjectName,  
string SegmentName );  
  
ViconDataStreamSDK.DotNET.Client MyClient =  
    new ViconDataStreamSDK.DotNET.Client();  
MyClient.Connect( "localhost" );  
MyClient.EnableSegmentData();  
MyClient.GetFrame();  
  
Output_GetSegmentParentName Output;  
Output = MyClient.GetSegmentParentName( "Bob", "Pelvis" );  
    // Output.Result == Success  
    // Output.SegmentName == ""  
    // This is the root segment  
Output = MyClient.GetSegmentParentName( "Bob", "LFemur" );  
    // Output.Result == Success  
    // Output.SegmentName == "Pelvis"
```

**GetSegmentChildCount**

*Return the number of descendant segments for a specified subject segment in the DataStream. This information can be used in conjunction with GetSegmentChildName.*

*See also:* [GetSegmentChildName](#), [GetSegmentParentName](#)

Input	Subject Name	string	The name of the subject
	Segment Name	string	The name of the segment
Output	Result	Result	Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidSegmentName
	Segment Count	unsigned integer	The number of segments
C++	<pre>// class Output_GetSegmentChildCount // { //   public: //     Result::Enum Result; //     unsigned int SegmentCount; //   }; // Output_GetSegmentChildCount GetSegmentChildCount( //   const String &amp; SubjectName, //   const String &amp; SegmentName ) const;  ViconDataStreamSDK::CPP::Client MyClient; MyClient.EnableSegmentData(); MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output_GetSegmentChildCount Output; Output = MyClient.GetSegmentCount( "Bob", "Pelvis" ); // Output.Result == Success // Output.SegmentCount &gt;= 0</pre>		
MATLAB	<pre>% [Output] = GetSegmentChildCount( SubjectName, SegmentName )  MyClient = Client(); MyClient.EnableSegmentData(); MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output = MyClient.GetSegmentChildCount( "Bob", "Pelvis" ); % Output.Result == Success % Output.SegmentCount &gt;= 0</pre>		
.NET	<pre>// public class Output_GetSegmentChildCount // { //   public Result Result; //   public uint SegmentCount; // }; // Output_GetSegmentChildCount GetSegmentChildCount( string SubjectName, //   string SegmentName );  ViconDataStreamSDK.DotNET.Client MyClient =   new ViconDataStreamSDK.DotNET.Client(); MyClient.EnableSegmentData(); MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output_GetSegmentCount Output; Output = MyClient.GetSegmentCount( "Bob", "Pelvis" ); // Output.Result == Success</pre>		

---

[About the SDK](#)[SDK Functions Listing:](#)  
[GetSegmentChildCount](#)[Appendix A: What's New](#)

---

```
// Output.SegmentCount >= 0
```

## GetSegmentChildName

*Return the name of a child segment for a specified subject segment. This can be passed into segment functions.*

*See also:* GetSegmentCount

Input	Subject Name	string	The name of the subject
	Segment Name	string	The name of the parent segment.
	Segment Index	unsigned integer	The index of the child segment.
Output	Result	Result	Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidSegmentName Result.InvalidIndex
	Segment Name	string	The name of the child segment
C++	<b>A valid Segment Index is between 0 and GetSegmentChildCount()-1</b> <pre> // class Output_GetSegmentChildName // { //   public: //     Result::Enum Result; //     String      SegmentName; //   }; // // Output_GetSegmentChildName GetSegmentName( //   const String      &amp; SubjectName, //   const String      &amp; SegmentName, //   const unsigned int SegmentIndex ) const  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); MyClient.EnableSegmentData(); MyClient.GetFrame();  Output_GetSegmentChildCount OutputGSCC; OutputGSCC = MyClient.GetSegmentChildCount( "Bob", "Pelvis" ); // OutputGSCC.Result == Success // OutputGSCC.SegmentCount == 2  Output_GetSegmentChildName OutputGSCN; OutputGSCN = MyClient.GetSegmentName( "Alice", 0 ); // OutputGSCN.Result == InvalidSubjectName // OutputGSCN.SegmentName == ""  OutputGSCN = MyClient.GetSegmentName( "Bob", "Pelvis", 0 ); // OutputGSCN.Result == Success // OutputGSCN.SegmentName == "LFemur" OutputGSCN = MyClient.GetSegmentName( "Bob", "Pelvis", 1 ); // OutputGSCN.Result == Success // OutputGSCN.SegmentName == "RFemur" OutputGSCN = MyClient.GetSegmentName( "Bob", "Pelvis", 2 ); // OutputGSCN.Result == InvalidIndex // OutputGSCN.SegmentName == "" // (no third segment) </pre>		
MATLAB	<b>A valid Segment Index is between 1 and GetSegmentChildCount()</b>		

	<pre>% [Output] = GetSegmentChildName( SubjectName, SegmentName, SegmentIndex )  MyClient = Client(); MyClient.Connect( "localhost" ); MyClient.EnableSegmentData(); MyClient.GetFrame();  OutputGSCC = MyClient.GetSegmentChildCount( "Bob", "Pelvis" );     % OutputGSCC.Result == Success     % OutputGSCC.SegmentCount == 2  OutputGSCN = MyClient.GetSegmentChildName( "Alice", "Pelvis", 1 );     % OutputGSCN.Result == InvalidSubjectName     % OutputGSCN.SegmentName == ""  OutputGSCN = MyClient.GetSegmentChildName( "Bob", "Pelvis", 1 );     % OutputGSCN.Result == Success     % OutputGSCN.SegmentName == "LFemur" OutputGSCN = MyClient.GetSegmentChildName( "Bob", "Pelvis", 2 );     % OutputGSCN.Result == Success     % OutputGSCN.SegmentName == "RFemur" OutputGSCN = MyClient.GetSegmentChildName( "Bob", "Pelvis", 3 );     % OutputGSCN.Result == InvalidIndex     % OutputGSCN.SegmentName == ""     % (no third segment)</pre>
.NET	<p>A valid Segment Index is between 0 and GetSegmentChildCount()-1</p> <pre>// public class Output_GetSegmentChildName // { //     public Result Result; //     public string SegmentName; // } // // Output_GetSegmentChildName GetSegmentChildName( string SubjectName, //   string SegmentName, //   uint    SegmentIndex );  ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect( "localhost" ); MyClient.EnableSegmentData(); MyClient.GetFrame();  Output_GetSegmentChildCount OutputGSCC; OutputGSCC = MyClient.GetSegmentChildCount( "Bob", "Pelvis" );     // OutputGSCC.Result == Success     // OutputGSCC.SegmentCount == 2  Output_GetSegmentChildName OutputGSCN; OutputGSCN = MyClient.GetSegmentChildName( "Alice", "Pelvis", 0 );     // OutputGSCN.Result == InvalidSubjectName     // OutputGSCN.SegmentName == ""  OutputGSCN = MyClient.GetSegmentChildName( "Bob", "Pelvis", 0 );     // OutputGSCN.Result == Success     // OutputGSCN.SegmentName == "LFemur" OutputGSCN = MyClient.GetSegmentChildName( "Bob", "Pelvis", 1 );     // OutputGSCN.Result == Success     // OutputGSCN.SegmentName == "RFemur" OutputGSCN = MyClient.GetSegmentChildName( "Bob", "Pelvis", 2 );     // OutputGSCN.Result == InvalidIndex     // OutputGSCN.SegmentName == ""     // (no third segment)</pre>

**GetSegmentStaticTranslation**

*Return the static pose translation of a subject segment.*

*See also:* GetSegmentStaticRotationHelical, GetSegmentStaticRotationMatrix, GetSegmentStaticRotationQuaternion, GetSegmentStaticRotationEulerXYZ, GetSegmentLocalTranslation, GetSegmentLocalRotationHelical, GetSegmentLocalRotationMatrix, GetSegmentLocalRotationQuaternion, GetSegmentLocalRotationEulerXYZ

<b>Input</b>	Subject Name	string	The name of the subject
	Segment Name	string	The name of the segment.
<b>Output</b>	Result	Result	Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidSegmentName
	Translation	double[3]	The translation of the segment
C++	<pre>// class Output_GetSegmentStaticTranslation //{ // public: //     Result::Enum Result; //     double      Translation[ 3 ]; // }; // // Output_GetSegmentStaticTranslation GetSegmentStaticTranslation( //     const String &amp; SubjectName, //     const String &amp; SegmentName ) const;  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); MyClient.EnableSegmentData(); MyClient.GetFrame();  Output_GetSegmentStaticTranslation Output =     MyClient.GetSegmentStaticTranslation( "Alice", "Pelvis" );</pre>		
MATLAB	<pre>% [Output] = GetSegmentStaticTranslation( SubjectName, SegmentName )  MyClient = Client(); MyClient.Connect( "localhost" ); MyClient.EnableSegmentData(); MyClient.GetFrame();  Output = MyClient.GetSegmentStaticTranslation( "Alice", "Pelvis" );</pre>		
.NET	<pre>// public class Output_GetSegmentStaticTranslation //{ //     public Result   Result; //     public double[] Translation; // }; // // Output_GetSegmentStaticTranslation GetSegmentStaticTranslation( //     string  SubjectName, //     string  SegmentName );  ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect( "localhost" ); MyClient.EnableSegmentData(); MyClient.GetFrame();  Output_GetSegmentStaticTranslation Output =     MyClient.GetSegmentStaticTranslations( "Alice", "Pelvis" );</pre>		

## GetSegmentStaticRotationHelical

*Return the static pose rotation of a subject segment in helical co-ordinates.*

*The helical co-ordinates represent a vector whose length is the amount of rotation in radians, and the direction is the axis about which to rotate.*

*See also:* GetSegmentStaticTranslation, GetSegmentStaticRotationMatrix, GetSegmentStaticRotationQuaternion, GetSegmentStaticRotationEulerXYZ, GetSegmentLocalTranslation, GetSegmentLocalRotationHelical, GetSegmentLocalRotationMatrix, GetSegmentLocalRotationQuaternion, GetSegmentLocalRotationEulerXYZ

<b>Input</b>	Subject Name	string	The name of the subject
	Segment Name	string	The name of the segment.
<b>Output</b>	Result	Result	Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidSegmentName
	Rotation	double[3]	The rotation of the segment
C++	<pre>// class Output_GetSegmentStaticRotationHelical //{ // public: //   Result::Enum Result; //   double      Rotation[ 3 ]; // }; // Output_GetSegmentStaticRotationHelical //   GetSegmentStaticRotationHelical( //     const String &amp; SubjectName, //     const String &amp; SegmentName ) const  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output_GetSegmentStaticRotationHelical Output =   MyClient.GetSegmentStaticRotationHelical( "Alice", "Pelvis" );</pre>		
MATLAB	<pre>% [Output] = GetSegmentStaticRotationHelical( SubjectName, SegmentName )  MyClient = Client(); MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output = MyClient.GetSegmentStaticRotationHelical( "Alice", "Pelvis" );</pre>		
.NET	<pre>// public class Output_GetSegmentStaticRotationHelical //{ //   public Result   Result; //   public double[] Rotation; // }; // // Output_GetSegmentStaticRotationHelical //   GetSegmentStaticRotationHelical( string SubjectName, //                                     string SegmentName );  ViconDataStreamSDK.DotNET.Client MyClient =   new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output_GetSegmentStaticRotationHelical Output =   MyClient.GetSegmentStaticRotationHelical( "Alice", "Pelvis" );</pre>		

**GetSegmentStaticRotationMatrix**

*Return the static pose rotation of a subject segment as a 3x3 row-major matrix.*

*See also:* GetSegmentStaticTranslation, GetSegmentStaticRotationHelical, GetSegmentStaticRotationQuaternion, GetSegmentStaticRotationEulerXYZ, GetSegmentLocalTranslation, GetSegmentLocalRotationHelical, GetSegmentLocalRotationQuaternion, GetSegmentLocalRotationEulerXYZ

Input	Subject Name	string	The name of the subject
	Segment Name	string	The name of the segment.
Output	Success	Result	Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidSegmentName
	Rotation	double[9]	The rotation of the segment
C++	<pre>// class Output_GetSegmentStaticRotationMatrix // { // public: //     Result::Enum Result; //     double        Rotation[ 9 ]; // }; // // Output_GetSegmentStaticRotationMatrix //     GetSegmentStaticRotationMatrix( //         const String &amp; SubjectName, //         const String &amp; SegmentName ) const;  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output_GetSegmentStaticRotationMatrix Output =     MyClient.GetSegmentStaticRotationMatrix( "Alice", "Pelvis" );</pre>		
MATLAB	<pre>% [Output] = GetSegmentStaticRotationMatrix( SubjectName, SegmentName )  MyClient = Client(); MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output = MyClient.GetSegmentStaticRotationMatrix( "Alice", "Pelvis" );</pre>		
.NET	<pre>// public class Output_GetSegmentStaticRotationMatrix // { //     public Result Result; //     public double[] Rotation; // }; // // Output_GetSegmentStaticRotationMatrix //     GetSegmentStaticRotationMatrix( string SubjectName, //                                     string SegmentName );  ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output_GetSegmentStaticRotationMatrix Output =     MyClient.GetSegmentStaticRotationMatrix( "Alice", "Pelvis" );</pre>		

**GetSegmentStaticRotationQuaternion**

*Return the static pose rotation of a subject segment in quaternion co-ordinates.*

*The quaternion is of the form (x, y, z, w) where w is the real component and x, y & z are the imaginary components. N.B. This is different from that used in many other applications, which use (w, x, y, z).*

*See also:* GetSegmentStaticTranslation, GetSegmentStaticRotationHelical, GetSegmentStaticRotationMatrix, GetSegmentStaticRotationEulerXYZ, GetSegmentLocalTranslation, GetSegmentLocalRotationHelical, GetSegmentLocalRotationMatrix, GetSegmentLocalRotationQuaternion, GetSegmentLocalRotationEulerXYZ

<b>Input</b>	Subject Name	string	The name of the subject
	Segment Name	string	The name of the segment.
<b>Output</b>	Result	Result	Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidSegmentName
	Rotation	double[4]	The rotation of the segment
C++	<pre>// class Output_GetSegmentStaticRotationQuaternion //{ // public: //   Result::Enum Result; //   double      Rotation[ 4 ]; // };  // Output_GetSegmentStaticRotationQuaternion //   GetSegmentStaticRotationQuaternion( //     const String &amp; SubjectName, //     const String &amp; SegmentName ) const  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output_GetSegmentStaticRotationQuaternion Output =   MyClient.GetSegmentStaticRotationQuaternion( "Alice", "Pelvis" );</pre>		
MATLAB	<pre>% [Output] = GetSegmentStaticRotationQuaternion( SubjectName, SegmentName )  MyClient = Client(); MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output = MyClient.GetSegmentStaticRotationQuaternion( "Alice", "Pelvis" );</pre>		
.NET	<pre>// public class Output_GetSegmentStaticRotationQuaternion //{ //   public Result Result; //   public double[] Rotation; // };  // Output_GetSegmentStaticRotationQuaternion //   GetSegmentStaticRotationQuaternion( string SubjectName, //   string SegmentName );  ViconDataStreamSDK.DotNET.Client MyClient =   new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output_GetSegmentStaticRotationQuaternion Output =   MyClient.GetSegmentStaticRotationQuaternion( "Alice", "Pelvis" );</pre>		

**GetSegmentStaticRotationEulerXYZ**

*Return the static pose rotation of a subject segment in EulerXYZ co-ordinates.*

*See also:* [GetSegmentStaticTranslation](#), [GetSegmentStaticRotationHelical](#), [GetSegmentStaticRotationMatrix](#), [GetSegmentStaticRotationQuaternion](#), [GetSegmentLocalTranslation](#), [GetSegmentLocalRotationHelical](#), [GetSegmentLocalRotationMatrix](#), [GetSegmentLocalRotationQuaternion](#), [GetSegmentLocalRotationEulerXYZ](#)

<b>Input</b>	Subject Name	string	The name of the subject
	Segment Name	string	The name of the segment.
<b>Output</b>	Result	Result	Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidSegmentName
	Rotation	double[3]	The rotation of the segment
C++	<pre>// class Output_GetSegmentStaticRotationEulerXYZ // { // public: //     Result::Enum Result; //     double      Rotation[ 3 ]; // }; // // Output_GetSegmentStaticRotationEulerXYZ //     GetSegmentStaticRotationEulerXYZ( //         const String &amp; SubjectName, //         const String &amp; SegmentName ) const  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output_GetSegmentStaticRotationEulerXYZ Output =     MyClient.GetSegmentStaticRotationEulerXYZ( "Alice", "Pelvis" );</pre>		
MATLAB	<pre>% [Output] = GetSegmentStaticRotationEulerXYZ( SubjectName, SegmentName )  MyClient = Client(); MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output = MyClient.GetSegmentStaticRotationEulerXYZ( "Alice", "Pelvis" );</pre>		
.NET	<pre>// public class Output_GetSegmentStaticRotationEulerXYZ // { //     public Result Result; //     public double[] Rotation; // }; // // Output_GetSegmentStaticRotationEulerXYZ //     GetSegmentStaticRotationEulerXYZ( string SubjectName, //   string SegmentName );  ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output_GetSegmentStaticRotationEulerXYZ Output =     MyClient.GetSegmentStaticRotationEulerXYZ( "Alice", "Pelvis" );</pre>		

**GetSegmentGlobalTranslation**

*Return the translation of a subject segment in global co-ordinates.*

*The Translation is of the form (x, y, z) where x, y & z are in millimeters with respect to the global origin.*

*See also:* GetSegmentGlobalRotationHelical, GetSegmentGlobalRotationMatrix, GetSegmentGlobalRotationQuaternion, GetSegmentGlobalRotationEulerXYZ, GetSegmentLocalTranslation, GetSegmentLocalRotationHelical, GetSegmentLocalRotationMatrix, GetSegmentLocalRotationQuaternion, GetSegmentLocalRotationEulerXYZ

<b>Input</b>	Subject Name	string	The name of the subject
	Segment Name	string	The name of the segment.
<b>Output</b>	Result	Result	Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidSegmentName
	Translation	double[3]	The translation of the segment
	Occluded	boolean	True if the segment was present at this frame. If false, then Translation will be [0,0,0]
C++	<pre>// class Output_GetSegmentGlobalTranslation // { // public: //     Result::Enum Result; //     double      Translation[ 3 ]; //     bool        Occluded; // }; // // Output_GetSegmentGlobalTranslation GetSegmentGlobalTranslation( //         const String &amp; SubjectName, //         const String &amp; SegmentName ) const;  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost" ); MyClient.EnableSegmentData(); MyClient.GetFrame();  Output_GetSegmentGlobalTranslation Output =     MyClient.GetSegmentGlobalTranslation("Alice", "Pelvis" );</pre>		
MATLAB	<pre>% [Output] = GetSegmentGlobalTranslation( SubjectName, SegmentName )  MyClient = Client(); MyClient.Connect("localhost" ); MyClient.EnableSegmentData(); MyClient.GetFrame();  Output = MyClient.GetSegmentGlobalTranslation("Alice", "Pelvis" );</pre>		
.NET	<pre>// public class Output_GetSegmentGlobalTranslation // { //     public Result   Result; //     public double[] Translation; //     public bool     Occluded; // }; // // Output_GetSegmentGlobalTranslation GetSegmentGlobalTranslation( //         string  SubjectName, //         string  SegmentName );  ViconDataStreamSDK.DotNET.Client MyClient =</pre>		

[About the SDK](#)SDK Functions Listing:  
**GetSegmentGlobalTranslation**[Appendix A: What's New](#)

```
new ViconDataStreamSDK.DotNET.Client();  
MyClient.Connect("localhost" );  
MyClient.EnableSegmentData();  
MyClient.GetFrame();  
  
Output_GetSegmentGlobalTranslation Output =  
MyClient.GetSegmentGlobalTranslation("Alice", "Pelvis" );
```

**GetSegmentGlobalRotationHelical**

*Return the rotation of a subject segment in global helical co-ordinates.*

*See also:* GetSegmentGlobalTranslation, GetSegmentGlobalRotationMatrix, GetSegmentGlobalRotationQuaternion, GetSegmentGlobalRotationEulerXYZ, GetSegmentLocalTranslation, GetSegmentLocalRotationHelical, GetSegmentLocalRotationMatrix, GetSegmentLocalRotationQuaternion, GetSegmentLocalRotationEulerXYZ

Input	Subject Name	string	The name of the subject
	Segment Name	string	The name of the segment.
Output	Result	Result	<b>Result.Success</b> <b>Result.NotConnected</b> <b>Result.NoFrame</b> <b>Result.InvalidSubjectName</b> <b>Result.InvalidSegmentName</b>
	Rotation	double[3]	The rotation of the segment
	Occluded	boolean	True if the segment was present at this frame. If false, then Rotation will be [0,0,0]
C++	<pre>// class Output_GetSegmentGlobalRotationHelical // { // public: //     Result::Enum Result; //     double      Rotation[ 3 ]; //     bool        Occluded; // }; // Output_GetSegmentGlobalRotationHelical //     GetSegmentGlobalRotationHelical( //         const String &amp; SubjectName, //         const String &amp; SegmentName ) const ViconDataStreamSDK::CPP::Client MyClient;  MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output_GetSegmentGlobalRotationHelical Output =     MyClient.GetSegmentGlobalRotationHelical( "Alice", "Pelvis" );</pre>		
MATLAB	<pre>% [Output] = GetSegmentGlobalRotationHelical( SubjectName, SegmentName )  MyClient = Client(); MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output = MyClient.GetSegmentGlobalRotationHelical( "Alice", "Pelvis" );</pre>		
.NET	<pre>// public class Output_GetSegmentGlobalRotationHelical // { //     public Result   Result; //     public double[] Rotation; //     public bool     Occluded; // }; // Output_GetSegmentGlobalRotationHelical //     GetSegmentGlobalRotationHelical( string SubjectName, //                                     string SegmentName ); ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client();  MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output_GetSegmentGlobalRotationHelical Output =     MyClient.GetSegmentGlobalRotationHelical( "Alice", "Pelvis" );</pre>		

**GetSegmentGlobalRotationMatrix**

*Return the rotation of a subject segment as a 3x3 row-major matrix in global co-ordinates.*

*See also:* [GetSegmentGlobalTranslation](#), [GetSegmentGlobalRotationHelical](#), [GetSegmentGlobalRotationQuaternion](#), [GetSegmentGlobalRotationEulerXYZ](#), [GetSegmentLocalTranslation](#), [GetSegmentLocalRotationHelical](#), [GetSegmentLocalRotationQuaternion](#), [GetSegmentLocalRotationEulerXYZ](#)

<b>Input</b>  <b>Output</b>	<b>Subject Name</b>  <b>Success</b>	<b>string</b>  <b>Result</b>	The name of the subject  Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidSegmentName
	<b>Segment Name</b>	<b>string</b>	The name of the segment.
	<b>Rotation</b>	<b>double[9]</b>	The rotation of the segment
	<b>Occluded</b>	<b>boolean</b>	True if the segment was present at this frame. If false, then Rotation will be all 0.
<b>C++</b>	<pre>// class Output_GetSegmentGlobalRotationMatrix //{ // public: //     Result::Enum Result; //     double        Rotation[ 9 ]; //     bool          Occluded; // }; // Output_GetSegmentGlobalRotationMatrix //     GetSegmentGlobalRotationMatrix( //         const String &amp; SubjectName, //         const String &amp; SegmentName ) const;  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output_GetSegmentGlobalRotationMatrix Output =     MyClient.GetSegmentGlobalRotationMatrix( "Alice", "Pelvis" );</pre>		
<b>MATLAB</b>	<pre>% [Output] = GetSegmentGlobalRotationMatrix( SubjectName, SegmentName )  MyClient = Client(); MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output = MyClient.GetSegmentGlobalRotationMatrix( "Alice", "Pelvis" );</pre>		
<b>.NET</b>	<pre>// public class Output_GetSegmentGlobalRotationMatrix //{ //     public Result    Result; //     public double[] Rotation; //     public bool      Occluded; // }; // Output_GetSegmentGlobalRotationMatrix //     GetSegmentGlobalRotationMatrix( string SubjectName, //                                     string SegmentName );  ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output_GetSegmentGlobalRotationMatrix Output =     MyClient.GetSegmentGlobalRotationMatrix( "Alice", "Pelvis" );</pre>		

## GetSegmentGlobalRotationQuaternion

*Return the rotation of a subject segment in global quaternion co-ordinates.*

*The quaternion is of the form (x, y, z, w) where w is the real component and x, y & z are the imaginary components. N.B. This is different from that used in many other applications, which use (w, x, y, z).*

*See also:* GetSegmentGlobalTranslation, GetSegmentGlobalRotationHelical, GetSegmentGlobalRotationMatrix, GetSegmentGlobalRotationEulerXYZ, GetSegmentLocalTranslation, GetSegmentLocalRotationHelical, GetSegmentLocalRotationMatrix, GetSegmentLocalRotationQuaternion, GetSegmentLocalRotationEulerXYZ

Input	Subject Name	string	The name of the subject
	Segment Name	string	The name of the segment.
Output	Result	Result	Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidSegmentName
	Rotation	double[4]	The rotation of the segment
	Occluded	boolean	True if the segment was present at this frame. If false, then Rotation will be [0,0,0,0]
C++	<pre>// class Output_GetSegmentGlobalRotationQuaternion // { //     public: //         Result::Enum Result; //         double        Rotation[ 4 ]; //         bool          Occluded; //     }; // // Output_GetSegmentGlobalRotationQuaternion //     GetSegmentGlobalRotationQuaternion( //         const String &amp; SubjectName, //         const String &amp; SegmentName ) const  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output GetSegmentGlobalRotationQuaternion Output =     MyClient.GetSegmentGlobalRotationQuaternion( "Alice", "Pelvis" );</pre>		
MATLAB	<pre>% [Output] = GetSegmentGlobalRotationQuaternion( SubjectName, SegmentName )  MyClient = Client(); MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output = MyClient.GetSegmentGlobalRotationQuaternion( "Alice", "Pelvis" );</pre>		
.NET	<pre>// public class Output_GetSegmentGlobalRotationQuaternion // { //     public Result    Result; //     public double[] Rotation; //     public bool      Occluded; // }; // // Output_GetSegmentGlobalRotationQuaternion //     GetSegmentGlobalRotationQuaternion( string SubjectName, //   string SegmentName );  ViconDataStreamSDK.DotNET.Client MyClient =</pre>		

---

[About the SDK](#)

### SDK Functions Listing: [GetSegmentGlobalRotationQuaternion](#)

[Appendix A: What's New](#)

---

```
new ViconDataStreamSDK.DotNET.Client();
MyClient.Connect( "localhost" );
MyClient.GetFrame();

Output_GetSegmentGlobalRotationQuaternion Output =
    MyClient.GetSegmentGlobalRotationQuaternion( "Alice", "Pelvis" );
```

**GetSegmentGlobalRotationEulerXYZ**

*Return the rotation of a subject segment in global EulerXYZ co-ordinates.*

*See also:* GetSegmentGlobalTranslation, GetSegmentGlobalRotationHelical, GetSegmentGlobalRotationMatrix, GetSegmentGlobalRotationQuaternion, GetSegmentLocalTranslation, GetSegmentLocalRotationHelical, GetSegmentLocalRotationMatrix, GetSegmentLocalRotationQuaternion, GetSegmentLocalRotationEulerXYZ

<b>Input</b>	Subject Name	string	The name of the subject
	Segment Name	string	The name of the segment.
<b>Output</b>	Result	Result	Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidSegmentName
	Rotation	double[3]	The rotation of the segment
	Occluded	boolean	True if the segment was present at this frame. If false, then Rotation will be [0,0,0]
<b>C++</b>	<pre>// class Output_GetSegmentGlobalRotationEulerXYZ // { // public: //     Result::Enum Result; //     double      Rotation[ 3 ]; //     bool        Occluded; // }; // Output_GetSegmentGlobalRotationEulerXYZ //     GetSegmentGlobalRotationEulerXYZ( //         const String &amp; SubjectName, //         const String &amp; SegmentName ) const  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost" ); MyClient.GetFrame();  Output_GetSegmentGlobalRotationEulerXYZ Output =     MyClient.GetSegmentGlobalRotationEulerXYZ("Alice", "Pelvis" );</pre>		
<b>MATLAB</b>	<pre>% [Output] = GetSegmentGlobalRotationEulerXYZ( SubjectName, SegmentName )  MyClient = Client(); MyClient.Connect("localhost" ); MyClient.GetFrame();  Output = MyClient.GetSegmentGlobalRotationEulerXYZ("Alice", "Pelvis" );</pre>		
<b>.NET</b>	<pre>// public class Output_GetSegmentGlobalRotationEulerXYZ // { //     public Result   Result; //     public double[] Rotation; //     public bool     Occluded; // }; // Output_GetSegmentGlobalRotationEulerXYZ //     GetSegmentGlobalRotationEulerXYZ( string SubjectName, //   string SegmentName );  ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect("localhost" ); MyClient.GetFrame();  Output_GetSegmentGlobalRotationEulerXYZ Output =     MyClient.GetSegmentGlobalRotationEulerXYZ("Alice", "Pelvis" );</pre>		

## GetSegmentLocalTranslation

*Return the translation of a subject segment in local co-ordinates relative to its parent segment.*

*See also:* GetSegmentLocalRotationHelical, GetSegmentLocalRotationMatrix, GetSegmentLocalRotationQuaternion, GetSegmentLocalRotationEulerXYZ, GetSegmentGlobalTranslation, GetSegmentGlobalRotationHelical, GetSegmentGlobalRotationMatrix, GetSegmentGlobalRotationQuaternion, GetSegmentGlobalRotationEulerXYZ

Input	Subject Name	string	The name of the subject
	Segment Name	string	The name of the segment.
Output	Result	Result	Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidSegmentName
	Translation	double[3]	The translation of the segment
	Occluded	boolean	True if the segment was present at this frame. If false, then Translation will be [0,0,0]
C++	<pre>// class Output_GetSegmentLocalTranslation //{ // public: //     Result::Enum Result; //     double      Translation[ 3 ]; //     bool        Occluded; // }; // // Output_GetSegmentLocalTranslation GetSegmentLocalTranslation( //     const String &amp; SubjectName, //     const String &amp; SegmentName ) const;  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); MyClient.EnableSegmentData(); MyClient.GetFrame();  Output_GetSegmentLocalTranslation Output =     MyClient.GetSegmentLocalTranslation( "Alice", "Pelvis" );</pre>		
MATLAB	<pre>% [Output] = GetSegmentLocalTranslation( SubjectName, SegmentName )  MyClient = Client(); MyClient.Connect( "localhost" ); MyClient.EnableSegmentData(); MyClient.GetFrame();  Output = MyClient.GetSegmentLocalTranslation( "Alice", "Pelvis" );</pre>		
.NET	<pre>// public class Output_GetSegmentLocalTranslation //{ //     public Result   Result; //     public double[] Translation; //     public bool     Occluded; // }; // // Output_GetSegmentLocalTranslation GetSegmentLocalTranslation( //     string  SubjectName, //     string  SegmentName );  ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client();</pre>		

---

[About the SDK](#)

## SDK Functions Listing: GetSegmentLocalTranslation

[Appendix A: What's New](#)

---

```
MyClient.Connect( "localhost" );
MyClient.EnableSegmentData();
MyClient.GetFrame();

Output_GetSegmentLocalTranslation Output =
MyClient.GetSegmentLocalTranslations( "Alice", "Pelvis" );
```

**GetSegmentLocalRotationHelical**

*Return the rotation of a subject segment in local helical co-ordinates relative to its parent segment.*

*See also:* GetSegmentLocalTranslation, GetSegmentLocalRotationMatrix, GetSegmentLocalRotationQuaternion, GetSegmentLocalRotationEulerXYZ, GetSegmentGlobalTranslation, GetSegmentGlobalRotationHelical, GetSegmentGlobalRotationMatrix, GetSegmentGlobalRotationQuaternion, GetSegmentGlobalRotationEulerXYZ

<b>Input</b>	Subject Name	string	The name of the subject
	Segment Name	string	The name of the segment.
<b>Output</b>	<b>Result</b>	<b>Result</b>	Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidSegmentName
	Rotation	double[3]	The rotation of the segment
	Occluded	boolean	True if the segment was present at this frame. If false, then Rotation will be [0,0,0]
C++	<pre>// class Output_GetSegmentLocalRotationHelical // { // public: //     Result::Enum Result; //     double        Rotation[ 3 ]; //     bool          Occluded; // }; // Output_GetSegmentLocalRotationHelical //     GetSegmentLocalRotationHelical( //         const String &amp; SubjectName, //         const String &amp; SegmentName ) const  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output_GetSegmentLocalRotationHelical Output =     MyClient.GetSegmentLocalRotationHelical( "Alice", "Pelvis" );</pre>		
MATLAB	<pre>% [Output] = GetSegmentLocalRotationHelical( SubjectName, SegmentName )  MyClient = Client(); MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output = MyClient.GetSegmentLocalRotationHelical( "Alice", "Pelvis" );</pre>		
.NET	<pre>// public class Output_GetSegmentLocalRotationHelical // { //     public Result    Result; //     public double[] Rotation; //     public bool      Occluded; // }; // Output_GetSegmentLocalRotationHelical //     GetSegmentLocalRotationHelical( string SubjectName, //                                     string SegmentName );  ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output_GetSegmentLocalRotationHelical Output =     MyClient.GetSegmentLocalRotationHelical( "Alice", "Pelvis" );</pre>		

**GetSegmentLocalRotationMatrix**

*Return the rotation row-major matrix of a subject segment in local co-ordinates relative to its parent segment.*

*See also:* [GetSegmentLocalTranslation](#), [GetSegmentLocalRotationQuaternion](#), [GetSegmentLocalRotationEulerXYZ](#), [GetSegmentGlobalTranslation](#), [GetSegmentGlobalRotationHelical](#), [GetSegmentGlobalRotationMatrix](#), [GetSegmentGlobalRotationQuaternion](#), [GetSegmentGlobalRotationEulerXYZ](#)

<b>Input</b>  <b>Output</b>	<b>Subject Name</b>  <b>Result</b>	<b>string</b>  <b>double[9]</b>	The name of the subject  Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidSegmentName
	<b>Segment Name</b>	<b>string</b>	The name of the segment.
	<b>Rotation</b>	<b>boolean</b>	The rotation of the segment
	<b>Occluded</b>	<b>boolean</b>	True if the segment was present at this frame. If false, then Rotation will be all 0.
<b>C++</b>	<pre>// class Output_GetSegmentLocalRotationMatrix // { // public: //     Result::Enum Result; //     double        Rotation[ 9 ]; //     bool          Occluded; // }; // Output_GetSegmentLocalRotationMatrix //     GetSegmentLocalRotationMatrix( //         const String &amp; SubjectName, //         const String &amp; SegmentName ) const; ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output_GetSegmentLocalRotationMatrix Output =     MyClient.GetSegmentLocalRotationMatrix( "Alice", "Pelvis" );</pre>		
<b>MATLAB</b>	<pre>% [Output] = GetSegmentLocalRotationMatrix( SubjectName, SegmentName )  MyClient = Client(); MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output = MyClient.GetSegmentLocalRotationMatrix( "Alice", "Pelvis" );</pre>		
<b>.NET</b>	<pre>// public class Output_GetSegmentLocalRotationMatrix // { //     public Result    Result; //     public double[] Rotation; //     public bool      Occluded; // }; // Output_GetSegmentLocalRotationMatrix //     GetSegmentLocalRotationMatrix( string SubjectName, //                                     string SegmentName ); ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output_GetSegmentLocalRotationMatrix Output =     MyClient.GetSegmentLocalRotationMatrix( "Alice", "Pelvis" );</pre>		

**GetSegmentLocalRotationQuaternion**

*Return the rotation of a subject segment in local quaternion co-ordinates relative to its parent segment.*

*The quaternion is of the form (x, y, z, w) where w is the real component and x, y & z are the imaginary components. N.B. This is different from that used in many other applications, which use (w, x, y, z).*

*See also:* GetSegmentLocalTranslation, GetSegmentLocalRotationHelical, GetSegmentLocalRotationMatrix, GetSegmentLocalRotationEulerXYZ, GetSegmentGlobalTranslation, GetSegmentGlobalRotationHelical, GetSegmentGlobalRotationMatrix, GetSegmentGlobalRotationQuaternion, GetSegmentGlobalRotationEulerXYZ

Input	Subject Name	string	The name of the subject
	Segment Name	string	The name of the segment.
Output	Result	Result	Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidSegmentName
	Rotation	double[4]	The rotation of the segment
	Occluded	boolean	True if the segment was present at this frame. If false, then Rotation will be [0,0,0,0]
C++	<pre>// class Output_GetSegmentLocalRotationQuaternion // { //     public: //         Result::Enum Result; //         double        Rotation[ 4 ]; //         bool          Occluded; //     }; // //     Output_GetSegmentLocalRotationQuaternion( //         const String &amp; SubjectName, //         const String &amp; SegmentName ) const  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output GetSegmentLocalRotationQuaternion Output =     MyClient.GetSegmentLocalRotationQuaternion( "Alice", "Pelvis" );</pre>		
MATLAB	<pre>% [Output] = GetSegmentLocalRotationQuaternion( SubjectName, SegmentName )  MyClient = Client(); MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output = MyClient.GetSegmentLocalRotationQuaternion( "Alice", "Pelvis" );</pre>		
.NET	<pre>// public class Output_GetSegmentLocalRotationQuaternion // { //     public Result    Result; //     public double[] Rotation; //     public bool      Occluded; // }; // // Output_GetSegmentLocalRotationQuaternion //     GetSegmentLocalRotationQuaternion( string SubjectName, //   string SegmentName );  ViconDataStreamSDK.DotNET.Client MyClient =</pre>		

[About the SDK](#)SDK Functions Listing:  
**GetSegmentLocalRotationQuaternion**[Appendix A: What's New](#)

```
new ViconDataStreamSDK.DotNET.Client();
MyClient.Connect( "localhost" );
MyClient.GetFrame();

Output_GetSegmentLocalRotationQuaternion Output =
    MyClient.GetSegmentLocalRotationQuaternion( "Alice", "Pelvis" );
```

**GetSegmentLocalRotationEulerXYZ**

*Return the rotation of a subject segment in local EulerXYZ co-ordinates relative to its parent segment.*

*See also:* GetSegmentLocalTranslation, GetSegmentLocalRotationHelical, GetSegmentLocalRotationMatrix, GetSegmentLocalRotationQuaternion, GetSegmentGlobalTranslation, GetSegmentGlobalRotationHelical, GetSegmentGlobalRotationMatrix, GetSegmentGlobalRotationQuaternion, GetSegmentGlobalRotationEulerXYZ

<b>Input</b>	Subject Name	string	The name of the subject
	Segment Name	string	The name of the segment.
<b>Output</b>	Result	Result	Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidSegmentName
	Rotation	double[3]	The rotation of the segment
	Occluded	boolean	True if the segment was present at this frame. If false, then Rotation will be [0,0,0]
C++	<pre>// class Output_GetSegmentLocalRotationEulerXYZ // { //     public: //         Result::Enum Result; //         double        Rotation[ 3 ]; //         bool          Occluded; //     }; // Output_GetSegmentLocalRotationEulerXYZ( //     const String &amp; SubjectName, //     const String &amp; SegmentName ) const  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output_GetSegmentLocalRotationEulerXYZ Output =     MyClient.GetSegmentLocalRotationEulerXYZ( "Alice", "Pelvis" );</pre>		
MATLAB	<pre>% [Output] = GetSegmentLocalRotationEulerXYZ( SubjectName, SegmentName )  MyClient = Client(); MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output = MyClient.GetSegmentLocalRotationEulerXYZ( "Alice", "Pelvis" );</pre>		
.NET	<pre>// public class Output_GetSegmentLocalRotationEulerXYZ // { //     public Result    Result; //     public double[] Rotation; //     public bool      Occluded; // }; // Output_GetSegmentLocalRotationEulerXYZ( //     GetSegmentLocalRotationEulerXYZ( string SubjectName, //                                     string SegmentName );  ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output_GetSegmentLocalRotationEulerXYZ Output =     MyClient.GetSegmentLocalRotationEulerXYZ( "Alice", "Pelvis" );</pre>		

## GetMarkerCount

*Return the number of markers for a specified subject in the DataStream. This information can be used in conjunction with GetMarkerName*

*See also:* GetSubjectName, GetMarkerName

<b>Input</b> <b>Output</b> <b></b> <b>C++</b> <b>MATLAB</b> <b>.NET</b>	<b>Subject Name</b> <b>Result</b> <b>Marker Count</b> <pre>// class Output_GetMarkerCount // { //   public: //     Result::Enum Result; //     unsigned int MarkerCount; // }; // // Output_GetMarkerCount GetMarkerCount( //   const String &amp; SubjectName ) const;  ViconDataStreamSDK::CPP::Client MyClient; MyClient.EnableMarkerData(); MyClient.Connect( "localhost" );  Output_GetMarkerCount Output; Output = MyClient.GetMarkerCount( "Bob" ); // Output.Result == NoFrame   // Output.MarkerCount == 0 MyClient.GetFrame();  Output = MyClient.GetMarkerCount( "Alice" );   // Output.Result == InvalidSubjectName   // Output.MarkerCount == 0   // (no "Alice")  Output = MyClient.GetMarkerCount( "Bob" ); // Output.Result == Success   // Output.MarkerCount &gt;= 0</pre> <pre>% [Output] = GetMarkerCount( SubjectName )  MyClient = Client(); MyClient.EnableMarkerData(); MyClient.Connect( "localhost" );  Output = MyClient.GetMarkerCount( "Bob" ); % Output.Result == NoFrame   % Output.MarkerCount == 0 MyClient.GetFrame();  Output = MyClient.GetMarkerCount( "Alice" );   % Output.Result == InvalidSubjectName   % Output.MarkerCount == 0   % (no "Alice")  Output = MyClient.GetMarkerCount( "Bob" ); % Output.Result == Success   % Output.MarkerCount &gt;= 0</pre> <pre>// public class Output_GetMarkerCount // { //   public Result Result; //   public uint MarkerCount; // }; // // Output_GetMarkerCount GetMarkerCount( string SubjectName );</pre>	<b>string</b> <b>Result</b> <b>unsigned integer</b> <pre>Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName</pre>	<b>The name of the subject</b> <b>The number of markers</b>

```
ViconDataStreamSDK.DotNET.Client MyClient =
    new ViconDataStreamSDK.DotNET.Client();
MyClient.EnableMarkerData();
MyClient.Connect( "localhost" );

Output_GetMarkerCount Output;
Output = MyClient.GetMarkerCount( "Bob" ); // Output.Result == NoFrame
                                              // Output.MarkerCount == 0
MyClient.GetFrame();

Output = MyClient.GetMarkerCount( "Alice" );
                                              // Output.Result == InvalidSubjectName
                                              // Output.MarkerCount == 0
                                              // (no "Alice")

Output = MyClient.GetMarkerCount( "Bob" ); // Output.Result == Success
                                              // Output.MarkerCount >= 0
```

## GetMarkerName

*Return the name of a marker for a specified subject. This can be passed into GetMarkerGlobalTranslation.*

*See also:* [GetMarkerCount](#), [GetMarkerGlobalTranslation](#)

Input	Subject Name	string	The name of the subject
	Marker Index	unsigned integer	The index of the marker.
Output	Result	Result	Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidIndex
	Marker Name	string	The name of the marker
C++	<b>A valid Marker Index is between 0 and GetMarkerCount()-1</b> <pre> // class Output_GetMarkerName // { //   public: //     Result::Enum Result; //     String      MarkerName; //   }; // // Output_GetMarkerName GetMarkerName( //   const String      &amp; SubjectName, //   const unsigned int MarkerIndex ) const;  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); MyClient.EnableMarkerData(); MyClient.GetFrame();  Output_GetMarkerCount OutputGMC; OutputGMC = MyClient.GetMarkerCount( "Bob" ); // OutputGMC.Result == Success // OutputGMC.MarkerCount == 2  Output_GetMarkerName OutputGMN; OutputGMN = MyClient.GetMarkerName( "Alice", 0 ); // OutputGMN.Result == InvalidSubjectName // OutputGMN.MarkerName == "" // (no "Alice")  OutputGMN = MyClient.GetMarkerName( "Bob", 0 ); // OutputGMN.Result == Success // OutputGMN.MarkerName == "LASI" OutputGMN = MyClient.GetMarkerName( "Bob", 1 ); // OutputGMN.Result == Success // OutputGMN.MarkerName == "RASI" OutputGMN = MyClient.GetMarkerName( "Bob", 2 ); // OutputGMN.Result == InvalidIndex // OutputGMN.MarkerName == "" // (no third marker) </pre>		
MATLAB	<b>A valid Marker Index is between 1 and GetMarkerCount()</b> <pre> % [Output] = GetMarkerName( SubjectName, MarkerIndex )  MyClient = Client(); MyClient.Connect( "localhost" ); MyClient.EnableMarkerData(); MyClient.GetFrame();  OutputGMC = MyClient.GetMarkerCount( "Bob" ); </pre>		

	<pre> // OutputGMC.Result == Success // OutputGMC.MarkerCount == 2  OutputGMN = MyClient.GetMarkerName( "Alice", 1 ); // OutputGMN.Result == InvalidSubjectName // OutputGMN.MarkerName == "" // (no "Alice")  OutputGMN = MyClient.GetMarkerName( "Bob", 1 ); // OutputGMN.Result == Success // OutputGMN.MarkerName == "LASI" OutputGMN = MyClient.GetMarkerName( "Bob", 2 ); // OutputGMN.Result == Success // OutputGMN.MarkerName == "RASI" OutputGMN = MyClient.GetMarkerName( "Bob", 3 ); // OutputGMN.Result == InvalidIndex // OutputGMN.MarkerName == "" // (no third marker) </pre>
.NET	<p>A valid Marker Index is between 0 and GetMarkerCount()-1</p> <pre> // public class Output_GetMarkerName // { //     public Result Result; //     public string MarkerName; // }; // // Output_GetMarkerName GetMarkerName( string SubjectName, //                                     uint    MarkerIndex );  ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect( "localhost" ); MyClient.EnableMarkerData(); MyClient.GetFrame();  Output_GetMarkerCount OutputGMC; OutputGMC = MyClient.GetMarkerCount( "Bob" ); // OutputGMC.Result == Success // OutputGMC.MarkerCount == 2  Output_GetMarkerName OutputGMN; OutputGMN = MyClient.GetMarkerName( "Alice", 0 ); // OutputGMN.Result == InvalidSubjectName // OutputGMN.MarkerName == "" // (no "Alice")  OutputGMN = MyClient.GetMarkerName( "Bob", 0 ); // OutputGMN.Result == Success // OutputGMN.MarkerName == "LASI" OutputGMN = MyClient.GetMarkerName( "Bob", 1 ); // OutputGMN.Result == Success // OutputGMN.MarkerName == "RASI" OutputGMN = MyClient.GetMarkerName( "Bob", 2 ); // OutputGMN.Result == InvalidIndex // OutputGMN.MarkerName == "" // (no third marker) </pre>

## GetMarkerParentName

*Return the name of the segment which is the parent of this marker.*

*See also:* GetMarkerCount, GetMarkerName, GetMarkerGlobalTranslation

Input	Subject Name	string	The name of the subject
	Marker Name	string	The name of the marker.
Output	Result	Result	Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidMarkerName
	Segment Name	string	The name of the parent segment.
C++	<pre>// class Output_GetMarkerParentName // { // public: //     Result::Enum Result; //     String      SegmentName; // }; // Output_GetMarkerParentName GetMarkerParentName( //     const String      &amp; SubjectName, //     const String      &amp; MarkerName ) const;  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost" ); MyClient.EnableMarkerData(); MyClient.GetFrame();  Output_GetMarkerParentName Output; Output = MyClient.GetMarkerParentName("Bob", "LFHD" ); // Output.Result == Success // Output.SegmentName == "Head"</pre>		
MATLAB	<pre>% [Output] = GetMarkerParentName( SubjectName, MarkerName )  MyClient = Client(); MyClient.Connect("localhost" ); MyClient.EnableMarkerData(); MyClient.GetFrame();  Output = MyClient.GetMarkerParentName("Bob", "LFHD" ); // Output.Result == Success // Output.SegmentName == "Head"</pre>		
.NET	<pre>// public class Output_GetMarkerParentName // { //     public Result Result; //     public string SegmentName; // }; // Output_GetMarkerParentName GetMarkerParentName( string SubjectName, //     string MarkerName );  ViconDataStreamSDK.DotNET.Client MyClient = new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect("localhost" ); MyClient.EnableMarkerData(); MyClient.GetFrame();  Output_GetMarkerParentName Output; Output = MyClient.GetMarkerParentName("Bob", "LFHD" ); // Output.Result == Success // Output.SegmentName == "Head"</pre>		

## GetMarkerGlobalTranslation

*Return the translation of a subject marker in global co-ordinates.*

*The Translation is of the form (x, y, z) where x, y & z are in Millimeters with respect to the global origin.*

*See also:* [GetMarkerName](#)

<b>Input</b>	Subject Name	string	The name of the subject
	Marker Name	string	The name of the marker.
<b>Output</b>	Result	Result	Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidMarkerName
	Translation	double[3]	The translation of the marker
	Occluded	boolean	True if the marker was present at this frame. If false, then Translation will be [0,0,0]
C++	<pre>// class Output_GetMarkerGlobalTranslation // { // public: //     Result::Enum Result; //     double      Translation[ 3 ]; //     bool        Occluded; // }; // // Output_GetMarkerGlobalTranslation GetMarkerGlobalTranslation( //     const String &amp; SubjectName, //     const String &amp; MarkerName ) const;  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); MyClient.EnableMarkerData(); MyClient.GetFrame();  Output_GetMarkerGlobalTranslation Output =     MyClient.GetMarkerGlobalTranslation( "Alice", "LASI" );</pre>		
MATLAB	<pre>% [Output] = GetMarkerGlobalTranslation( SubjectName, MarkerName )  MyClient = Client(); MyClient.Connect( "localhost" ); MyClient.EnableMarkerData(); MyClient.GetFrame();  Output = MyClient.GetMarkerGlobalTranslation( "Alice", "LASI" );</pre>		
.NET	<pre>// public class Output_GetMarkerGlobalTranslation // { //     public Result  Result; //     public double[] Translation[]; //     public bool    Occluded; // }; // // Output_GetMarkerGlobalTranslation //     GetMarkerGlobalTranslation( string SubjectName, //                                 string MarkerName );  ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client();</pre>		

---

[About the SDK](#)[SDK Functions Listing:](#)  
[GetMarkerGlobalTranslation](#)[Appendix A: What's New](#)

---

```
MyClient.Connect( "localhost" );
MyClient.EnableMarkerData();
MyClient.GetFrame();

Output_GetMarkerGlobalTranslation Output =
    MyClient.GetMarkerGlobalTranslation( "Alice", "LASI" );
```

## GetUnlabeledMarkerCount

*Return the number of unlabeled markers in the data stream. This information can be used in conjunction with GetUnlabeledMarkerGlobalTranslation*

*See also:* [GetUnlabeledMarkerGlobalTranslation](#)

Input			
Output	Result	Result	Result.Success Result.NotConnected Result.NoFrame
	MarkerCount	unsigned integer	The number of markers
C++	<pre>// class Output_GetUnlabeledMarkerCount // { // public: //     Result::Enum Result; //     unsigned int MarkerCount; // }; // // Output_GetUnlabeledMarkerCount GetUnlabeledMarkerCount() const;  ViconDataStreamSDK::CPP::Client MyClient; MyClient.EnableUnlabeledMarkerData(); MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output_GetUnlabeledMarkerCount Output =     MyClient.GetUnlabeledMarkerCount(); // Output.Result == Success  // Output.MarkerCount &gt;= 0</pre>		
MATLAB	<pre>% [Output] = GetUnlabeledMarkerCount();  MyClient = Client(); MyClient.EnableUnlabeledMarkerData(); MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output = MyClient.GetUnlabeledMarkerCount(); // Output.Result == Success  // Output.MarkerCount &gt;= 0</pre>		
.NET	<pre>// public class Output_GetUnlabeledMarkerCount // { //     public Result Result; //     public uint MarkerCount; // }; // // Output_GetUnlabeledMarkerCount GetUnlabeledMarkerCount();  ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); MyClient.EnableUnlabeledMarkerData(); MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output_GetUnlabeledMarkerCount Output =     MyClient.GetUnlabeledMarkerCount(); // Output.Result == Success  // Output.MarkerCount &gt;= 0</pre>		

**GetUnlabeledMarkerGlobalTranslation**

*Return the translation of an unlabeled marker in global co-ordinates.*

*The Translation is of the form (x, y, z) where x, y & z are in Millimeters with respect to the global origin.*

*See also:* [GetUnlabeledMarkerCount](#)

Input	Marker Index	unsigned integer	The index of the marker.
Output	Result	Result	Result.Success Result.NotConnected Result.NoFrame Result.InvalidIndex
	Translation	double[3]	The translation of the marker
C++	<b>A valid Marker Index is between 0 and GetUnlabeledMarkerCount()-1</b> <pre>// class Output_GetUnlabeledMarkerGlobalTranslation // { // public: //     Result::Enum Result; //     double      Translation[ 3 ]; // }; // Output_GetUnlabeledMarkerGlobalTranslation //     GetUnlabeledMarkerGlobalTranslation( //         const unsigned int MarkerIndex ) const;  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); MyClient.EnableUnlabeledMarkerData(); MyClient.GetFrame();  Output_GetUnlabeledMarkerGlobalTranslation Output =     MyClient.GetUnlabeledMarkerGlobalTranslation( 0 );</pre>		
MATLAB	<b>A valid Marker Index is between 1 and GetUnlabeledMarkerCount()</b> <pre>% [Output] = GetUnlabeledMarkerGlobalTranslation( MarkerIndex )  MyClient = Client(); MyClient.Connect( "localhost" ); MyClient.EnableUnlabeledMarkerData(); MyClient.GetFrame();  Output = MyClient.GetUnlabeledMarkerGlobalTranslation( 1 );</pre>		
.NET	<b>A valid Marker Index is between 0 and GetUnlabeledMarkerCount()-1</b> <pre>// public class Output_GetUnlabeledMarkerGlobalTranslation // { //     public Result   Result; //     public double[] Translation; // }; // Output_GetUnlabeledMarkerGlobalTranslation //     GetUnlabeledMarkerGlobalTranslation( uint MarkerIndex ) const;  ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect( "localhost" ); MyClient.EnableUnlabeledMarkerData(); MyClient.GetFrame();  Output_GetUnlabeledMarkerGlobalTranslation Output =     MyClient.GetUnlabeledMarkerGlobalTranslation( 0 );</pre>		

## GetDeviceCount

*Return the number of ForcePlates, EMGs, and other devices in the DataStream. This information can be used in conjunction with GetDeviceName*

*See also:* [GetDeviceName](#)

Input			
Output	Result	Result	Result.Success Result.NotConnected Result.NoFrame
	Device Count	unsigned integer	The number of devices
C++	<pre>// class Output_GetDeviceCount // { // public: //     Result::Enum Result; //     unsigned int DeviceCount; // }; // // Output_GetDeviceCount GetDeviceCount() const;  ViconDataStreamSDK::CPP::Client MyClient; MyClient.EnableDeviceData(); MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output_GetDeviceCount Output = MyClient.GetDeviceCount(); // Output.Result == Success // Output.DeviceCount &gt;= 0</pre>		
MATLAB	<pre>% [Output] = GetDeviceCount()  MyClient = Client(); MyClient.EnableDeviceData(); MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output = MyClient.GetDeviceCount(); // Output.Result == Success // Output.DeviceCount &gt;= 0</pre>		
.NET	<pre>// public class Output_GetDeviceCount // { //     public Result Result; //     public uint DeviceCount; // }; // // Output_GetDeviceCount GetDeviceCount();  ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); MyClient.EnableDeviceData(); MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output_GetDeviceCount Output = MyClient.GetDeviceCount(); // Output.Result == Success // Output.DeviceCount &gt;= 0</pre>		

## GetDeviceName

*Return the name and type of a device. This name can be passed into device functions.*

*See also:* GetDeviceCount, GetDeviceOutputCount, GetDeviceOutputValue

Input	Device Index	unsigned integer	The index of the device.
Output	Result	Result	Result.Success Result.NotConnected Result.NoFrame Result.InvalidIndex
	Device Name	string	The name of the device
	Device Type	DeviceType	Unknown ForcePlate
C++	<b>A valid Device Index is between 0 and GetDeviceCount()-1</b> <pre>// class Output_GetDeviceName // { // public: //     Result::Enum      Result; //     String           DeviceName; //     DeviceType::Enum DeviceType; // }; // // Output_GetDeviceName //     GetDeviceName( const unsigned int DeviceIndex ) const;  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); MyClient.EnableDeviceData(); MyClient.GetFrame();  Output_GetDeviceCount OutputGDC; OutputGDC = MyClient.GetDeviceCount( DeviceCount ); // OutputGDC.Result == Success // OutputGDC.DeviceCount == 2  Output_GetDeviceName OutputGDN; OutputGDN = MyClient.GetDeviceName( 0 ); // OutputGDN.Result == Success // OutputGDN.DeviceName == "ZeroWire" // OutputGDN.DeviceType == Unknown  OutputGDN = MyClient.GetDeviceName( 1 ); // OutputGDN.Result == Success // OutputGDN.DeviceName == "AMTI #1" // OutputGDN.DeviceType == ForcePlate  OutputGDN = MyClient.GetDeviceName( 2 ); // OutputGDN.Result == InvalidIndex // OutputGDN.DeviceName == "" // OutputGDN.DeviceType == Unknown</pre>		
MATLAB	<b>A valid Device Index is between 1 and GetDeviceCount()</b> <pre>% [Output] = GetDeviceName( DeviceIndex )  MyClient = Client(); MyClient.Connect( "localhost" ); MyClient.EnableDeviceData(); MyClient.GetFrame();  OutputGDC = MyClient.GetDeviceCount( DeviceCount );</pre>		

	<pre>% OutputGDC.Result == Success % OutputGDC.DeviceCount == 2  OutputGDN = MyClient.GetDeviceName( 1 ); % OutputGDN.Result == Success % OutputGDN.DeviceName == "ZeroWire" % OutputGDN.DeviceType == Unknown  OutputGDN = MyClient.GetDeviceName( 2 ); % OutputGDN.Result == Success % OutputGDN.DeviceName == "AMTI #1" % OutputGDN.DeviceType == ForcePlate  OutputGDN = MyClient.GetDeviceName( 3 ); % OutputGDN.Result == InvalidIndex % OutputGDN.DeviceName == "" % OutputGDN.DeviceType == Unknown</pre>
.NET	<p>A valid Device Index is between 0 and GetDeviceCount()-1</p> <pre>// public class Output_GetDeviceName // { //     public Result      Result; //     public string      DeviceName; //     public DeviceType  DeviceType; // }; // // Output_GetDeviceName //     GetDeviceName( uint DeviceIndex );  ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect( "localhost" ); MyClient.EnableDeviceData(); MyClient.GetFrame();  Output_GetDeviceCount OutputGDC; OutputGDC = MyClient.GetDeviceCount( DeviceCount ); // OutputGDC.Result == Success // OutputGDC.DeviceCount == 2  Output_GetDeviceName OutputGDN; OutputGDN = MyClient.GetDeviceName( 0 ); // OutputGDN.Result == Success // OutputGDN.DeviceName == "ZeroWire" // OutputGDN.DeviceType == Unknown  OutputGDN = MyClient.GetDeviceName( 1 ); // OutputGDN.Result == Success // OutputGDN.DeviceName == "AMTI #1" // OutputGDN.DeviceType == ForcePlate  OutputGDN = MyClient.GetDeviceName( 2 ); // OutputGDN.Result == InvalidIndex // OutputGDN.DeviceName == "" // OutputGDN.DeviceType == Unknown</pre>

## GetDeviceOutputCount

*Return the number of outputs for a device in the data stream. This information can be used in conjunction with GetDeviceOutputName*

*See also:* [GetDeviceName](#), [GetDeviceOutputName](#)

Input	Device Name	string	The device name
Output	Result	Result	Result.Success Result.NotConnected Result.NoFrame Result.InvalidDeviceName
	Device Output Count	unsigned integer	The number of device outputs
C++	<pre>// class Output_GetDeviceOutputCount //{ // public: //     Result::Enum Result; //     unsigned int DeviceOutputCount; // }; // // Output_GetDeviceOutputCount GetDeviceOutputCount( //     const String &amp; DeviceName ) const;  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); MyClient.EnableDeviceData(); MyClient.GetFrame();  Output_GetDeviceOutputCount Output; Output = MyClient.GetDeviceOutputCount( "DataGlove" ); // Output.Result == InvalidDeviceName // Output.DeviceOutputCount == 0 // (no "DataGlove" device)  Output = MyClient.GetDeviceOutputCount( "ZeroWire" ); // Output.Result == Success // Output.DeviceOutputCount == 6</pre>		
MATLAB	<pre>% [Output] = GetDeviceOutputCount( DeviceName )  MyClient = Client(); MyClient.Connect( "localhost" ); MyClient.EnableDeviceData(); MyClient.GetFrame();  Output = MyClient.GetDeviceOutputCount( "DataGlove" ); // Output.Result == InvalidDeviceName // Output.DeviceOutputCount == 0 // (no "DataGlove" device)  Output = MyClient.GetDeviceOutputCount( "ZeroWire" ); // Output.Result == Success // Output.DeviceOutputCount == 6</pre>		
.NET	<pre>// public class Output_GetDeviceOutputCount //{ //     public Result Result; //     public uint DeviceOutputCount; // }; // // Output_GetDeviceOutputCount GetDeviceOutputCount( string DeviceName );  ViconDataStreamSDK.DotNET.Client MyClient =</pre>		

```
new ViconDataStreamSDK.DotNET.Client();  
MyClient.Connect( "localhost" );  
MyClient.EnableDeviceData();  
MyClient.GetFrame();  
  
Output_GetDeviceOutputCount Output;  
Output = MyClient.GetDeviceOutputCount( "DataGlove" );  
// Output.Result == InvalidDeviceName  
// Output.DeviceOutputCount == 0  
// (no "DataGlove" device)  
  
Output = MyClient.GetDeviceOutputCount( "ZeroWire" );  
// Output.Result == Success  
// Output.DeviceOutputCount == 6
```

## GetDeviceOutputName

*Return the name and SI unit of a device output. This name can be passed into GetDeviceOutputValue.*

*See also:* GetDeviceCount, GetDeviceOutputCount, GetDeviceOutputValue

Input	Device Name	string	The device name
	Device Output Index	integer	The index of the device output.
Output	Result	Result	Result.Success Result.NotConnected Result.NoFrame Result.InvalidDeviceName Result.InvalidIndex
	Device Output Name	string	The name of the device output, e.g. "Fx" - Force X "Fy" - Force Y "Fz" - Force Z "Mx" - Moment X "My" - Moment Y "Mz" - Moment Z "Cx" - Centre Of Pressure X "Cy" - Centre Of Pressure Y "Cz" - Centre Of Pressure Z "Pin1" - Analog Input 1 "Pin2" - Analog Input 2
	Device Output Unit	Unit	The unit of the device output.  Unit.Unknown Unit.Volt Unit.Newton Unit.NewtonMeter Unit.Meter Unit.Kilogram Unit.Second Unit.Ampere Unit.Kelvin Unit.Mole Unit.Candela Unit.Radian Unit.Steradian Unit.MeterSquared Unit.MeterCubed Unit.MeterPerSecond Unit.MeterPerSecondSquared Unit.RadianPerSecond Unit.RadianPerSecondSquared Unit.Hertz Unit.Joule Unit.Watt Unit.Pascal Unit.Lumen Unit.Lux Unit.Coulomb Unit.Ohm Unit.Farad Unit.Weber Unit.Tesla Unit.Henry

			Unit.Siemens Unit.Becquerel Unit.Gray Unit.Sievert Unit.Katal
C++	<p><b>A valid Device Output Index is between 0 and GetDeviceOutputCount()-1</b></p> <pre>// class Output_GetDeviceOutputName // { // public: //     Result::Enum Result; //     String      DeviceOutputName; //     Unit::Enum   DeviceOutputUnit; // }; // // Output_GetDeviceOutputName GetDeviceOutputName( //     const String      &amp; DeviceName, //     const unsigned int DeviceOutputIndex ) const;  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); MyClient.EnableDeviceData(); MyClient.GetFrame();  Output_GetDeviceOutputName Output =     MyClient.GetDeviceOutputName( "AMTI", 0 );     // Output.Result == Success     // Output.DeviceOutputName == "Fx"     // Output.DeviceOutputUnit == Newton</pre>		
MATLAB	<p><b>A valid Device Output Index is between 1 and GetDeviceOutputCount()</b></p> <pre>% [Output] = GetDeviceOutputName( DeviceName, DeviceOutputIndex )  MyClient = Client(); MyClient.Connect( "localhost" ); MyClient.EnableDeviceData(); MyClient.GetFrame();  Output = MyClient.GetDeviceOutputName( "AMTI", 0 );     % Output.Result == Success     % Output.DeviceOutputName == "Fx"     % Output.DeviceOutputUnit == Newton</pre>		
.NET	<p><b>A valid Device Output Index is between 0 and GetDeviceOutputCount()-1</b></p> <pre>// public class Output_GetDeviceOutputName // { //     public Result Result; //     public string DeviceOutputName; //     public Unit   DeviceOutputUnit; // }; // // Output_GetDeviceOutputName GetDeviceOutputName( //     string DeviceName, //     uint   DeviceOutputIndex );  ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect( "localhost" ); MyClient.EnableDeviceData(); MyClient.GetFrame();  Output_GetDeviceOutputName Output =     MyClient.GetDeviceOutputName( "AMTI", 0 );     // Output.Result == Success     // Output.DeviceOutputName == "Fx"     // Output.DeviceOutputUnit == Newton</pre>		

## GetDeviceOutputValue

*Return the value of a device output. If there are multiple samples for a frame, then the first sample is returned.*

*The force plate data provided in the individual device channels is in a coordinate system local to the plate aligned Z upwards, Y towards the front of the plate. This coordinate system is located at the center of the top surface of the plate. Any plate origin offset has been accounted for in the moment data. These are forces not reactions.*

*See also:* GetDeviceCount, GetDeviceOutputCount, GetDeviceOutputName

Input	Device Name	string	The device name
	Device Output Name	string	The name of the device output.
Output	Result	Result	Result.Success Result.NotConnected Result.NoFrame Result.InvalidDeviceName Result.InvalidDeviceOutputName
	Value	double	The value of the device output
	Occluded	boolean	True if the value was present at this frame. If false, then Value will be 0.
C++	<pre>// class Output_GetDeviceOutputValue // { // public: //     Result::Enum Result; //     double      Value; //     bool        Occluded; // }; // // Output_GetDeviceOutputValue //     GetDeviceOutputValue( //         const String &amp; DeviceName, //         const String &amp; DeviceOutputName ) const;  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); MyClient.EnableDeviceData(); MyClient.GetFrame();  Output_GetDeviceOutputValue Output =     MyClient.GetDeviceOutputValue( "AMTI", "Fx" ); // Output.Result == Success // Output.Value == ? // Output.Occluded = ?</pre>		
MATLAB	<pre>// [Output] = GetDeviceOutputValue( DeviceName, DeviceOutputName )  MyClient = Client(); MyClient.Connect( "localhost" ); MyClient.EnableDeviceData(); MyClient.GetFrame();  Output = MyClient.GetDeviceOutputValue( "AMTI", "Fx" ); // Output.Result == Success // Output.Value == ? // Output.Occluded = ?</pre>		

[About the SDK](#)SDK Functions Listing:  
[GetDeviceOutputValue](#)[Appendix A: What's New](#)**.NET**

```
// public class Output_GetDeviceOutputValue
// {
//     public Result Result;
//     public double Value;
//     public bool Occluded;
// }
//
// Output_GetDeviceOutputValue
//     GetDeviceOutputValue( string DeviceName,
//                         string DeviceOutputName );
//
ViconDataStreamSDK.DotNET.Client MyClient =
    new ViconDataStreamSDK.DotNET.Client();
MyClient.Connect( "localhost" );
MyClient.EnableDeviceData();
MyClient.GetFrame();

Output_GetDeviceOutputValue Output =
    MyClient.GetDeviceOutputValue( "AMTI", "Fx" );
// Output.Result == Success
// Output.Value == ?
// Output.Occluded = ?
```

## GetDeviceOutputSubsamples

*Return the number of samples available the specified device for the current frame. If an analog device is sampling at 1000 Hz and the system is running at 100 Hz then this function will return 10.*

*The samples can accessed by supplying the subsample index to GetDeviceOutputValue. See below.*

*See also:* GetDeviceOutputCount, GetDeviceOutputValue

Input	Device Name	string	The device name
	Device Output Name	string	The name of the device output.
Output	Result	Result	Result.Success Result.NotConnected Result.NoFrame Result.InvalidIndex Result.InvalidDeviceName Result.InvalidDeviceOutputName
	DeviceOutputSubsamples	Uint	The number of subsamples for this device output.
	Occluded	boolean	True if the value was present at this frame. If false, then Value will be 0.
C++	<pre>// class Output_GetDeviceOutputSubsamples // { // public: //     Result::Enum Result; //     unsigned int DeviceOutputSubsamples; //     bool Occluded; // }; // // Output_GetDeviceOutputSubsamples GetDeviceOutputSubsamples( const String &amp; DeviceName, //   const String &amp; DeviceOutputName ) const;  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); MyClient.EnableDeviceData(); MyClient.GetFrame();  Output_GetDeviceOutputSubsamples Output =     MyClient. GetDeviceOutputSubsamples ( "AMTI", "Fx" );</pre>		
MATLAB	<pre>// [Output] = GetDeviceOutputSubsamples( DeviceName, DeviceOutputName )  MyClient = Client(); MyClient.Connect( "localhost" ); MyClient.EnableDeviceData(); MyClient.GetFrame();  Output = MyClient. GetDeviceOutputSubsamples ( "AMTI", "Fx" ); // Output.Result == Success // Output. DeviceOutputSubsamples == ? // Output.Occluded = ?</pre>		
.NET	<pre>// public class Output_GetDeviceOutputSubsamples // { //     public Result Result; //     unsigned int DeviceOutputSubsamples; //     public bool Occluded; // };</pre>		

[About the SDK](#)SDK Functions Listing:  
[GetDeviceOutputSubsamples](#)[Appendix A: What's New](#)

```
//  
// Output_GetDeviceOutputSubsamples^ GetDeviceOutputSubsamples( String^  
DeviceName,  
//  
//                                         String^ DeviceOutputName )  
  
ViconDataStreamSDK.DotNET.Client MyClient =  
    new ViconDataStreamSDK.DotNET.Client();  
MyClient.Connect( "localhost" );  
MyClient.EnableDeviceData();  
MyClient.GetFrame();  
  
Output_GetDeviceOutputSubsamples Output =  
    MyClient.GetDeviceOutputSubsamples( "AMTI", "Fx" );  
    // Output.Result == Success  
    // Output.DeviceOutputSubsamples == ?  
    // Output.Occluded = ?
```

## GetDeviceOutputValue<sub>2</sub>

*Return the value of a device output. This override allows access to the individual subsamples for the current frame of data. See GetDeviceOutputValue for information about the meaning of the force plate channels.*

*See also:* [GetDeviceOutputSubsamples](#), [GetDeviceOutputValue](#)

Input	Device Name	string	The device name
	Device Output Name	string	The name of the device output.
	Subsample	unsigned int	The subsample to access.
Output	Result	Result	Result.Success Result.NotConnected Result.NoFrame Result.InvalidIndex Result.InvalidDeviceName Result.InvalidDeviceOutputName
	Value	double	The value of the device output
	Occluded	boolean	True if the value was present at this frame. If false, then Value will be 0.
C++	<pre>// class Output_GetDeviceOutputValue // { // public: //   Result::Enum Result; //   double      Value; //   bool        Occluded; // }; // // Output_GetDeviceOutputValue //   GetDeviceOutputValue( //     const String &amp; DeviceName, //     const String &amp; DeviceOutputName ) const;  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); MyClient.EnableDeviceData(); MyClient.GetFrame();  Output_GetDeviceOutputValue Output =   MyClient.GetDeviceOutputValue( "AMTI", "Fx", 6 );   // Output.Result == Success   // Output.Value == ?   // Output.Occluded = ?</pre>		
MATLAB	<pre>// [Output] = GetDeviceOutputValue( DeviceName, DeviceOutputName )  MyClient = Client(); MyClient.Connect( "localhost" ); MyClient.EnableDeviceData(); MyClient.GetFrame();  Output = MyClient.GetDeviceOutputValue( "AMTI", "Fx", 6 );   // Output.Result == Success   // Output.Value == ?   // Output.Occluded = ?</pre>		
.NET	<pre>// public class Output_GetDeviceOutputValue // { //   public Result Result; //   public double Value; //   public bool   Occluded;</pre>		

[About the SDK](#)**SDK Functions Listing:  
GetDeviceOutputValue2**[Appendix A: What's New](#)

```
// };
// 
// Output_GetDeviceOutputValue
//     GetDeviceOutputValue( string DeviceName,
//                           string DeviceOutputName );
// 
ViconDataStreamSDK.DotNET.Client MyClient =
    new ViconDataStreamSDK.DotNET.Client();
MyClient.Connect( "localhost" );
MyClient.EnableDeviceData();
MyClient.GetFrame();

Output_GetDeviceOutputValue Output =
    MyClient.GetDeviceOutputValue( "AMTI", "Fx", 6 );
    // Output.Result == Success
    // Output.Value == ?
    // Output.Occluded = ?
```

## GetForcePlateCount

*Return the number of ForcePlates available in the DataStream.*

*See also:* [GetGlobalForceVector](#), [GetGlobalMomentVector](#), [GetGlobalCentreOfPressure](#)

<b>Input</b>			
<b>Output</b>	<b>Result</b>	<b>Result</b>	<code>Result.Success</code> <code>Result.NotConnected</code> <code>Result.NoFrame</code>
	<b>Force Plate Count</b>	unsigned integer	<b>The number of force plates</b>
<b>C++</b>	<pre>// class Output_GetForcePlateCount // { // public: //     Result::Enum Result; //     unsigned int ForcePlateCount; // }; // // Output_GetForcePlateCount GetForcePlateCount() const;  ViconDataStreamSDK::CPP::Client MyClient; MyClient.EnableDeviceData(); MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output_GetForcePlateCount Output = MyClient. GetForcePlateCount (); // Output.Result == Success // Output.ForcePlateCount &gt;= 0</pre>		
<b>MATLAB</b>	<pre>% [Output] = GetForcePlateCount()  MyClient = Client(); MyClient.EnableDeviceData(); MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output = MyClient.GetForcePlateCount(); // Output.Result == Success // Output.ForcePlateCount &gt;= 0</pre>		
<b>.NET</b>	<pre>// public class Output_GetForcePlateCount // { //     public Result Result; //     public uint ForcePlateCount; // }; // // Output_GetForcePlateCount GetForcePlateCount();  ViconDataStreamSDK.DotNET.Client MyClient =     new ViconDataStreamSDK.DotNET.Client(); MyClient.EnableDeviceData(); MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output_GetForcePlateCount Output = MyClient.GetForcePlateCount(); // Output.Result == Success // Output.ForcePlateCount &gt;= 0</pre>		

## GetGlobalForceVector

*Return the force vector for the plate in global co-ordinates.*

*The vector is in Newtons and is with respect to the global coordinate system regardless of the orientation of the plate. The vector represents the force exerted upon the plate, not the reaction force.*

*If multiple sub-samples are available this function returns the first subsample. See the alternate version of this function to access all of the analog data.*

*See also:* [GetGlobalMomentVector](#), [GetGlobalCentreOfPressure](#)

Input	Force Plate Index	unsigned integer	The index of the plate
Output	Result	Result	Result.Success Result.NotConnected Result.NoFrame Result.InvalidIndex
	ForceVector	double[3]	The force on the plate
C++	<p>A valid ForcePlateIndex is between 0 and GetForcePlateCount()-1</p> <pre>// class Output_GetGlobalForceVector // { // public: //     Result::Enum Result; //     double      ForceVector[ 3 ]; // }; // Output_GetGlobalForceVector // GetGlobalForceVector ( //     const unsigned int ForcePlateIndex ) const;  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); MyClient.EnableDeviceData(); MyClient.GetFrame();  Output_GetGlobalForceVector Output = MyClient.GetGlobalForceVector( 0 );</pre>		
MATLAB	<p>A valid ForcePlateIndex is between 1 and GetForcePlateCount()</p> <pre>% [Output] = GetGlobalForceVector( ForcePlateIndex )  MyClient = Client(); MyClient.Connect( "localhost" ); MyClient.EnableDeviceData(); MyClient.GetFrame();  Output = MyClient. GetGlobalForceVector( 1 );</pre>		
.NET	<p>A valid ForcePlateIndex is between 0 and GetForcePlateCount() - 1</p> <pre>// public ref class Output_GetGlobalForceVector // { // public: //     Result          Result; //     array&lt; double &gt;^ ForceVector; // }; // Output_GetGlobalForceVector // GetGlobalForceVector( uint ForcePlateIndex ) const;  ViconDataStreamSDK.DotNET.Client MyClient = new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect( "localhost" ); MyClient.EnableUnlabeledMarkerData(); MyClient.GetFrame();</pre>		

---

[About the SDK](#)[SDK Functions Listing:  
GetGlobalForceVector](#)[Appendix A: What's New](#)

---

	Output_ GetGlobalForceVector Output = MyClient. GetGlobalForceVector( 0 );
--	--

## GetGlobalMomentVector

*Return the moment vector for the plate in global co-ordinates.*

*The vector is in Newton-Meters and is with respect to the global coordinate system regardless of the orientation of the plate.*

*The vector represents the moment exerted upon the plate, not the reaction moment. Any force plate origin offset is accounted for in the moments so they are acting about the exact centre of the top surface of the plate.*

*If multiple sub-samples are available this function returns the first subsample. See the alternate version of this function to access all of the analog data.*

*See also:* [GetGlobalForceVector](#), [GetGlobalCentreOfPressure](#)

Input	Plate Index	unsigned integer	The index of the force plate
Output	Result	Result	Result.Success Result.NotConnected Result.NoFrame Result.InvalidIndex
	MomentVector	double[3]	The moment exerted on the plate
C++	A valid ForcePlateIndex is between 0 and GetForcePlateCount()-1 <pre>// class Output_GetGlobalMomentVector // { // public: //   Result::Enum Result; //   double      MomentVector[ 3 ]; // }; // // Output_GetGlobalMomentVector GetGlobalMomentVector ( //   const unsigned int ForcePlateIndex ) const;  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); MyClient.EnableDeviceData(); MyClient.GetFrame();  Output_GetGlobalMomentVector Output = MyClient.GetGlobalMomentVector( 0 );</pre>		
MATLAB	A valid ForcePlateIndex is between 1 and GetForcePlateCount() <pre>% [Output] = GetGlobalMomentVector( ForcePlateIndex )  MyClient = Client(); MyClient.Connect( "localhost" ); MyClient.EnableDeviceData(); MyClient.GetFrame();  Output = MyClient.GetGlobalMomentVector( 1 );</pre>		
.NET	A valid ForcePlateIndex is between 0 and GetForcePlateCount() - 1 <pre>// public ref class Output_GetGlobalMomentVector // { // public: //   Result      Result; //   array&lt; double &gt;^ MomentVector; // }; // Output_GetGlobalMomentVector // GetGlobalMomentVector( uint ForcePlateIndex ) const;  ViconDataStreamSDK.DotNET.Client MyClient = new</pre>		

---

[About the SDK](#)[SDK Functions Listing:](#)  
[GetGlobalMomentVector](#)[Appendix A: What's New](#)

---

```
ViconDataStreamSDK.DotNET.Client();
MyClient.Connect( "localhost" );
MyClient. EnableDeviceData ();
MyClient.GetFrame();

Output_ GetGlobalMomentVector Output = MyClient.GetGlobalMomentVector( 0 );
```

## GetGlobalCentreOfPressure

*Return the centre of pressure for the plate in global co-ordinates.*

*The position is in millimeters and is with respect to the global coordinate system.*

*If multiple sub-samples are available this function returns the first subsample. See the alternate version of this function to access all of the analog data.*

*See also:* [GetGlobalForceVector](#), [GetGlobalMomentVector](#)

Input	Plate Index	unsigned integer	The index of the force plate
Output	Result	Result	Result.Success Result.NotConnected Result.NoFrame Result.InvalidIndex
	CentreOfPressure	double[3]	The CoP.
C++	A valid ForcePlateIndex is between 0 and GetForcePlateCount()-1 <pre>// class Output_GetGlobalCentreOfPressure // { // public: //   Result::Enum Result; //   double      CentreOfPressure[ 3 ]; // }; // // Output_GetGlobalCentreOfPressure // GetGlobalCentreOfPressure ( //   const unsigned int ForcePlateIndex ) const;  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); MyClient.EnableDeviceData(); MyClient.GetFrame();  Output_GetGlobalCentreOfPressure Output = MyClient.GetGlobalCentreOfPressure( 0 );</pre>		
MATLAB	A valid ForcePlateIndex is between 1 and GetForcePlateCount() <pre>% [Output] = GetGlobalCentreOfPressure( ForcePlateIndex )  MyClient = Client(); MyClient.Connect( "localhost" ); MyClient.EnableDeviceData(); MyClient.GetFrame();  Output = MyClient.GetGlobalCentreOfPressure( 1 );</pre>		
.NET	A valid ForcePlateIndex is between 0 and GetForcePlateCount() - 1 <pre>// public class Output_GetGlobalCentreOfPressure // { // public: //   Result      Result; //   array&lt; double &gt;^ CentreOfPressure; // }; // // Output_GetGlobalCentreOfPressure // GetGlobalCentreOfPressure( uint ForcePlateIndex ) const;  ViconDataStreamSDK.DotNET.Client MyClient = new ViconDataStreamSDK.DotNET.Client();</pre>		

[About the SDK](#)SDK Functions Listing:  
**GetGlobalCentreOfPressure**[Appendix A: What's New](#)

```
MyClient.Connect( "localhost" );
MyClient. EnableDeviceData ();
MyClient. GetFrame();

Output_ GetGlobalCentreOfPressure Output =
MyClient. GetGlobalCentreOfPressure( 0 );
```

## GetForcePlateSubsamples

*Return the number of subsamples available for a specified plate in the current frame. Additional versions of GetGlobalForceVector, GetGlobalMomentVector GetGlobalCentreOfPressure take the subsample index to allow access of all the force plate data.*

*See also:* GetGlobalForceVector, GetGlobalMomentVector, GetGlobalCentreOfPressure

Input	Plate Index	unsigned integer	The index of the force plate
Output	Result	Result	Result.Success Result.NotConnected Result.NoFrame Result.InvalidIndex
	ForcePlateSubsamples	unsigned integer	The number of subsamples.
C++	A valid ForcePlateIndex is between 0 and GetForcePlateCount()-1 <pre>// class Output_GetForcePlateSubsamples // { // public: //   Result::Enum Result; //   unsigned int ForcePlateSubsamples; // }; // // Output_GetForcePlateSubsamples //   GetForcePlateSubsamples( const unsigned int ForcePlateIndex ) const;  ViconDataStreamSDK::CPP::Client MyClient; MyClient.EnableDeviceData(); MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output_GetForcePlateSubsamples Output = MyClient.GetForcePlateSubsamples( 0 ); // Output.Result == Success // Output.ForcePlateSubsamples &gt;= 0</pre>		
MATLAB	A valid ForcePlateIndex is between 1 and GetForcePlateCount() <pre>% [Output] = GetForcePlateSubsamples()  MyClient = Client(); MyClient.EnableDeviceData(); MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output = MyClient. GetForcePlateSubsamples( 1 ); // Output.Result == Success // Output. ForcePlateSubsamples &gt;= 0</pre>		
.NET	A valid ForcePlateIndex is between 0 and GetForcePlateCount()-1 <pre>// public class Output_GetForcePlateSubsamples // { //   public Result Result; //   public uint ForcePlateSubsamples; // }; // // Output_GetForcePlateCount GetForcePlateSubsamples( unsigned int // ForcePlateIndex );  ViconDataStreamSDK.DotNET.Client MyClient =   new ViconDataStreamSDK.DotNET.Client(); MyClient.EnableDeviceData(); MyClient.Connect( "localhost" );</pre>		

---

[About the SDK](#)[SDK Functions Listing:](#)  
[GetForcePlateSubsamples](#)[Appendix A: What's New](#)

---

```
MyClient.GetFrame();  
  
Output_GetForcePlateSubsamples Output = MyClient. GetForcePlateSubsamples ( 0 );  
                                         // Output.Result == Success  
                                         // Output. ForcePlateSubsamples >= 0
```

**GetGlobalForceVector<sub>2</sub>**

*Return the force vector for the plate in global co-ordinates. This version takes a subsample index that allows access to all of the force information.*

*The vector is in Newtons and is with respect to the global coordinate system regardless of the orientation of the plate. The vector represents the force exerted upon the plate, not the reaction force.*

*See also:* GetGlobalMomentVector, GetGlobalCentreOfPressure

Input	Force Plate Index	unsigned integer	The index of the plate
	Subsample	unsigned integer	The subsample to access
Output	Result	Result	Result.Success Result.NotConnected Result.NoFrame Result.InvalidIndex
	ForceVector	double[3]	The force on the plate
C++	A valid ForcePlateIndex is between 0 and GetForcePlateCount()-1 A valid Subsample is between 0 and GetForcePlateSubsamples()-1 <pre>// class Output_GetGlobalForceVector // { // public: //   Result::Enum Result; //   double      ForceVector[ 3 ]; // } // // Output_GetGlobalForceVector // GetGlobalForceVector ( //   const unsigned int ForcePlateIndex, const unsigned int Subsample ) const;  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); MyClient.EnableDeviceData(); MyClient.GetFrame();  const unsigned int Index(0); const unsigned int Samples = MyClient.GetForcePlateSubsamples( index ).ForcePlateSubsamples; for( unsigned int Sample = 0; Sample &lt; Samples; ++ Sample ) {     Output_GetGlobalForceVector Output = MyClient.GetGlobalForceVector( Index, Sample ); }</pre>		
MATLAB	A valid ForcePlateIndex is between 1 and GetForcePlateCount() A valid Subsample is between 1 and GetForcePlateSubsamples() <pre>% [Output] = GetGlobalForceVector( ForcePlateIndex, Subsample )  MyClient = Client(); MyClient.Connect( "localhost" ); MyClient.EnableDeviceData(); MyClient.GetFrame(); Index = 0; Output_GetForcePlateSubsamples = MyClient.GetForcePlateSubsamples( Index ); for Sample = 1:Output_GetForcePlateSubsamples.ForcePlateSubsamples     Output = MyClient.GetGlobalForceVector( Index, Sample ); end</pre>		

**.NET**

A valid ForcePlateIndex is between 0 and GetForcePlateCount() – 1  
A valid Subsample is between 0 and GetForcePlateSubsamples()-1

```
// public ref class Output_GetGlobalForceVector
// {
//     public:
//         Result             Result;
//         array< double >^ ForceVector;
//     };
//
// Output_GetGlobalForceVector
//     GetGlobalForceVector( uint ForcePlateIndex, uint Subsample ) const;

ViconDataStreamSDK.DotNET.Client MyClient = new
ViconDataStreamSDK.DotNET.Client();
MyClient.Connect( "localhost" );
MyClient.EnableUnlabeledMarkerData();
MyClient.GetFrame();

uint Index = 0;
uint Samples =
MyClient.GetForcePlateSubsamples(ForcePlateIndex).ForcePlateSubsamples;
for (uint Sample = 0; Sample < Samples; ++ Sample)
{
    Output_GetGlobalForceVector Output = MyClient.GetGlobalForceVector( Index,
Sample );
}
```

**GetGlobalMomentVector<sub>2</sub>**

*Return the moment vector for the plate in global co-ordinates. This version takes a subsample index that allows access to all of the force information.*

*The vector is in Newton-Meters and is with respect to the global coordinate system regardless of the orientation of the plate.*

*The vector represents the moment exerted upon the plate, not the reaction moment. Any force plate origin offset is accounted for in the moments so they are acting about the exact centre of the top surface of the plate.*

*See also:* GetGlobalForceVector, GetGlobalCentreOfPressure

<b>Input</b>	<b>Plate Index</b>	unsigned integer	The index of the force plate
	<b>Subsample</b>	unsigned integer	The subsample to access
<b>Output</b>	<b>Result</b>	<b>Result</b>	Result.Success Result.NotConnected Result.NoFrame Result.InvalidIndex
	<b>MomentVector</b>	double[3]	The moment exerted on the plate
<b>C++</b>	A valid ForcePlateIndex is between 0 and GetForcePlateCount()-1 A valid Subsample is between 0 and GetForcePlateSubsamples()-1 <pre>// class Output_GetGlobalMomentVector // { // public: //   Result::Enum Result; //   double      MomentVector[ 3 ]; // }; // // Output_GetGlobalMomentVector GetGlobalMomentVector ( //   const unsigned int ForcePlateIndex, const unsigned int Subsample ) const;  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); MyClient.EnableDeviceData(); MyClient.GetFrame();  const unsigned int Index(0); const unsigned int Samples = MyClient.GetForcePlateSubsamples( index ).ForcePlateSubsamples; for( unsigned int Sample = 0; Sample &lt; Samples; ++ Sample) {   Output_GetGlobalMomentVector Output = MyClient.GetGlobalMomentVector( Index, Sample ); }</pre>		
<b>MATLAB</b>	A valid ForcePlateIndex is between 1 and GetForcePlateCount() A valid Subsample is between 1 and GetForcePlateSubsamples() <pre>% [Output] = GetGlobalMomentVector( ForcePlateIndex, Subsample )  MyClient = Client(); MyClient.Connect( "localhost" ); MyClient.EnableDeviceData(); MyClient.GetFrame();  Index = 0; Output_GetForcePlateSubsamples = MyClient.GetForcePlateSubsamples( Index );</pre>		

	<pre>for Sample = 1:Output_GetForcePlateSubsamples.ForcePlateSubsamples     Output = MyClient.GetGlobalMomentVector( Index, Sample ); end</pre>
.NET	<p>A valid ForcePlateIndex is between 0 and GetForcePlateCount() - 1</p> <p>A valid Subsample is between 0 and GetForcePlateSubsamples()-1</p> <pre>//  public ref class Output_GetGlobalMomentVector //  { //  public: //      Result          Result; //      array&lt; double &gt;^ MomentVector; //  }; //  Output_GetGlobalMomentVector //  GetGlobalMomentVector( uint ForcePlateIndex, uint Subsample ) const;  ViconDataStreamSDK.DotNET.Client MyClient = new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect( "localhost" ); MyClient.EnableDeviceData(); MyClient.GetFrame();  uint Index = 0; uint Samples = MyClient.GetForcePlateSubsamples(ForcePlateIndex).ForcePlateSubsamples; for (uint Sample = 0; Sample &lt; Samples; ++ Sample) {     Output_GetGlobalMomentVector Output = MyClient.GetGlobalMomentVector( Index, Sample ); }</pre>

**GetGlobalCentreOfPressure<sub>2</sub>**

*Return the centre of pressure for the plate in global co-ordinates. This version takes a subsample index that allows access to all of the force information.*

*The position is in millimeters and is with respect to the global coordinate system.*

*See also:* GetGlobalForceVector, GetGlobalMomentVector

Input	Plate Index	unsigned integer	The index of the force plate
	Subsample	unsigned integer	The subsample to access
Output	Result	Result	Result.Success Result.NotConnected Result.NoFrame Result.InvalidIndex
	CentreOfPressure	double[3]	The CoP.
C++	A valid ForcePlateIndex is between 0 and GetForcePlateCount()-1 A valid Subsample is between 0 and GetForcePlateSubsamples()-1 <pre>// class Output_GetGlobalCentreOfPressure // { //   public: //     Result::Enum Result; //     double      CentreOfPressure[ 3 ]; // }; // // Output_GetGlobalCentreOfPressure // GetGlobalCentreOfPressure ( //   const unsigned int ForcePlateIndex, const unsigned int Subsample ) const;  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); MyClient.EnableDeviceData(); MyClient.GetFrame();  const unsigned int Index(0); const unsigned int Samples = MyClient.GetForcePlateSubsamples( index ).ForcePlateSubsamples; for( unsigned int Sample = 0; Sample &lt; Samples; ++ Sample) {   Output_GetGlobalCentreOfPressure Output = MyClient.GetGlobalCentreOfPressure( Index, Sample ); }</pre>		
MATLAB	A valid ForcePlateIndex is between 1 and GetForcePlateCount() A valid Subsample is between 1 and GetForcePlateSubsamples() <pre>% [Output] = GetGlobalCentreOfPressure( ForcePlateIndex, Subsample )  MyClient = Client(); MyClient.Connect( "localhost" ); MyClient.EnableDeviceData(); MyClient.GetFrame();  Index = 0; Output_GetForcePlateSubsamples = MyClient.GetForcePlateSubsamples( Index ); for Sample = 1:Output_GetForcePlateSubsamples.ForcePlateSubsamples   Output = MyClient.GetGlobalCentreOfPressure( Index, Sample ); end</pre>		

**.NET**

A valid ForcePlateIndex is between 0 and GetForcePlateCount() - 1  
A valid Subsample is between 0 and GetForcePlateSubsamples() - 1

```
// public class Output_
// {
//     public:
//         Result           Result;
//         array< double >^ CentreOfPressure;
//     };
//
// Output_GetGlobalCentreOfPressure
//     GetGlobalCentreOfPressure( uint ForcePlateIndex, uint Subsample ) const;

ViconDataStreamSDK.DotNET.Client MyClient = new
ViconDataStreamSDK.DotNET.Client();
MyClient.Connect( "localhost" );
MyClient.EnableDeviceData();
MyClient.GetFrame();

uint Index = 0;
uint Samples =
MyClient.GetForcePlateSubsamples(ForcePlateIndex).ForcePlateSubsamples;
for (uint Sample = 0; Sample < Samples; ++ Sample)
{
    Output_GetGlobalCentreOfPressure Output = MyClient. GetGlobalCentreOfPressure
(Index,Sample);
}
```

## GetEyeTrackerCount

*Return the number of eye trackers available in the DataStream.*

*See also:* [GetEyeTrackerGlobalGazeVector](#), [GetEyeTrackerGlobalPosition](#)

Input			
Output	Result	Result	Result.Success Result.NotConnected Result.NoFrame
	Eye Tracker Count	unsigned integer	The number of eye trackers
C++	// class Output_GetEyeTrackerCount // { // public: //     Result::Enum Result; //     unsigned int EyeTrackerCount; // }; // // Output_GetEyeTrackerCount GetEyeTrackerCount() const;  ViconDataStreamSDK::CPP::Client MyClient; MyClient.EnableDeviceData(); MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output_GetDeviceCount Output = MyClient. GetEyeTrackerCount () ; // Output.Result == Success // Output. EyeTrackerCount >= 0		
MATLAB	% [Output] = GetEyeTrackerCount()  MyClient = Client(); MyClient.EnableDeviceData(); MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output = MyClient.GetEyeTrackerCount(); // Output.Result == Success // Output.EyeTrackerCount >= 0		
.NET	// public class Output_GetEyeTrackerCount // { //     public Result Result; //     public uint EyeTrackerCount; // }; // // Output_GetEyeTrackerCount GetEyeTrackerCount();  ViconDataStreamSDK.DotNET.Client MyClient = new ViconDataStreamSDK.DotNET.Client(); MyClient.EnableDeviceData(); MyClient.Connect( "localhost" ); MyClient.GetFrame();  Output_GetEyeTrackerCount Output = MyClient.GetEyeTrackerCount(); // Output.Result == Success // Output.EyeTrackerCount >= 0		

## GetEyeTrackerGlobalPosition

*Returns the location of the eye. The position is in Millimeters with respect to the global origin. The segment and device data need to be enabled to get the position.*

*See also:* [GetEyeTrackerCount](#), [GetEyeTrackerGlobalGazeVector](#)

Input	<code>EyeTrackerIndex</code>	<code>unsigned integer</code>	The index of the eye tracker
Output	<code>Result</code>	<code>Result</code>	<code>Result.Success</code> <code>Result.NotConnected</code> <code>Result.NoFrame</code> <code>Result.InvalidIndex</code>
	<code>Position</code>	<code>double[3]</code>	The eye position
	<code>Occluded</code>	<code>boolean</code>	This is true if the segment that has the eye tracker attached is not visible. If true the position will be (0,0,0).
C++	<p>A valid EyeTrackerIndex is between 0 and GetEyeTrackerCount()-1</p> <pre>// class Output_GetEyeTrackerGlobalPosition // { // public: //     Result::Enum Result; //     double      Position[ 3 ]; //     bool        Occluded; // }; // Output_GetEyeTrackerGlobalPosition GetEyeTrackerGlobalPosition( // const unsigned int EyeTrackerIndex ) const;  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); MyClient.EnableSegmentData(); MyClient.EnableDeviceData(); MyClient.GetFrame();  Output_GetEyeTrackerGlobalPosition Output = MyClient.GetEyeTrackerGlobalPosition( 0 );</pre>		
MATLAB	<p>A valid EyeTrackerIndex is between 1 and GetEyeTrackerCount()</p> <pre>% [Output] = GetEyeTrackerGlobalPosition ( EyeTrackerIndex )  MyClient = Client(); MyClient.Connect( "localhost" ); MyClient.EnableSegmentData(); MyClient.EnableDeviceData(); MyClient.GetFrame();  Output = MyClient.GetEyeTrackerGlobalPosition ( 1 );</pre>		
.NET	<p>A valid EyeTrackerIndex is between 0 and GetEyeTrackerCount() - 1</p> <pre>// public ref class Output_GetEyeTrackerGlobalPosition // { // public: //     Result          Result; //     array&lt; double &gt;^ Position; //     bool            Occluded; // }; // Output_GetEyeTrackerGlobalPosition^ GetEyeTrackerGlobalPosition( //         unsigned int EyeTrackerIndex )</pre>		

[About the SDK](#)SDK Functions Listing:  
[GetEyeTrackerGlobalPosition](#)[Appendix A: What's New](#)

```
ViconDataStreamSDK.DotNET.Client MyClient = new
ViconDataStreamSDK.DotNET.Client();
MyClient.Connect( "localhost" );
MyClient. EnableSegmentData ();
MyClient. EnableDeviceData ();
MyClient.GetFrame();

Output_GetEyeTrackerGlobalPosition Output =
MyClient.GetEyeTrackerGlobalPosition ( 0 );
```

**GetEyeTrackerGlobalGazeVector**

*Returns the gaze direction as a unit vector in global coordinates. The gaze vector will be marked as occluded if the segment that has the eye tracker attached is not visible, the eye tracker is not calibrated or the pupil is not found. The segment and device data need to be enabled to get the gaze vector.*

*See also:* [GetEyeTrackerCount](#), [GetEyeTrackerGlobalPosition](#)

Input	EyeTrackerIndex	unsigned integer	The index of the eye tracker
Output	Result	Result	Result.Success Result.NotConnected Result.NoFrame Result.InvalidIndex
	GazeVector	double[3]	The gaze direction vector
	Occluded	boolean	This is true if gaze vector could not be calculated. If false the position will be (0,0,0).
C++	A valid EyeTrackerIndex is between 0 and GetEyeTrackerCount()-1 <pre>// class Output_GetEyeTrackerGlobalGazeVector // { // public: //     Result::Enum Result; //     double      GazeVector [ 3 ]; //     bool        Occluded; // }; // Output_GetEyeTrackerGlobalGazeVector GetEyeTrackerGlobalGazeVector( //   const unsigned int EyeTrackerIndex ) const;  ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect( "localhost" ); MyClient.EnableSegmentData (); MyClient.EnableDeviceData (); MyClient.GetFrame();  Output_GetEyeTrackerGlobalPosition Output = MyClient.GetEyeTrackerGlobalGazeVector ( 0 );</pre>		
MATLAB	A valid EyeTrackerIndex is between 1 and GetEyeTrackerCount() <pre>% [Output] = GetEyeTrackerGlobalGazeVector ( EyeTrackerIndex )  MyClient = Client(); MyClient.Connect( "localhost" ); MyClient.EnableSegmentData (); MyClient.EnableDeviceData (); MyClient.GetFrame();  Output = MyClient.GetEyeTrackerGlobalGazeVector ( 1 );</pre>		
.NET	A valid EyeTrackerIndex is between 0 and GetEyeTrackerCount() - 1 <pre>// public ref class Output_GetEyeTrackerGlobalPosition // { // public: //     Result      Result; //     array&lt; double &gt;^ Position; //     bool        Occluded; // }; // Output_GetEyeTrackerGlobalPosition^ GetEyeTrackerGlobalPosition( //   unsigned int EyeTrackerIndex )</pre>		

[About the SDK](#)SDK Functions Listing:  
**GetEyeTrackerGlobalGazeVector**[Appendix A: What's New](#)

```
ViconDataStreamSDK.DotNET.Client MyClient = new
ViconDataStreamSDK.DotNET.Client();
MyClient.Connect( "localhost" );
MyClient. EnableSegmentData ();
MyClient. EnableDeviceData ();
MyClient.GetFrame();

Output_GetEyeTrackerGlobalPosition Output =
MyClient.GetEyeTrackerGlobalPosition ( 0 );
```

## Appendix A – What's New

### What's New in Version 1.0

- | Full access to analog device data in Nexus. This can be scaled data or raw voltages.
- | One SDK for all applications.
- | Four segment rotation options: Quaternion, 3x3 row-major Matrix, Helical, and EulerXYZ.
- | Support streaming, request, and pre-fetch modes.
- | Formats specific to C++, MATLAB and .NET.
- | Version control.
- | Result feedback for success criteria.

### What's New in Version 1.0.1

- | C++ programs that access the DS-SDK dll files can now be compiled in Debug mode.
- | New function calls for Vicon Tracker \*\*\*
  - ConnectToMulticast
  - StartTransmittingMulticast
  - StopTransmittingMulticast
  - GetLatencyTotal
  - GetLatencySampleCount
  - GetLatencySampleName
  - GetLatencySampleValue

\*\*\* These functions will not work with Vicon Nexus 1.4 and Vicon Blade 1.6.

### What's New in Version 1.1.0

- | Release of C++ and .NET SDKs on Windows x64.
- | Release of C++ SDK on Linux x86.
- | New function calls
  - DisableSegmentData
  - DisableMarkerData
  - DisableUnlabeledMarkerData
  - DisableDeviceData
  - GetMarkerParentName
  - GetSubjectRootSegmentName
  - GetSegmentParentName
  - GetSegmentChildCount
  - GetSegmentChildName
  - GetSegmentStaticTranslation

- GetSegmentStaticRotationHelical
  - GetSegmentStaticRotationMatrix
  - GetSegmentStaticRotationQuaternion
  - GetSegmentStaticRotationEulerXYZ
- | Corrected some units. The values given by the SDK have not changed – they were incorrectly labeled in previous versions.
- "NewtonMillimetre" has become "NewtonMeter"
  - "Millimetre" has become "Meter"
- | Corrected segment rotations following calls to SetAxisMapping()
- | Added command-line options for the Test programs to specify a host to connect to.

### What's New in Version 1.2.0

- | Added C++ Linux x64 support
- | Fix to support of .NET under Windows x64
- | New function calls:
- GetForcePlateCount
  - GetGlobalForceVector
  - GetGlobalMomentVector
  - GetGlobalCentreOfPressure
- | Minor improvements to documentation.

### What's New in Version 1.3.0

- | New function calls:
- GetFrameRate
  - GetEyeTrackerCount
  - GetEyeTrackerGlobalPosition
  - GetEyeTrackerGlobalGazeVector
  - GetDeviceOutputSubsamples
  - GetForcePlateSubsamples
- | New overrides to function calls to allow access to all the analog data:
- GetDeviceOutputValue
  - GetGlobalForceVector
  - GetGlobalMomentVector
  - GetGlobalCentreOfPressure
- | Minor improvements to documentation.
- | Added Mac OSX support.