XIAOZHI VOICE SATELLITE — WIRING DIAGRAM

Freenove ESP32-S3 WROOM CAM · INMP441 · MAX98357A · 4–8 Ω speaker · SH1106 1.3″ OLED (I²C)

v0.2 · 2026-10-17

Pins: config.h @ ed5cd7b · OLED SCK→21 / SDA→47 as wired 2026-10-17

