
Support for ICAP Layer

Yongsheng.guo@ansys.com



ICap support on Control XML





Icap xml syntax was support from GDS Import Wizard V5.6

CSVTech overlapping template.csv

	Α	В	С	D	Е	F	G	ŀ	Н	1
1	NO	LayerNam	Туре	LayerMap	TextLayerI	Thickness	Height	LowerLayer		UpperLayer
2	13	fill_in	D			0.001				
3	14	M4	С	31;0		0.001	0.002			
4	15	CTM2	С	67;3		0.0003	0.0006			
5	17	M3	С	28;0		0.0005	0			
6	21	via34	V	29;0				None		M4
7										
8								Set	LowerLav	er to None to indic

Set LowerLayer to None to indicate the StopLayer not having value.

Options:

tech2xmlOption.json

"UseSheetLayer": false,

"FixedSmallLayerGap": 0,

"CreatViaGroups": false,

"AutoComps": false,

Must set for the small value in Thickness and Height

← If viagroup not need

← If Components not need



Options in CSV Tech, New in GDS Import Wizard V5.6

	Α	В	С	D	Е	F	G	Н	1
1	NO	LayerName	Туре	LayerMap	TextLayerl	Thickness	Height	LowerLayer	UpperLayer
2	13	fill_in	D			0.001			
3	14	M4	С	31;0		0.001	0.002		
4	15	CTM2	С	67;3		0.0003	0.0006		
5	17	M3	С	28;0		0.0005	0		
6	21	via34	V	29;0				None	M4
7									
8		UseSheetLayer	О	FALSE					
9		FixedSmallLayerGap	О	0					
10		CreatViaGroups	О	FALSE					
11		AutoComps	О	FALSE					
12	#Note:								

Options in CSV Tech with Type as O or (Option).
Options in CSV Tech have highest priority then GUI and any other ways, it should be used with caution, which may cause mismatch between GUI and finally effective.

