UART - MBED-OS -

Handong university

Jong-won Lee

USART in STM32-F411

- USART Features
 - Full duplex, asynchronous communications
 - x8 or x16 oversampling
 - Supports USART synchronous communications
 - Transmitter clock output for synchronous transmission
 - Has the same format of asynchronous transmission
 - No clock at the start and stop bit
 - Supports LIN (local interconnection network)
 - Single-wire half-duplex communication
 - Supports the asynchronous protocol of Smartcards as defined in the ISO 7816-3 standard
 - □ IrDA SIR encoder decoder
 - Can use DMA



USART in STM32-F411RE

□ 사용 가능한 USART 장치 및 USART 장치의 TX/RX 핀

| USART 장치 | RTS/CTS 신호선 | 최대 전송속도 (Mbps) (x16/x8 클럭 사용시) | 비고 (Mbed-os에서 사용 가능한 핀) {TX/RX} |
|-------------|----------------|-----------------------------------|--|
| USART1 | 있음 | 6.25/12.5 | {PA_9(D8)/PA_10(D2} {PA_15/PB_3} {PB_6(D10)/PB_7(CN7_21)} |
| USART2 | 있음 | 3.12/6.25 | USB 디버거 포트를 PC와 연결하였을 때, Virtual comm 포트 {PA_2/PA_3} |
| USART6 | 없음 | 6.25/12.5 | {PA_11/PA_12} {PC_6/PC_7} |

□ USART 장치의 RX 입력 신호

■ 5V tolerant



USART in Nucleo-F411RE


□ **Cf.:** https://github.com/ARMmbed/mbed-os/blob/master/targets/TARGET_STM/TARGET_STM32F4/TARGET_STM32F411xE/TARGET_NUCLEO_F411RE/PeripheralPinMaps.h

```
MSTD CONSTEXPR OBJ 11 PinMap PinMap UART TX[] = {
   {PA_2,
                UART_2, STM_PIN_DATA(STM_MODE_AF_PP, GPIO_PULLUP, GPIO_AF7_USART2)}, // Connected to STDIO_UART_TX
   {PA_9, UART_1, STM_PIN_DATA(STM_MODE_AF_PP, GPIO_PULLUP, GPIO_AF7_USART1)},
              UART 6, STM PIN DATA(STM MODE AF PP, GPIO PULLUP, GPIO AF8 USART6)},
   {PA_11,
               UART 1, STM PIN DATA(STM MODE AF PP, GPIO PULLUP, GPIO AF7 USART1)},
   {PA 15,
   {PB 6,
                UART 1, STM PIN DATA(STM MODE AF PP, GPIO PULLUP, GPIO AF7 USART1)},
   {PC_6,
                UART_6, STM_PIN_DATA(STM_MODE_AF_PP, GPIO_PULLUP, GPIO_AF8_USART6)},
   {NC, NC, 0}
};
MSTD CONSTEXPR OBJ 11 PinMap PinMap UART RX[] = {
               UART_2, STM_PIN_DATA(STM_MODE_AF_PP, GPIO_PULLUP, GPIO_AF7_USART2)}, // Connected to STDIO UART RX
   {PA 3,
              UART 1, STM PIN DATA(STM MODE AF PP, GPIO PULLUP, GPIO AF7 USART1)},
   {PA 10,
   {PA 12,
               UART 6, STM PIN DATA(STM MODE AF PP, GPIO PULLUP, GPIO AF8 USART6)},
   {PB_3,
              UART_1, STM_PIN_DATA(STM_MODE_AF_PP, GPIO_PULLUP, GPIO_AF7_USART1)}, // Connected to SWO
              UART_1, STM_PIN_DATA(STM_MODE_AF_PP, GPIO_PULLUP, GPIO_AF7_USART1)},
   {PB 7,
   {PC_7,
                UART 6, STM PIN DATA(STM MODE AF PP, GPIO PULLUP, GPIO AF8 USART6)},
   {NC, NC, 0}
};
```



UART

Data frame




- TX: parallel-to-serial conversion with a start bit, and followed by the data bits (LSB first), parity bit, and the stop bits according to the programmed.
- RX: serial-to-parallel conversion after a valid start pulse has been detected.
 - Overrun, parity, frame error checking, and line-break detection are also performed.



Synchronous Mode in F411RE


- In synchronous mode the USART transmitter works exactly like in asynchronous mode.
- The CK pin is the output of the USART transmitter clock.
 - No clock pulses are sent to the CK pin during start bit and stop bit.





Synchronous Mode in F411RE


- Timing diagram
 - The same as that of SPI
 - M=0 (8 data bits)





Synchronous Mode in F411RE

- □ Timing diagram
 - The same as that of SPI
 - M=1 (9 data bits)





UART - MBED-OS -

Handong university

Jong-won Lee

Mbed-OS UART API

- Two classes
 - BufferedSerial and UnbuferedSerial

 Compared to the previous Mbed-os version, there are many changes.

| Deprecated API | Replaced by |
|----------------|--|
| Serial | printf and puts which are used in the console.BufferedSerial for efficient serial communication.UnbufferedSerial for bypassing locks in IRQ or short of RAM. |
| RawSerial | UnbufferedSerial |
| UARTSerial | BufferedSerial |



Mbed-OS BufferedSerial API

BufferedSerial

- When the receive interrupt is triggered when receiving data from a device, the BufferedSerial class stores the byte(s) available to read from the hardware buffer to an internal intermediary buffer.

 When a read request is made, the BufferedSerial class uses a mutex lock and enters a critical section to read out the number of bytes requested if as many are available in the intermediary buffer.
- To transmit multiple bytes, the class uses an intermediary buffer to store the bytes to send and monitors the serial interface to transfer them to the hardware buffer as soon as it is available.
- The RX and TX buffers are circular buffers with preallocated sizes configurable using the configuration parameters **uart-serial-rxbuf-size** and **uart-serial-txbuf-size**. You can find both configuration parameters in drivers/mbed_lib.json.



| 생성자 | <pre>BufferedSerial (PinName tx, PinName rx, int baud = MBED_CONF_PLATFORM_DEFAULT_SERIAL_BAUD_RATE)</pre> |
|------|---|
| 설명 | 주어진 tx, rx 핀을 사용하는 BufferedSerial 객체를 생성한다. Default baud rate = 9600 |
| 사용 예 | static BufferedSerial serial_port(CONSOLE_TX, CONSOLE_RX, 115200); |
| 함수 | void set_baud (int baud); |
| 설명 | UART의 baud rate를 설정함. |
| 사용 예 | serial_port.set_baud(115200); |
| 함수 | <pre>void set_format (int bits = 8, Parity parity = BufferedSerial::None,</pre> |
| 설명 | UART의 전송 포맷을 설정함. Parity: BufferedSerial::None, BufferedSerial::Odd, BufferedSerial::Even, |
| 사용 예 | serial_port.set_format(8, BufferedSerial::Odd, 2); |

| 함수 | bool readable () const |
|------|---|
| 설명 | 읽을 데이터가 존재하면 true를 반환한다. |
| 사용 예 | <pre>If (serial_port.readable()) num = serial_port.read(buf, sizeof(buf));</pre> |
| 함수 | bool writable () const |
| 설명 | write()를 위한 버퍼가 존재하면 true를 반환한다. |
| 사용 예 | <pre>If (serial_port.writable()) serial_port.write(buf, num);</pre> |
| 함수 | int set_blocking (bool blocking) |
| 설명 | int set_blocking (bool blocking) Blocking 혹은 non-blocking 모드로 설정. (디폴트 모드는 blocking 모드이다.) FILE (기에게 |
| 사용 예 | serial_port.set_blocking(true); |
| | (MINI DAGHEN |



| 함수 | ssize_t read (void * buffer, size_t size) |
|------|--|
| 설명 | 버퍼로 수신한 데이터를 읽는다. 위을 데이터가 없을 경우: - Blocking function이면, 읽을 데어터가 있을 때까지 기다린다. - Non-blocking function이면, -EAGAIN 값을 반환한다. 반환값: - 읽은 데이터의 개수. - error인 경우는 음수 값을 반환한다. |
| 사용 예 | <pre>num = serial_port.read(buf, sizeof(buf));</pre> |



BufferedSerial class

| 함수 | ssize_t write (void * buffer, size_t size) |
|------|---|
| 설명 | 버퍼의 내용을 전송한다. 충분한 tx 버퍼가 없을 경우: - Blocking function이면, 모든 데이터를 쓸 때까지 기다린다. - Non-blocking function 일 경우: .tx 버퍼가 full이면, EAGAIN을 반환한다. .일부 데이터를 쓸 수 있으면, 일부 데이터를 쓴다. 반환값: - 쓴 데이터의 개수. Vedum - error인 경우는 음수 값을 반환한다. |
| 사용 예 | serial_port.write(buf, num); |

Blocking: 卫曼 印刷部 生 时初日 7年2年

non-blocking; tr HZAL full doz EAGAIN recurn



BufferedSerial class

| 함수 | void sigio (Callback< void()> func) |
|------|--|
| 설명 | 상태 변화에 대한 callback 함수를 등록한다. (쓸 수 있거나, 읽을 수 있는 것과 같이 상태 변화가 있을 때에 callback 함수가 실행된다.) Callback 함수 내에서 heavy job을 수행하지 않아야 한다. (어떤 interrupt context 안에서 callback 함수가 불리움.) |
| 사용 예 | serial_port.sigio (rx_handler); |

份明 超到(生产影似, 路至于别的)



Floating point in mbed-os v.6.0 printf()

- □ Refer to: https://github.com/ARMmbed/mbed-os/blob/master/platform/source/minimal-printf/README.md
- To reduce the code size Mbed introduced Minimal printf and snprintf.
 - As of Mbed OS 6.0 it is enabled by default. Floating point parameters are only present when minimal-printf-enable-floating-point config is set to true (disabled by default).
- To enable floating-point parameters, configure it in mbed_app.json

```
{
    "target_overrides": {
        "*": {
            "target.printf_lib": "std"
        }
     }
}

target_overrides": {
    "*": {
        "target.printf_lib": "minimal-printf"
        }
}
```




Lab4-1~Lab4-3: UART

- □ 실습 목적
 - □ 1. Mbed-OS 상에서 UART 장치를 동작시키는 방법에 대해 이해한다.
 - BufferedSerial and UnbufferedSerial
 - □ 2. 터미널 에뮬레이션 프로그램을 사용할 수 있다.
- □ 실습 과정
 - PC와 Nucleo board를 USB 케이블을 이용하여 연결한다.
 - □ TeraTerm을 실행시키고 동작 환경을 설정한다. (포트 연결 및 Baudrate 설정)
 - Baud rate: 115,200 bps
 - Format: 8 bit data, 1 stop bit, no parity
 - □ 사용자의 입력이 터미널 에뮬레이터에 나타나도록 코드를 구현한다.
 - 사용자의 입력을 polling/interrupt 방식에 의해서 감지하여라.
 - □ 사용자가 Enter(엔터) 키를 입력할 경우에 다음 줄로 넘어가도록 한다.



Lab4-1: TeraTerm 설정


① [제어판] - [장치 관리자]: 연결 확인



② TeraTerm 실행 시 시리얼 포트 선택



③ TeraTerm [설정] - [시리얼포트]



④ 시리얼 포트 속도 포맷 설정

| Tera Term: 시리얼포트 설정 | 3 | | × |
|---------------------|---------|-------------|----|
| 포트(P): | COM14 | * 확인 | |
| 속도(E): | 115200 | ~ | |
| 데이터(D): | 8 bit | > 취소 | |
| 패리티(A): | none | ~ | |
| 스탑비트(S): | 1 bit | 도움말(| H) |
| 흐름제어(F): | none | ~ | |
| 전송지연 0 msec/ | /char O | msec/line | |



- USART2 TX and RX pin
 - Pin naming in Mbed: In PinNames.h

```
// STDIO for console print
#ifdef MBED_CONF_TARGET_STDIO_UART_TX
    CONSOLE_TX = MBED_CONF_TARGET_STDIO_UART_TX,
#else
    CONSOLE_TX = PA_2,
#endif
#ifdef MBED_CONF_TARGET_STDIO_UART_RX
    CONSOLE_RX = MBED_CONF_TARGET_STDIO_UART_RX,
#else
    CONSOLE_RX = PA_3,
#endif
```



Lab4-1: UART (BufferedSerial)

A sample code

```
#include "mbed.h"
// Maximum number of element the application buffer can contain
#define MAXIMUM BUFFER SIZE 80
char buf [MAXIMUM BUFFER SIZE] ;
// Create a DigitalOutput object to toggle an LED whenever data is received.
static DigitalOut led(LED1);
// Create a BufferedSerial object with a default baud rate.
static BufferedSerial pc(CONSOLE_TX, CONSOLE_RX, 115200);
int main(void)
   printf("mbed-os version: %d.%d.%d\r\n",
           MBED MAJOR VERSION, MBED MINOR VERSION, MBED PATCH VERSION);
   sprintf(buf, "Hello New Serial function in mbed-os v.%.1f\r\n", 6.0);
   pc.write(buf, strlen(buf));
   sprintf(buf, "Enter characters...\r\n");
   pc.write(buf, strlen(buf));
   while (1) {
      led = !led;
      // Echo the input back to the terminal.
      int num = pc.read(buf, sizeof(buf));
      pc.write(buf, num);
      if (buf[0] == '\r') {
         pc.write("\n", 1);
```



Lab4-1: UART (BufferedSerial)

mbed_app.jason

```
F411-lab4-1_bufferedSerial_22

resources
CMakeLists.txt
CONTRIBUTING.md
LICENSE
main.cpp
mbed_app.json
README.md

mbed-os
```



□ 결과 (mbed-os version in 2023: 6.17.0)

```
M COM15 - Tera Term VT

File Edit Setup Control Window Help

mbed-os version: 6.17.0

Hello New Serial function in mbed-os v.6.0

Enter characters...

■
```

```
COM15 - Tera Term VT

File Edit Setup Control Window Help

mbed-os version: 6.17.0

Hello New Serial function in mbed-os v.6.0

Enter characters...

Handong Global University

Embedded Application
```

〈초기 화면〉

〈동작 화면〉



UART - MBED-OS -

Handong university

Jong-won Lee

- The UnbufferedSerial class provides UART functionality with an API similar to the BufferedSerial class.
- Unlike the BufferedSerial class, the UnbufferedSerial class does not use intermediary buffers to store bytes to transmit to or read from the hardware.
- The method to read data returns only one byte for every call. However, you can write multiple bytes at once.
- You can use this class for use in interrupt handlers with the RTOS.
- Because it does not acquire a mutex lock, you must ensure only one instance uses the serial port.
- For normal blocking applications, BufferedSerial performs better than UnbufferedSerial and causes less CPU load and fewer latency issues.
- Only applications that are short of RAM and cannot afford buffering or that need more control of the serial port and use it from IRQ should use UnbufferedSerial.



| 생성자 | <pre>UnbufferedSerial (PinName tx, PinName rx, int baud = MBED_CONF_PLATFORM_DEFAULT_SERIAL_BAUD_RATE)</pre> |
|------|---|
| 설명 | 주어진 tx, rx 핀을 사용하는 UnbufferedSerial 객체를 생성한다. |
| 사용 예 | static UnbufferedSerial serial_port(CONSOLE_TX, CONSOLE_RX); |
| 함수 | void baud (int baud); |
| 설명 | UART의 baud rate를 설정함. |
| 사용 예 | serial_port.baud(115200); |
| 함수 | <pre>void format (int bits = 8, Parity parity = SerialBase::None,</pre> |
| 설명 | UART의 전송 포맷을 설정함. |
| 사용 예 | serial_port.format(8, SerialBase::Odd, 2); |



| 함수 | int readable () |
|------|--|
| 설명 | 읽을 데이터가 존재하면 '1'을 반환한다. |
| 사용 예 | <pre>If (serial_port.readable()) num = serial_port.read(buf, sizeof(buf));</pre> |
| 함수 | int writable () |
| 설명 | write()를 위한 버퍼가 존재하면 '1'을 반환한다. |
| 사용 예 | <pre>If (serial_port.writable()) serial_port.write(buf, num);</pre> |



| 함수 | ssize_t read (void * buffer, size_t size) |
|------|---|
| 설명 | 버퍼로 수신한 데이터를 읽는다. 정확하게 한 바이트만 읽는다. 그때까지 block된다. 반환값: - 읽은 데이터의 수. |
| 사용 예 | <pre>num = serial_port.read(buf, sizeof(buf));</pre> |
| | h/2 |



| 함수 | ssize_t write (void * buffer, size_t size) |
|------|---|
| 설명 | 버퍼의 내용을 전송한다. 모든 데이터를 전송할 때까지 block된다. 반환값: - 쓴 데이터의 개수. |
| 사용 예 | serial_port.write(buf, num); |
| | |



| UnbufferedSerial class | |
|--|--|
| 함수 | void attach (Callback< void()> func, lrqType type=Rxlrq) |
| 설명 | 주어진 인터럽트가 발생할 때마다 인터럽트 핸들러를 부른다. |
| 사용 예 | serial_port.attach (rx_handler, SerialBase::Rxlrq); |



Lab4-3: UART (UnbufferedSerial)

- □ 실습 목적
 - □ UnbufferedSerial 동작을 이해한다.
- □ 실습 과정
 - □ Lab4-1과 동일한 실험 환경을 구성한다.
 - 사용자의 입력이 터미널 에뮬레이터에 나타나도록 코드를 구현한다.
 - 사용자의 입력을 interrupt 방식에 의해서 감지하여라.
 - □ 사용자가 Enter(엔터) 키를 입력할 경우에 다음 줄로 넘 어가도록 한다.



Lab4-3: UART (UnbufferedSerial)

A sample code (interrupt)

```
#include "mbed.h"
// Maximum number of element the application buffer can contain
#define MAXIMUM BUFFER SIZE 80
char buf[MAXIMUM BUFFER SIZE] ;
// Create a DigitalOutput object to toggle an LED whenever data is received.
static DigitalOut led(LED1);
// Create a BufferedSerial object with a default baud rate.
static UnbufferedSerial pc(CONSOLE TX, CONSOLE RX);
void rx handler()
    char c:
   // Toggle the LED.
   led = !led:
   // Read the data to clear the receive interrupt.
   if (pc.read(&c, 1)) {
       // Echo the input back to the terminal.
       pc.write(&c, 1);
        if (c == '\r') {
           pc.write("\n",1);
```



Lab4-3: UART (UnbufferedSerial)

A sample code (con't)

```
int main(void)
{
   pc.baud(115200);
   pc.format(8,SerialBase::None, 1);

   // Register a callback to process a Rx (receive) interrupt.
   pc.attach(rx_handler, SerialBase::RxIrq);

   sprintf(buf, "Hello New Serial function in mbed-os v.%.1f\r\n", 6.0);
   pc.write(buf, strlen(buf));

   sprintf(buf, "Enter characters...\r\n");
   pc.write(buf, strlen(buf));

   while (1) {
   }
}
```



- MBED-OS -

LAB

Handong university

Jong-won Lee

- □ 실습 목적
 - BufferedSerial 동작을 이해한다.
 - □ Sigio 의 동작을 이해한다.
- □ 실습 과정
 - □ Lab4-1과 동일한 실험 환경을 구성한다.
 - 사용자의 입력이 터미널 에뮬레이터에 나타나도록 코드를 구현한다.
 - 사용자의 입력을 sigio 에 의해서 감지하여라.
 - □ 사용자가 Enter(엔터) 키를 입력할 경우에 다음 줄로 넘어가도록 한다.



Lab4-2: UART (BufferedSerial)

- A skeleton code (with signal handler): complete the code
 - Must have the same function of that of Lab4-1

```
#include "mbed.h"
// Maximum number of element the application buffer can contain
#define MAXIMUM BUFFER SIZE 80
char buf[MAXIMUM BUFFER SIZE];
static DigitalOut led(LED1);
static BufferedSerial pc(CONSOLE_TX, CONSOLE_RX, 115200);
// RX interrupt handler
void rx handler()
  led = !led; // Toggle the LED.
 // complete your code
 // ....
```

Lab4-2: UART (BufferedSerial)

A skeleton code (with signal handler): complete the code

```
int main(void)
  pc.set_blocking(false); // non-critical in this example
  pc.sigio(rx_handler); //event handler
 sprintf(buf, "Hello New Serial function in mbed-os v.%.1f\r, 6.0);
  pc.write(buf, strlen(buf));
  sprintf(buf, "Enter characters...\r\n");
  pc.write(buf, strlen(buf));
 while (1) {
   // complete your code
    // ...
```




- □ 실습 목적
 - □ 블루투스 모듈 사용법을 익힌다.
 - □ 스마트 폰 앱을 이용하여 Nucleo 보드 상의 GPIO를 제어한다.
- □ 실습 시나리오
 - □ 스마트폰 앱에 입력된 글자들은 PC의 Terminal(TeraTerm) 창에 출력되어야 한다.
 - 스마트폰 앱을 통하여 주어진 명령어 따라 LED가 제어 되어야 한다.
 - RedLED on, RedLED off, RedLED status
 - GreenLED on, GreenLED off, GreenLED status
 - 첫번째 argument와 두번째 argument 사이에 space가 하나가 아니더라도 동일한 명령어로 인식되어야 한다.
 - Ex.: "RedLED on"이란 명령어도 "RedLED on"과 동일하게 동작하여야 함.



- □ 실습 시나리오 (con't)
 - 주어진 명령이 실행된 다음에 스마트폰 앱에 결과가 다음과 같이 표시되어야 한다.
 - 정상적인 명령이 주어졌을 경우에는 명령이 실행된 다음 혹은 현재의 LED의 상태가 다음과 같이 표시되어야 한다.
 - RedLED status: on 혹은 RedLED status: off
 - GreenLED status: on 혹은 GreenLED status: off
 - 잘못된 명령어가 주어졌을 경우에는 다음과 같이 표시되어야 한다.
 - Undefined command



- □ Bluetooth module: HM-10 (BLE 기반의 Bluetooth-serial)
 - Master 혹은 slave 기능 모두 가능함.
 - □ 디폴트 시리얼 통신 포맷
 - 9600 bps, No parity, Data: 8 bits, 1 stop bit, No flow control
 - \square Module name: nes-xx (xx: 01 \sim 99)
 - □ 연결할 핀
 - GND,
 - VCC (3.6V ~ 6V)
 - RXD, TXD (5V logic level)
 - 내부 BLE 모듈은 3.3V 전원으로 동작.
 - Voltage regulator와 level shifter 회로 존재.






- □ 회로 구성
 - □ Nucleo-F411RE 보드와 HM-10 모듈 연결 방법
 - VCC (HM-10) ⇔ CN6-5 (+5V, Nucelo 보드)
 - GND (HM-10) ⇔ CN6-6 (GND, Nucelo 보드)
 - TXD (HM-10) ⇔ D2 (USART1 RXD, Nucelo 보드)
 - RXD (HM-10) ⇔ D8 (USART1 TXD, Nucelo 보드)
 - □ LED 제어를 위한 회로 구성
 - D3, D4에 전선을 연결 후 저항(220~330Ω)과 LED 연결
 - D3 (Red LED), D4(Green LED)



□ 회로 구성






- □ 휴대폰에서 사용 가능한 앱
 - □ 안드로이드폰: Serial Bluetooth Terminal
 - Bluetooth Classic & BLE
 - □ iPhone: HM10 Bluetooth Serial Lite




- □ 앱 동작 과정: 안드로이드폰: Serial Bluetooth Terminal
- ① App(Serial Bluetooth Terminal) 설치 ③ 우측 상단 [SCAN] 클릭




② 좌측 상단 - [Devices] 선택






④ 해당 Bluetooth module 연결





□ 동작 예



```
COM5 - Tera Term VT
File Edit Setup Control Window Help
LED Control Example by a CellPhone
LED Control Example by a CellPhone
LED Control Example by a CellPhone
RedLED on
RedLED status: on
RedLED off
RedLFD status: off
RedLED status
RedLED status: off
Greenl FD
            on
GreenLED status: on
Greenl FD
            off
GreenLED status: off
GreenLED on
GreenLED status: on
GreenLED status
GreenLED status: on
GreenLED Toggle
Undefined command
YellowLED on
Undefined command
```