State diagram when Sn:Zn=8.5:1.5 inside a furnace -×- alloy temperature[°C] -100 time[s]