		ransi untuk	Nominal	> 0,5 s/d 3		> 6 s/d	> 3 30 s/d 1	0 > 20 s/d	120 >	3 5 d 1000	> 0 s/d 2	000 > 20 2000 s/d	000 > 4000 s /	4000 d 8000	
	perm	esinan	Tolerans	±0,15	±0,	2 ±0,	5 ±0,	8 ±	1,2	± 2	±	3 ±	4	± 5	
			TOLER	RANSI	SI UMUM DAPAT DILIHAT F					PADA SIP 04.000					
000	Perubahan												М	icro	
00	\wedge	V				Micr		V					М	icro	
	\sim	X				Micr	\wedge	. X					M	icro	
1		X						. x					-		
RB5022-HII00000															
													E		
													<u>5</u>		
										,			50		
				A) 160			-				50			
							_					· ·	D		
							<u>_</u>	PROCES		_			Prapa	re	
								CHECK	DIM (+			Appro	ove	
									Ė	2/4 -//			Appro		
									Ľ	J.ty/U	nit: ,	ZR	<u> </u>		
		<u> </u>	The state of the s												
	No.	Nan	na Bagian	J	m / .		Keteran	gan			RB502	?2-H1000	000	2	
												Penggunaan			
	Bobot (kg) 0.603				Bagian Perlakuan Panas				s K	etebo	alan	nggunaan jml Bahan SIKU 50 5x50x50x160			
	Diperiksa Digambar Roni				Tanggal Nama B. S/KL							Perl.Permukaan			
	Dischwiggi Skala Pandu AN 1:2 060916			ı	Ukuran mm			No. Gambar RB5022-H11000				000			
THORE DT I INITED TRACTORS DANIDI I ENGINEEDING															

PT UNITED TRACTORS PANDU ENGINEERING