

Variables OPC-UA		Type	Description	Type
Set Reference Data	wrValidationID	String[20]	Set Reference Name / Order Number	write
	wrClipName	String[20]	Set Clip Name / Splice Name (optional)	
	wrProcessTemp	Int	Set Shrinking Temperature in Celsius (ex.: 500)	
	wrShrinkingTime	Int	Set Shrinking Time in seconds (ex.: 20)	
	wrCoolingTime	Int	Set Cooling Time in seconds (ex.: 5)	
	wrTubeName	String[20]	Set Tube (ex.: RBK2) (optional) - <i>shrinking tube that's defined for selected configuration</i>	
	wrMMSSpliceWidth	Double	Splice Size (mm) [11.0 - 19.0]	
	wrMMTTubeSize	Double	Tube Size (mm) [20.0 - 75.0]	
	wrMMDiameter1	Double	Diameter 1 (mm) [0.5 - 12.0]	
	wrMMDiameter2	Double	Diameter 2 (mm) [0.5 - 12.0]	
	wrSpliceStatus	Int	<i>Default = 0 ; OK = 1 ; Done = 2 ; Locked = 3 ; Shrinking = 4 ; Error = 5</i>	
	wrOrderStatus	Int	<i>Not_exists = -1 ; Default = 0 ; Exists = 1 ; Completed = 2</i>	
End of Shrinking Process Reference Data - <i>ProcessResults</i>	ValidationID	String[20]	Reference Name / Order Number - <i>Validation ID of parameters used for shrinking</i>	read
	EndClipName	String[20]	Clip Name / Splice Name (optional)	
	ProcessTemp	Int	Shrinking Temperature in Celsius (ex.: 500)	
	ShrinkingTime	Int	Shrinking Time in seconds (ex.: 20)	
	CoolingTime	Int	Cooling Time in seconds (ex.: 5)	
	TubeName	String[20]	Tube (ex.: RBK2) (optional) - <i>shrinking tube that's defined for selected configuration</i>	
	Date_Time	String[20]	ex.: 2025-01-01 10:00:00	
	EndMachineID	String[20]	ex.: 031821-00-0001	
	ShrinkingStatus	String[20]	<i>NOK = -1 ; Empty = 0 ; OK = 1 ; - NOK for process aborted</i>	
Information - <i>Tracing</i>	machineModel	String[20]	Mecalbi Machine Model (ex.: STCS-RCMM)	read
	SFVersion	String[20]	Current Firmware Version (ex.: 031821-33-000-R01) - <i>Software version on machine</i>	
	MachineID	String[20]	Serial number of the Machine (ex.: 031821-00-0001) - <i>Machine uploads Machine ID / unique identification of machine (SN)</i>	
	HeaterTime	Int	Partial Working Time in minutes (resettable) - <i>Resettable parameter. Counts partial time of heater work.</i>	
	timeTotalUptimeInMinutes	Int	Total Working Time in minutes. <i>Counts total time of heater work.</i>	
	cyclesPartialCounter	Int	Cycle Partial Counter (resettable)	
	cyclesTotalCounter	Int	Cycle Total Counter	
	LastLifeTime	String[20]	Last Life Time (ex.: 2025-01-01 10:00:00) - <i>Current date and time</i>	
	temperature	Int	Current Oven Temperature in Celsius (ex.: 450)	
General - <i>Status</i>	userCurrent	String[20]	Current User (ex.: Operator1)	read
	functionMode	String[20]	Operating Mode (ex.: m1, m2, ms)	
	programState	String[20]	Status of Machine (STANDBY, ADJUSTING, READY, MAINTENANCE, CALIBRATION, ALERT, EMERGENCY) - <i>Machine Status</i>	
	standby	Bool	true/false - <i>Machine Status: true when machine is in Standby Mode.</i>	
	running	Bool	true/false - <i>Machine Status: true when machine is in Adjusting/Ready Mode.</i>	
	maintenance	Bool	true/false - <i>Machine Status: true when machine is in Maintenance Mode.</i>	
	RemoteMode	String[20]	Communication with external ultrasonic welding machines (m1) (ex.: OFF ; ON-TON ; ON-TOFF ; ON-EXTENDED)	
	ShrinkingStep	String[20]	<i>Empty = 0 ; Shrinking = 1 ; Timeout = 2 ; Abort = 3 ; Done = 5</i>	
Calibration	Offset	Int	Offset Current in Celsius (ex.: 2) - <i>Heater temperature compensation</i>	read
	LastCalibration	String[20]	Last Calibration Time	
Errors - <i>Alerts</i>	erroractive	Bool	Error Active (true/false) - <i>Flag to signalize if an error is active (global level).</i>	read
	errorcode	Array[30]	Error Code - last 10 machine error codes. The first position is the most recent and the last position the oldest.	
	errorlevel	Array[30]	Error Level - last 10 machine error levels. The first position is the most recent and the last position the oldest.	
	errormessages	Array[30]	Error Messages - last 10 machine error messages. The first position is the most recent and the last position the oldest. (ex.: Emergency; Resistor; Thermocouple; Air Pressure; Oven Back; Oven Front; Expelling Back; Expelling Front; Fans ; Electrode Back ; Electrode Front ; Clamps ; Driver Motor Right ; Driver Motor Left ; Driver Motors Connection ; Power Resistor).	