# Chapter 12 Electron Spin Qubit in Semicoductor-1-Qubit and 2-Qubit Gates

#### 12.1 Introduction

In Chap.11, we showed how to implement a qubit using electron spin on a silicon substrate. We also demonetrated how to initialize and measure a qubit. In this chapter, we will sudy how to perform a universal 1-qubit gate and a 2-qubit entnaglement gate to fulfill the last two DiVincenzo's criteria (Sect. 1.3). In Chap.10, we showed that by applying a vertical DC magnetic field and a rotating horizontal magnetic field and then working in the rotating frame, we would be able to rotate any state on Bloch sphere about any vector. This allows us to build a universal 1-qubit gate (Section 27.4 in [1]) However, in the literature, many silicon qubits are still implemented with the setup in Chap. 9 which means that the qubit is places in a vertical DC magnetic field and a perturbating and linearly oscillating horizontal magnetic field. This is what we will use in this chapter. We will first summarize an experimental paper on how it implements 1-qubit gate. Then we will discuss the implementation of a 2-qubit entnaglement gate with an example.

## 12.1.1 Learning Outcomes

Be able to describe how a 1-qubit gate can be implemented for silicon spin qubits; understant how a CNOT-gate can be impelmented by using a native entanglement gate of silicon spin qubits and other 1-qubit gates.

#### 12.1.2 Teaching Videos


- Search for Ch12 in this playlist
  - https://tinyurl.com/3yhze3jn
- Other Videos
  - https://youtu.be/0JVw4xICV10 - https://youtu.be/\_CpQ-Uy0Kgo

#### 12.2 1-Qubit Gate Implementation

We will use an example in [2] (with some variation) to demonstrate how to implement electron spin qubit in silicon and the 1-qubit gate. The setup is illustrated in Fig. 12.1.

Firstly, the Hilbert space is created by applying a DC magnetic field pointing to the right. This direction is named the  $-\hat{z}$  direction. Therefore, spin-up means that the spin is pointing to the left, and spin-down means that the spin is pointing to the right. This is nothing special because the name of direction is completely a human definition.

The system is kept at 50 mK and  $B_0 = 1.4T$ . This is a spin qubit. To enhance the decoherence time, we need to avoid the spin interacting with the external environment. The electron spin can interact with the nuclear spin in the silicon easily and lose its coherence. Unfortunately, while 95.53% of natural silicon atoms have a zero nuclear spin (92.23%  $^{28}Si$  isotope and 3.1%  $^{30}Si$  isotope), 4.67% of them have a spin ( $^{29}Si$  isotope). This is because  $^{29}Si$  has 14 protons and 15 neutrons and their spins are not nullified due odd number of nucleons. The electron spin will interact strongly with the nucleus of  $^{29}Si$ . Therefore, a highly purified silicon substrate is used, in which  $^{29}Si$  is reduced to 800 ppm (part-per-million). That means, among 1 million silicon atoms in the substrate, only 800 will be  $^{29}Si$ .



**Fig. 12.1** Illustration of how an electron spin qubit is implemented in [2]. The magnetic field due to  $I_{ESR}$  is shown and it points perpendicular to the substrate at the qubit

For **readout**, it also uses spin-to-charge conversion as in Sect. 11.6. However, instead of using a qunatum point contact (QPC) transistor, it uses a **single electron transistor** (SET) which has its current also very sensitive to the charge occupation in the quantum dot.

To implement a 1-qubit gate, it uses the theory we learned in Sect 9.3. That is by applying a perturbing oscillating magnetic field in the  $\hat{x}$  direction. But note that, the  $\hat{x}$  direction in Fig.12.1 is perpendicular to the silicon substrate. To achieve the oscillating magnetic field, an AC electric current,  $I_{ESR}$ , is passed through a wire next to the qubit. ESR stands for **electron spin resonance** which means that its frequency is the same as the Larmor frequency due to  $\vec{B}$  (see Sect.9.4). The current will generate a circular magnetic field about the wire

due to the **Biot-Savart law** (see also Example 24.2). Although it is circular, at the point where it touches the qubit, it is pointing at the tangential direction of the circle and thus it is pointing in the  $\hat{x}$  direction and perpendicular to the Si substrate. Since  $I_{ESR}$  in an AC current, the magnetic field at the qubit oscillates up and down and has the equation form given in the first term of Eq. (9.5). And as discussed in Sect. 9.6, in the rotating frame, any state will rotate about the  $\hat{x'}$  due to Rabi oscillation. Combined with Larmor precession, it can be used to implement any 1-qubit gate.

### 12.3 2-Qubit Gate for Spin Implementation

A 2-qubit gate is usually much more difficult to implement than a 1-qubit gate. We also need to recall that, to form a universal set of quantum gates, what we need is not an arbitary 2-qubit gate but an **entanglement gate**, which can be used to create entanglements (see Sect. 4.6). Entanglement is one of the reasons that makes quantum computing superior to classical computing.

A 2-qubit gate requires the interaction between two qubits and the external excitation under an appropriate Hamiltonian. It is not difficult to appreciate that different quatum computer architectures have different "native" entnaglement gates because the physics is fairly different in different quantum computing archtectures. Here, a **native entanglement gate** is a gate that can be implemented easily using the physics relevant to a given architecture and its controls.

One of the native entanglement gates for an electron spin qubit is a special form of the controlled phase shift gate. We will call it  $U_{Cphase}$  [3] to distinguish it from  $U_{CPS,\pi}$  in Section 16.4 in [1],

$$U_{Cphase} = \begin{pmatrix} 1 & 0 & 0 & 0\\ 0 & e^{i\phi} & 0 & 0\\ 0 & 0 & e^{i(\pi-\phi)} & 0\\ 0 & 0 & 0 & 1 \end{pmatrix}.$$
 (12.1)

where  $\phi$  is the phase. We will discuss how to implement it soon. We will first show how it can be used to create an entanglement.

#### 12.3.1 Creation of Entanglement

We have learned that we can use CNOT gate,  $U_{XOR}$  to make two qubits entangled (Section 15.4 in [1] and Sect.4.6). This is realized with the help of a Hadamard gate, H. This circuit is shown in Fig. 12.2.

The circuit implement the following operations:

$$U_{XOR}(|0\rangle \otimes |0\rangle) = U_{XOR}(\frac{1}{\sqrt{2}}(|0\rangle + |1\rangle) \otimes |0\rangle).$$

$$= U_{XOR}\frac{1}{\sqrt{2}}(|00\rangle + |10\rangle),$$

$$= \frac{1}{\sqrt{2}}(|00\rangle + |11\rangle), \qquad (12.2)$$

where we used the difinitions of  $\boldsymbol{H}$  and  $\boldsymbol{U_{XOR}}$  in line 1 and line 3, respectively. We can use **controlled phase shift gate** with a phase shift of  $\pi$  ( $\boldsymbol{U_{CPS,\pi}}$ ) (see Section 16.4 in [1]) to implement the  $\boldsymbol{U_{XOR}}$  gate by combining it with other 1-qubit gates.

Example 12.1 Show that  $U_{XOR} = (I \otimes H)U_{CPS,\pi}(I \otimes H)$ . Firstly the matrix form of  $U_{XOR}$  is

$$U_{XOR} = \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & 1 & 0 & 0 \\ 0 & 0 & 0 & 1 \\ 0 & 0 & 1 & 0 \end{pmatrix}$$
 (12.3)




Fig.12.2 An entanglement circuit implemented using a  $U_{XOR}$  gate and an H gate. Note that the least significant bit (LSB) and the most significant bit (MSB) are on the top and bottom, respectively

and the matrix form of  $U_{CPS,\pi}$  is

$$U_{CPS,\pi} = \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & 1 & 0 & 0 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & e^{i\pi} \end{pmatrix},$$

$$= \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & 1 & 0 & 0 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & -1 \end{pmatrix}, \tag{12.4}$$

as  $e^{i\pi} = \cos \pi + i \sin \pi = -1$ . Therefore,

$$(I \otimes H)U_{CPS,\pi}(I \otimes H)$$

$$\begin{split} &= \begin{pmatrix} 1 & 0 \\ 0 & 1 \end{pmatrix} \otimes \frac{1}{\sqrt{2}} \begin{pmatrix} 1 & 1 \\ 1 & -1 \end{pmatrix} \boldsymbol{U_{CPS,\pi}} \begin{pmatrix} 1 & 0 \\ 0 & 1 \end{pmatrix} \otimes \frac{1}{\sqrt{2}} \begin{pmatrix} 1 & 1 \\ 1 & -1 \end{pmatrix}, \\ &= \frac{1}{\sqrt{2}} \begin{pmatrix} 1 & 1 & 0 & 0 \\ 1 & -1 & 0 & 0 \\ 0 & 0 & 1 & 1 \\ 0 & 0 & 1 & -1 \end{pmatrix} \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & 1 & 0 & 0 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & -1 \end{pmatrix} \frac{1}{\sqrt{2}} \begin{pmatrix} 1 & 1 & 0 & 0 \\ 1 & -1 & 0 & 0 \\ 0 & 0 & 1 & 1 \\ 0 & 0 & 1 & -1 \end{pmatrix}, \\ &= \frac{1}{2} \begin{pmatrix} 1 & 1 & 0 & 0 \\ 1 & -1 & 0 & 0 \\ 0 & 0 & 1 & 1 \\ 0 & 0 & 1 & -1 \end{pmatrix} \begin{pmatrix} 1 & 1 & 0 & 0 \\ 1 & -1 & 0 & 0 \\ 0 & 0 & 1 & 1 \\ 0 & 0 & 1 & -1 \end{pmatrix}, \\ &= \frac{1}{2} \begin{pmatrix} 2 & 0 & 0 & 0 \\ 0 & 2 & 0 & 0 \\ 0 & 0 & 2 & 0 \\ 0 & 0 & 2 & 0 \\ 0 & 0 & 0 & 1 \\ 0 & 0 & 1 & 0 \end{pmatrix}, \\ &= \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & 1 & 0 & 0 \\ 0 & 0 & 0 & 1 \\ 0 & 0 & 1 & 0 \end{pmatrix}, \\ &= \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & 1 & 0 & 0 \\ 0 & 0 & 0 & 1 \\ 0 & 0 & 1 & 0 \end{pmatrix}, \\ &= \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & 1 & 0 & 0 \\ 0 & 0 & 0 & 1 \\ 0 & 0 & 1 & 0 \end{pmatrix}, \\ &= \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & 0 & 0 & 1 \\ 0 & 0 & 1 & 0 \end{pmatrix}, \\ &= \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & 0 & 0 & 1 \\ 0 & 0 & 1 & 0 \end{pmatrix}, \\ &= \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & 0 & 0 & 1 \\ 0 & 0 & 1 & 0 \end{pmatrix}, \\ &= \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & 0 & 0 & 1 \\ 0 & 0 & 1 & 0 \end{pmatrix}, \\ &= \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & 0 & 0 & 1 \\ 0 & 0 & 1 & 0 \end{pmatrix}, \\ &= \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & 0 & 0 & 1 \\ 0 & 0 & 1 & 0 \end{pmatrix}, \\ &= \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & 0 & 0 & 1 \\ 0 & 0 & 1 & 0 \end{pmatrix}, \\ &= \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & 0 & 0 & 1 \\ 0 & 0 & 1 & 0 \end{pmatrix}, \\ &= \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & 0 & 0 & 1 \\ 0 & 0 & 1 & 0 \end{pmatrix}, \\ &= \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & 0 & 0 & 1 \\ 0 & 0 & 1 & 0 \end{pmatrix}, \\ &= \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & 0 & 0 & 1 \\ 0 & 0 & 1 & 0 \end{pmatrix}, \\ &= \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & 0 & 0 & 1 \\ 0 & 0 & 1 & 0 \end{pmatrix}, \\ &= \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & 0 & 0 & 1 \\ 0 & 0 & 1 & 0 \end{pmatrix}, \\ &= \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & 0 & 0 & 1 \\ 0 & 0 & 1 & 0 \end{pmatrix}, \\ &= \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & 0 & 0 & 1 \\ 0 & 0 & 0 & 1 \end{pmatrix}, \\ &= \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & 0 & 0 & 1 \\ 0 & 0 & 0 & 1 \end{pmatrix}, \\ &= \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & 0 & 0 & 1 \\ 0 & 0 & 0 & 1 \end{pmatrix}, \\ &= \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & 0 & 0 & 1 \\ 0 & 0 & 0 & 1 \end{pmatrix}, \\ &= \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & 0 & 0 & 1 \\ 0 & 0 & 0 & 1 \end{pmatrix}, \\ &= \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & 0 & 0 & 1 \\ 0 & 0 & 0 & 1 \end{pmatrix}, \\ &= \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & 0 & 0 & 1 \\ 0 & 0 & 0 & 1 \end{pmatrix}, \\ &= \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & 0 & 0 & 1 \\ 0$$

$$=U_{XOR}. (12.5)$$

Now, we will show that we can implement  $U_{CPS,\pi}$  using  $U_{Cphase}$  and other 1-qubit gates.

Example 12.2 Show that  $U_{CPS,\pi} = U_{Cphase}(I \otimes U_{PS,-\phi})(U_{PS,\phi-\pi} \otimes I)$ . Recall that the matrix form of the palse shift gate,  $U_{PS,\phi}$ , is

$$\begin{pmatrix} 1 & 0 \\ 0 & e^{i\phi} \end{pmatrix}. \tag{12.6}$$

Therefore,

$$I \otimes U_{PS,-\phi} = \begin{pmatrix} 1 & 0 \\ 0 & 1 \end{pmatrix} \otimes \begin{pmatrix} 1 & 0 \\ 0 & e^{-i\phi} \end{pmatrix} = \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & e^{-i\phi} & 0 & 0 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & e^{-i\phi} \end{pmatrix}, \quad (12.7)$$

and

$$(\mathbf{U}_{PS,\phi-\pi}\otimes\mathbf{I}) = \begin{pmatrix} 1 & 0 \\ 0 & e^{i(\phi-\pi)} \end{pmatrix} \otimes \begin{pmatrix} 1 & 0 \\ 0 & 1 \end{pmatrix} = \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & 1 & 0 & 0 \\ 0 & 0 & e^{i(\phi-\pi)} & 0 \\ 0 & 0 & 0 & e^{i(\phi-\pi)} \end{pmatrix}. (12.8)$$

Using Eqs.(12.1),(12.7), and (12.8), we have

$$U_{Cphase}(I \otimes U_{PS,-\phi})(U_{PS,\phi-\pi} \otimes I)$$

$$= \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & e^{i\phi} & 0 & 0 \\ 0 & 0 & e^{i(\pi-\phi)} & 0 \\ 0 & 0 & 0 & 1 \end{pmatrix} \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & e^{-i\phi} & 0 & 0 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & e^{-i\phi} \end{pmatrix} \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & 1 & 0 & 0 \\ 0 & 0 & e^{i(\phi-\pi)} & 0 \\ 0 & 0 & 0 & e^{i(\phi-\pi)} & 0 \\ 0 & 0 & e^{i(\pi-\phi)} & 0 \\ 0 & 0 & 0 & 1 \end{pmatrix} \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & e^{-i\phi} & 0 & 0 \\ 0 & 0 & e^{i(\phi-\pi)} & 0 \\ 0 & 0 & e^{-i\pi} \end{pmatrix},$$

$$= \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & 1 & 0 & 0 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & e^{-i\pi} \end{pmatrix},$$

$$= \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & 1 & 0 & 0 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & e^{i\pi} \end{pmatrix} = \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & 1 & 0 & 0 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & -1 \end{pmatrix},$$

$$= U_{CPS,\pi},$$

$$(12.9)$$




Fig.12.3 The equibalent circuit of Fig.12.2 implemented by 1-qubit gates and a  $U_{Cphase}$  gate

where at the end, we used the face that  $e^{-i\pi} = e^{i\pi}$ .

Therefore, we have successfully impelmented a  $U_{XOR}$  gate for entanglement Creation using the native 2-qubit gate for electron spin. Figure 12.3 shows the full entanglement circuit using 1-qubit gates and a  $U_{Cphase}$  gate.

### 12.3.2 Physical Impelementation of $U_{Cphase}$ Gate

#### 12.3.2.1 Setup and Individual 1-Qubit Operations

We now will try to omplement the  $U_{Cphase}$  gate in Eq. (12.1). We will following the appropriate in [3] and [4], however, with pretty significant modifications and simplifications. If there is only on thing that you can remember from this subsection, I hope you can appreciate that fact that we need to use the physics of a system to realize an entanglement gate and we need to adjust the condition so that it can achieve the purpose most effectively. The process of using the right physics and adjusting the conditions is called **Hamiltonian engineering**. Again, Hamiltonian refers to the total energy of the system. So the fancy word "Hamiltonian engineering" is nothing but setting up the system at the right energy at the right time to let it evolve in a desirable way.

Figure 12.4 shows the schematic of two qubits on a silicon wafer. The barrier gate is not shown for clarity. Same as the 1-qubit example in Sect. 12.2, T = 50 mK and  $B_0 = 1.4T$  and highly purified Si is used (with only 800 ppm of  $^{29}Si$ ).

Before working on a 2-qubit gate, we need to make sure we can perform 1-qubit operation on *individual* qubit. To do so, we need to have different electron spin resonance frequency, which is the Larmor frequency,  $\omega_L$ , for each qubit. Otherwise, we will be applying the same 1-qubit gate to both qubits at the same time. Equation (8.11) tells us that  $\omega_L$  depends on  $B_0$ , the g-factor, g, and the effective mass of the electron,  $m^*$ , which is repeated here for convenience.




Fig. 12.4 Schematic showing a 2-qubit system. The barrier gate is not used

$$\omega_L = \left| \frac{2ge\hbar}{4m^*} B_o \right| / \hbar. \tag{12.10}$$

 $B_0$  can be set to be different at each qubit by putting a micro-magent with a different strength nex to each qubit. However, this is not very scalable when millions of qubits need to be integrated. Instead of using micro-magnet, with some engineering, it is also possible to create a non-constant DC magnetic field

(but still constant and pointing in  $-\hat{z}$  direction) from qubit to qubit.  $m^*$  is likely to be the sam ebecause the crystal properties would not change much across the chip. Another approach is to change g which can be affected by the electric field it experiences through **Stark effect** [2]. This is very convenient because it means that we can just apply different plunger gate boltages (in combination with other electrodes) to achieve different plunger gate voltages (in combination with other electrodes) to achieve different  $\omega_L$  for each qubit. We can then change the frequency of  $I_{ESR}$  so that we can address individual qubits. This is called **spectral selectivity** as we are selecting qubits based on frequency.

For example, qubit 1 might have  $\omega_L = 0.34MHz$  and qubit 1 might have  $\omega_L = 0.36MHz$ . By setting  $I_{ESR}$  to oscillate at 0.34MHz, only qubit 1 will perform Rabi oscillation as it is at its spin resonance. Qubit 2 wil not as it is off-resonant.

#### 12.3.2.2 2-Qubit Physics

The physics and the mathematics of implementing the 2-qubit