YN-232I Magnetically Isolated USB to RS-232Converter

Packing List

Before you begin installing, please make sure that the following materials have been shepped:

YN-232I x1 USB cable x1 Driver&Manual CD x1 This Manual x1

If any of these are missing or damaged, contact your distributor or sales representative immediately.

Specifications

Compatibility: USB v2.0 standard

Interface: Network:USB Serial:RS-232
Port: One Independent RS-232 ports
Connector: Network: USB-type A connector

Serial: Screw terminal

Transmission speed: 600bps to 115.2Kbps
Parity bit: odd, even, none

 Data bit:
 5, 6, 7, 8

 Stop bit:
 1, 1.5, 2

 Isolation protection:
 2,500 V

Driver Support: Windows CE/2000/2003/XP/Vista/7/8 (32bit and 64bit)

Linux/Mac

Power Consumption: 1.5W @ 5V

Max. Distance: 50ft (15m) @ 19.2Kbps Case: Blue transparent ABS


Operating Temperature: $-30^{\circ}\text{C} \sim +70^{\circ}\text{C}$

Operating Humidity: 20% to 95% (non-condensing)

Overview

Your Neighbor Tech's YN-232I allows PC users to connect their RS-232 device to systems that use USB interface. By attaching the YN-232I to a PC, it will no longer be necessary to open the chassis or turn off the PC to install the hub. With the YN-232I , the user instantly gets one extra high-speed RS-232 ports. In addition, since the power is derived from the USB port, there are not any cumbersome power adapters. This makes the YN-232I especially suitable for PLCs, printers, POS system and industrial control devices.

Dimensions&Communication LED Status



RXLED	Flash when data from RS-232 device to YN232I
TXLED	Flash when data from YN232I to RS-232 device

Pin Defination

1,4,6	GND	Isolated RS-232 side GND, connect to device ground
2	TOUT	Isolated RS-232 side Data output(TX)
3	RIN	Isolated RS-232 side Data input(RX)

Application Wiring

YN-232I connect to RS-232 device with 3 wire interface,

TOUT --> RX, RIN <-- TX, GND <--> GND.

