



| PS1 | PS0 | BNO08X (BOOTN=1) | BNO08X bootloader (BOOTN=0) |
|-----|-----|------------------|-----------------------------|
| 0 | 0 | I ² C | I ² C |
| 0 | 1 | UART-RVC | Reserved |
| 1 | 0 | UART | UART |
| 1 | 1 | SPI | SPI |

Figure 1-5: Protocol selection for BNO08X

| Source | CLKSEL0 | CLKSEL1 |
|----------|------------------|----------------------|
| Crystal | 0 or unconnected | Connected to crystal |
| External | 1 | 1 |
| Internal | 1 | 0 or unconnected |

Figure 1-8: Clock Source Selection