Задание 1.

```
yukei@yukei:~/TEST/tmp$ cat hello.
#include <stdio.h>
#include <unistd.h>
int main(int argc, char *argv[]) {
         printf("Hello!\n");
          sleep(15);
          return 0;
vukei@vukei:~/TEST/tmp$ arm-linux-gnueabihf-gcc -static -o init hello.c
yukei@yukei:~/TEST/tmp$ echo init | cpio -o -H newc | gzip > initranfs.cpio.gz
901 блок
yukei@yukei:~/TEST/tmp$ ls
     hello.c
                       anfs.cpio.gz vexpress-v2p-ca9.dtb zImage
yukei@yukei:~/TEST/tmp$ QEMU_AUDIO_DRV=none qemu-system-arm -M vexpress-a9 -kern
el zImage -dtb vexpress-v2p-ca9.dtb -initrd initranfs.cpio.gz -append "console=t
tyAMA0" -nographic
Run /init as init process
Hello!
drm-clcd-pl111 10020000.clcd: DVI muxed to daughterboard 1 (core tile) CLCD
drm-clcd-pl111 10020000.clcd: initializing Versatile Express PL111
i2c 0-0039: deferred probe pending: sii902x: Failed to find remote bridge
amba 1000f000.wdt: deferred probe pending: (reason unknown)
amba 10020000.clcd: deferred probe pending: (reason unknown)
amba 100e0000.memory-controller: deferred probe pending: (reason unknown)
amba 100e1000.memory-controller: deferred probe pending: (reason unknown)
amba 100e5000.watchdog: deferred probe pending: (reason unknown)
Kernel panic - not syncing: Attempted to kill init! exitcode=0x00000000
CPU: 0 UID: 0 PID: 1 Comm: init Not tainted 6.17.0+ #2 NONE
Hardware name: ARM-Versatile Express
Call trace:
 unwind_backtrace from show_stack+0x10/0x14
 show_stack from dump_stack_lvl+0x50/0x64
 dump_stack_lvl from vpanic+0xc4/0x2c8
 vpanic from panic+0x2c/0x30
 panic from do_exit+0x974/0x978
 do_exit from do_group_exit+0x34/0x84
 do_group_exit from pid_child_should_wake+0x0/0x60
 --[ end Kernel panic - not syncing: Attempted to kill init! exitcode=0x000000000
 ]---
```

Задание 2.

```
yukei@yukei:~/TEST/busybox-1.36.1$ ARCH=arm make defconfig HOSTCC scripts/basic/fixdep HOSTCC scripts/basic/split-include
В menuconfig устанавливаем CrossCompilePrefix на arm-linux-gnueabihf- и устанавливаем статическую компиляцию.

yukei@yukei:~/TEST/busybox-1.36.1$ ARCH=arm make menuconfig
```

```
устанавливаем статическую компиляцию.
  HOSTLD scripts/kconfig/mconf
  HOSTCC scripts/kconfig/lxdialog/checklist.o
  HOSTCC scripts/kconfig/lxdialog/inputbox.o
  HOSTCC scripts/kconfig/lxdialog/lxdialog.o
  HOSTCC scripts/kconfig/lxdialog/menubox.o
  HOSTCC scripts/kconfig/lxdialog/msgbox.o
  HOSTCC scripts/kconfig/lxdialog/textbox.o
  HOSTCC scripts/kconfig/lxdialog/util.o
  HOSTCC scripts/kconfig/lxdialog/yesno.o
  HOSTLD scripts/kconfig/lxdialog/lxdialog
scripts/kconfig/mconf Config.in
# using defaults found in .config
*** End of configuration.
*** Execute 'make' to build the project or try 'make help'.
yukei@yukei:~/TEST/busybox-1.36.1$ make -j2
yukei@yukei:~/TEST/busybox-1.36.1$ make install
  ./ install//bin/arch -> busybox
  ./ install//bin/ash -> busybox
  ./ install//bin/base32 -> busybox
yukei@yukei:~/TEST/busybox-1.36.1/_install$ find . | cpio -o -H newc | gzip > in
itranfs.cpio.gz
3136 блоков
yukei@yukei:~/TEST/tmp$ QEMU_AUDIO_DRV=none qemu-system-arm -M vexpress-a9 -kern
el zImage -dtb vexpress-v2p-ca9.dtb -initrd initranfs.cpio.gz -append "console=t
tyAMAO rdinit=/bin/ash" -nographic
 - # ls
```

```
~ # ls
bin initranfs.cpio.gz sbin
dev root usr
~ #
```