COMP 3721 Introduction to Data Communications


04. Week 4

Learning Outcomes

- By the end of this lecture, you will be able to:
 - Explain what is data rate and what is signal rate.
 - Compute the bandwidth of a digital signal.
 - Explain line coding schemes and their characteristics.


Introduction

- A computer network is designed to send information from one point to another.
- This information needs to be converted to either a digital signal or an analog signal for transmission.
- This lecture: We will discuss digital-to-digital conversion (convert digital data to digital signals).




Digital-To-Digital Conversion

- Representing digital data by using digital signals.
- Line coding:
 - The process of converting digital data to digital signal.
 - A sequence of bits is converted to a digital signal.



Common Binary Line Code Formats



Some of the Common Characteristics of Line Coding Schemes

- 1. Signal element vs. Data element
- 2. Data rate vs. Signal rate
- 3. Bandwidth
- 4. Baseline wandering
- 5. Self-synchronization
- 6. DC components

Some of the Common Characteristics of Line Coding Schemes

- 1. Signal element vs. Data element
- 2. Data rate vs. Signal rate
- 3. Bandwidth
- 4. Baseline wandering
- 5. Self-synchronization
- 6. DC components

- Data element (bit)
 - The smallest entity that can represent a piece of information.
 - Data elements are what we need to send.
 - Two types: 0 and 1

- Data element (bit)
 - The smallest entity that can represent a piece of information.
 - Data elements are what we need to send.
 - Two types: 0 and 1
- Signal element (symbol, state)
 - It carries data elements.
 - The shortest unit (timewise) of a digital signal.

- Data element (bit)
 - The smallest entity that can represent a piece of information.
 - Data elements are what we need to send.
 - Two types: 0 and 1
- Signal element (symbol, state)

Data elements are what we **need** to send (logically). Signal elements are what we **can** send (physically).

- It carries data elements.
- The shortest unit (timewise) of a digital signal.

- Data element (bit)
 - The smallest entity that can represent a piece of information.
 - Data elements are what we need to send.
 - Two types: 0 and 1
- Signal element (symbol, state)

Data elements are what we **need** to send (logically). Signal elements are what we **can** send (physically).

- It carries data elements.
- The shortest unit (timewise) of a digital signal.
- **Ratio** (*r*)
 - The number of data elements carried by each signal element.
 - Different for each line coding scheme.


Signal Element vs. Data Element – Transportation Analogy


• An analogy: Suppose each data element is a person who needs to be carried from one place to another. We can think of a signal element as a vehicle that can carry people. When r = 1, it means each person is driving a vehicle. When r > 1, it means more than one person is travelling in a vehicle (a carpool, for example). We can also have the case where one person is driving a car and a trailer (r = 1/2).






r = 1 r > 1







a. One data element per one signal element (r = 1)




a. One data element per one signal element (r = 1)







a. One data element per one signal element (r = 1)




b. One data element per two signal elements $\left(r = \frac{1}{2}\right)$







c. Two data elements per one signal element (r = 2)




c. Two data elements per one signal element (r = 2)





c. Two data elements per one signal element (r = 2)



d. Four data elements per three signal elements $\left(r = \frac{4}{3}\right)$

Some of the Common Characteristics of Line Coding Schemes

- 1. Signal element vs. Data element
- 2. Data rate vs. Signal rate
- 3. Bandwidth
- 4. Baseline wandering
- 5. Self-synchronization
- 6. DC components

- Data rate (bit rate)
 - The number of data elements (bits) sent in 1 second.
 - Unit is **bps**.
 - Increase in the data rate → Increase in the speed of transmission

- Data rate (bit rate)
 - The number of data elements (bits) sent in 1 second.
 - Unit is **bps**.
 - Increase in the data rate → Increase in the speed of transmission
- Signal rate (modulation rate, pulse rate, baud rate)
 - The number of signal elements sent in 1 second.
 - Unit is baud.
 - Decrease in the signal rate \rightarrow Decrease in the bandwidth requirement

- Data rate (bit rate)
 - The number of data elements (bits) sent in 1 second.
 - Unit is bps.
 - Increase in the data rate → Increase in the speed of transmission
- Signal rate (modulation rate, pulse rate, baud rate)
 - The number of signal elements sent in 1 second.
 - Unit is baud.
 - Decrease in the signal rate → Decrease in the bandwidth requirement

A goal in data communications is to increase the data rate while decreasing the signal rate.

• The relationship between data rate (N) and signal rate (S):

$$S = N/r$$

• This relationship, of course, depends on the value of *r* and the pattern of the data.

• The relationship between data rate (N) and signal rate (S):

$$S = N/r$$

- This relationship, of course, depends on the value of *r* and the pattern of the data.
- Three cases:
 - 1. Worst case (having the maximum signal rate)
 - 2. Best case (having minimum signal rate)
 - 3. Average case (we are usually interested in)

• The relationship between data rate (N) and signal rate (S):

$$S = N/r$$

- This relationship, of course, depends on the value of *r* and the pattern of the data.
- Three cases:
 - 1. Worst case (having the maximum signal rate)
 - 2. Best case (having minimum signal rate)
 - 3. Average case (we are usually interested in)

$$S_{avg} = c \times N \times \frac{1}{r}$$

Case factor (different for each case)

Data Rate vs. Signal Rate – Example

• A signal is carrying data in which one data element is encoded as one signal element. If the bit rate is 100 kbps, what is the average value of the baud rate if c is 1/2?

Data Rate vs. Signal Rate – Example

• A signal is carrying data in which one data element is encoded as one signal element. If the bit rate is 100 kbps, what is the average value of the baud rate if c is 1/2?

Answer:

$$r = 1$$

 $S = c \times N \times \frac{1}{r} = \frac{1}{2} \times 100000 \times \frac{1}{1} = 50000 \text{ baud} = 50 \text{ kbaud}$

Some of the Common Characteristics of Line Coding Schemes

- 1. Signal element vs. Data element
- 2. Data rate vs. Signal rate
- 3. Bandwidth
- 4. Baseline wandering
- 5. Self-synchronization
- 6. DC components

• The actual bandwidth of a nonperiodic digital signal is continuous with an infinite range (theoretically).

- The actual bandwidth of a nonperiodic digital signal is continuous with an infinite range (theoretically).
- The effective bandwidth is finite.
 - Many of the components of a composite signal have such a small amplitude that they can be ignored.

- The actual bandwidth of a nonperiodic digital signal is continuous with an infinite range (theoretically).
- The effective bandwidth is finite.
 - Many of the components of a composite signal have such a small amplitude that they can be ignored.
- The baud rate, not the bit rate, determines the required bandwidth for a digital signal.

- The actual bandwidth of a nonperiodic digital signal is continuous with an infinite range (theoretically).
- The effective bandwidth is finite.
 - Many of the components of a composite signal have such a small amplitude that they can be ignored.
- The baud rate, not the bit rate, determines the required bandwidth for a digital signal.
- The bandwidth (range of frequencies) is proportional to the signal rate (baud rate).
 - We can replace S (signal rate) with B (bandwidth)

$$B = c \times N \times \frac{1}{r}$$

Bandwidth (Cont.)

• From the previous formula, we have the following,

$$N = \frac{1}{c} \times B \times r$$

Date rate of a channel

Bandwidth (Cont.)

• From the previous formula, we have the following,

$$N = \frac{1}{c} \times B \times r$$

Date rate of a channel

• Does the above formula agree with the Nyquist formula for N_{max} ?



Bandwidth (Cont.)

• From the previous formula, we have the following,

$$N = \frac{1}{c} \times B \times r$$

Date rate of a channel

- Does the above formula agree with the Nyquist formula for N_{max} ?
 - A signal with *L* levels can carry log₂ *L* bits (data elements) per level.
 - If each level corresponds to one signal element and we assume the average case (c = 1/2), we have the following,

$$N_{\text{max}} = \frac{1}{c} \times B \times r = 2 \times B \times \log_2 L$$

Maximum date rate of a channel

Nyquist formula

Some of the Common Characteristics of Line Coding Schemes

- 1. Signal element vs. Data element
- 2. Data rate vs. Signal rate
- 3. Bandwidth
- 4. Baseline wandering
- 5. Self-synchronization
- 6. DC components

Baseline Wandering

Baseline

- In decoding a digital signal, the receiver calculates a running average of the received signal power. This average is called the baseline.
- The incoming signal power is evaluated against this baseline to determine the value of the data element.

Baseline Wandering

Baseline

- In decoding a digital signal, the receiver calculates a running average of the received signal power. This average is called the baseline.
- The incoming signal power is evaluated against this baseline to determine the value of the data element.
- Baseline wandering: A drift in the baseline caused by a long string of Os or a long string of 1s.
 - Difficult for the receiver to decode the received signal correctly.

Baseline Wandering

Baseline

- In decoding a digital signal, the receiver calculates a running average of the received signal power. This average is called the baseline.
- The incoming signal power is evaluated against this baseline to determine the value of the data element.
- Baseline wandering: A drift in the baseline caused by a long string of Os or a long string of 1s.
 - Difficult for the receiver to decode the received signal correctly.

A good line coding scheme needs to prevent baseline wandering.

Some of the Common Characteristics of Line Coding Schemes

- 1. Signal element vs. Data element
- 2. Data rate vs. Signal rate
- 3. Bandwidth
- 4. Baseline wandering
- 5. Self-synchronization
- 6. DC components


Self-Synchronization

- The receiver clock must be synchronized with the sender clock (the receiver's bit intervals must correspond exactly to the sender's bit intervals).
 - To correctly interpret the received signals.
- Self-synchronization
 - Self-synchronizing digital signal includes timing information in the data being transmitted.
 - Transitions (changes in voltage level) in the signal that alert the receiver to the beginning, middle, or end of the pulse (if the receiver's clock is out of synchronization, these points can reset the clock).


Self-Synchronization (Cont.)

- If the receiver clock is **faster** or **slower**, the bit intervals are not matched, and the receiver might **misinterpret** the signals.
- Figure in the next slide shows a situation in which the receiver has a shorter bit duration.
- The sender sends 10110001, while the receiver receives 110111000011.

Self-Synchronization (Cont.)



Self-Synchronization (Cont.)



Receiver has a shorter bit duration than the sender.

Self-Synchronization – Example

• In a digital transmission, the receiver clock is 0.1 percent faster than the sender clock. How many extra bits per second does the receiver receive if the data rate is 1 kbps? How many if the data rate is 1 Mbps?

Self-Synchronization – Example

- In a digital transmission, the receiver clock is 0.1 percent faster than the sender clock. How many extra bits per second does the receiver receive if the data rate is 1 kbps? How many if the data rate is 1 Mbps?
- Answer:
- 1 kbps → 1000 bits sent in 1 s
 1000 × (1 + 0.1%) bits received in 1 s = 1001 bits received in 1 s
 → 1 extra bps
- 1 Mbps → 1000000 bits sent in 1 s
 1000000 × (1 + 0.1%) bits received in 1 s = 1001000 bits received in 1 s
 → 1000 extra bps

Some of the Common Characteristics of Line Coding Schemes

- 1. Signal element vs. Data element
- 2. Data rate vs. Signal rate
- 3. Bandwidth
- 4. Baseline wandering
- 5. Self-synchronization
- 6. DC components

DC Components


- The very low frequencies (around zero) that are created by the spectrum as a result of a duration of fixed voltage level in a digital signal are called Direct Current (DC) Components (or constant components).
- Causes problems for a system that cannot pass low frequencies or uses electrical coupling.
 - e.g., A line that cannot pass frequencies below 200 Hz. (For these systems, we need a line coding scheme with no DC component.)
- With no DC component, a signal has an average amplitude of 0.

DC component (bias): The mean amplitude of the waveform.


If the mean amplitude is zero, there is no DC bias (DC balanced or DC free waveform).


DC Components – Example

A composite analog signal.




Same signal with added DC component.






Some of the Line Coding Schemes (Techniques)



Unipolar (On-Off Keying) Schemes


- All the signal levels are on one side of the time axis, either above or below.
- Traditionally, a unipolar scheme was designed as a non-return-to-zero (NRZ) scheme
 - NRZ because the signal does not return to zero at the middle of the bit.
- Positive voltage defines bit 1 and the zero voltage defines bit 0.



Polar Schemes – NRZ-L and NRZ-I

- The voltages are on both sides of the time axis.
- NRZ-L (Level)
 - Two levels of voltage amplitude.
 - Positive voltage level for 0 and negative voltage level for 1.
- NRZ-I (Invert)
 - The change or lack of change in the level of the voltage determines the value of the bit.
 - No change for 0 and change for 1.


Figure 4.6 Polar NRZ-L and NRZ-I schemes



Polar Schemes – Problems

- DC components
 - Power density is very high around frequencies close to zero.
- Baseline wandering
 - A long sequence of 0s or 1s
- No self-synchronization
 - A long sequence of 0s or 1s

Polar Schemes – Manchester and Differential Manchester



Popular techniques for data transmission.

It is used for IR protocols, RFID, and NFC system.

NRZ-I and differential Manchester are classified as differential encoding

Used in 802.5 with Twisted Pair.

Polar Schemes – Manchester and Differential Manchester (Cont.)


- Have Self-Synchronization
 - Provided by the transition at the middle of the bit.
- No baseline wandering
- No DC component
 - Each bit has a positive and negative voltage contribution.
- Drawback
 - The signal rate for Manchester and differential Manchester is higher compared with some other polar schemes, e.g., NRZ-L.

Bipolar (Multilevel Binary) Schemes

- Three voltage levels: positive, negative, zero.
 - The voltage level for one data element (bit) is at zero.
 - The voltage level for the other element alternates between positive and negative.

Bipolar (Multilevel Binary) Schemes – AMI

- Alternate Mark Inversion (AMI) alternate 1 inversion
 - 0 → a neutral zero voltage



Summary

- Line coding schemes (for digital-to-digital conversion) and their common characteristics.
 - Unipolar, polar, and bipolar schemes.

References

[1] Behrouz A.Forouzan, Data Communications & Networking with TCP/IP Protocol Suite, 6th Ed, 2022, McGraw-Hill companies.

Reading

- Chapter 2 of the textbook, section 2.3.1.
- Chapter 2 of the textbook, section 2.8 (Practice Test)