

InvenSense Inc.

1745 Technology Drive, San Jose, CA 95110 U.S.A.
Tel: +1 (408) 988-7339 Fax: +1 (408) 988-8104
Website: www.invensense.com

Document Number: RM-MPU-9250A-00

Revision: 1.4

Release Date: 9/9/2013

MPU-9250 Register Map and Descriptions Revision 1.4



Document Number: RM-MPU-9250A-00

Revision: 1.4 Release Date: 9/9/2013

CONTENTS

1	REVIS	SION HISTORY	5
2	PURF	POSE AND SCOPE	6
3	REGI	STER MAP FOR GYROSCOPE AND ACCELEROMETER	7
4		STER DESCRIPTIONS	
	4.1	REGISTERS 0 TO 2 – GYROSCOPE SELF-TEST REGISTERS	10
	4.2	REGISTERS 13 TO 15 – ACCELEROMETER SELF-TEST REGISTERS	10
	4.3	REGISTERS 19 TO 24 – GYRO OFFSET REGISTERS	11
	4.4	REGISTER 25 – SAMPLE RATE DIVIDER	12
	4.5	REGISTER 26 – CONFIGURATION	12
	4.6	REGISTER 27 – GYROSCOPE CONFIGURATION	13
	4.7	REGISTER 28 – ACCELEROMETER CONFIGURATION	14
	4.8	REGISTER 29 – ACCELEROMETER CONFIGURATION 2	14
	4.9	REGISTER 30 – LOW POWER ACCELEROMETER ODR CONTROL	16
	4.10	REGISTER 31 – WAKE-ON MOTION THRESHOLD	17
	4.11	REGISTER 35 – FIFO ENABLE	17
	4.12	REGISTER 36 – I2C MASTER CONTROL	18
	4.13	REGISTERS 37 TO 39 – I ² C SLAVE 0 CONTROL	20
	REGIST	ER 37 - I2C_SLV0_ADDR	20
	REGIST	ER 38 - I2C_SLV0_REG	20
	REGIST	ER 39 - I2C_SLV0_CTRL	20
	4.14	REGISTERS 40 TO 42 – I ² C SLAVE 1 CONTROL	21
	REGIST	ER 40 - I2C_SLV1_ADDR	21
	REGIST	ER 41 - I2C_SLV1_REG	22
	REGIST	ER 42 - I2C_SLV1_CTRL	22
	4.15	REGISTERS 43 TO 45 – I ² C SLAVE 2 CONTROL	23
	REGIST	ER 43 - I2C_SLV2_ADDR	23
	REGIST	ER 44 - I2C_SLV2_REG	24
	REGIST	ER 45 - I2C_SLV2_CTRL	24
	4.16	REGISTERS 46 TO 48 – I ² C SLAVE 3 CONTROL	25
	REGIST	ER 46 - I2C_SLV3_ADDR	25
	REGIST	er 47 - I2C_SLV3_REG	25
	REGIST	ER 48 - I2C_SLV3_CTRL	25
	4.17	REGISTERS 49 TO 53 – I ² C SLAVE 4 CONTROL	26



Document Number: RM-MPU-9250A-00 Revision: 1.4 Release Date: 9/9/2013

	REGIST	ER 49 - I2C_SLV4_ADDR	26
	REGIST	ER 50 - I2C_SLV4_REG	26
	REGIST	ER 51 - I2C_SLV4_DO	27
	REGIST	ER 52 - I2C_SLV4_CTRL	27
	REGIST	ER 53 - I2C_SLV4_DI	27
	4.18	REGISTER 54 – I ² C MASTER STATUS	28
	4.19	REGISTER 55 – INT PIN / BYPASS ENABLE CONFIGURATION	29
	4.20	REGISTER 56 – INTERRUPT ENABLE	29
	4.21	REGISTER 58 – INTERRUPT STATUS	30
	4.22	REGISTERS 59 TO 64 – ACCELEROMETER MEASUREMENTS	31
	4.23	REGISTERS 65 AND 66 – TEMPERATURE MEASUREMENT	33
	4.24	REGISTERS 67 TO 72 – GYROSCOPE MEASUREMENTS	33
	4.25	REGISTERS 73 TO 96 – EXTERNAL SENSOR DATA	35
	4.26	REGISTER 99 – I ² C SLAVE 0 DATA OUT	37
	4.27	REGISTER 100 – I ² C SLAVE 1 DATA OUT	37
	4.28	REGISTER 101 – I ² C SLAVE 2 DATA OUT	37
	4.29	REGISTER 102 – I ² C SLAVE 3 DATA OUT	37
	4.30	REGISTER 103 – I ² C MASTER DELAY CONTROL	38
	4.31	REGISTER 104 – SIGNAL PATH RESET	39
	4.32	REGISTER 105 – ACCELEROMETER INTERRUPT CONTROL	39
	4.33	REGISTER 106 – USER CONTROL	39
	4.34	REGISTER 107 – POWER MANAGEMENT 1	40
	4.35	REGISTER 108 – POWER MANAGEMENT 2	41
	4.36	REGISTER 114 AND 115 – FIFO COUNT REGISTERS	42
	4.37	REGISTER 116 – FIFO READ WRITE	43
	4.38	REGISTER 117 – WHO AM I	44
	4.39	REGISTERS 119, 120, 122, 123, 125, 126 ACCELEROMETER OFFSET REGISTERS	44
5	REGI	STER MAP FOR MAGNETOMETER	47
	5.1	REGISTER MAP DESCRIPTION	48
	5.2	DETAILED DESCRIPTIONS FOR MAGNETOMETER REGISTERS	49
	5.3	WIA: DEVICE ID	49
	5.4	INFO: Information	49
	5.5	ST1: STATUS 1	49
	5.6	HXL TO HZH: MEASUREMENT DATA	50



Document Number: RM-MPU-9250A-00 Revision: 1.4 Release Date: 9/9/2013

6	ADVA	NCED HARDWARE FEATURES	54
	5.13	ASAX, ASAY, ASAZ: SENSITIVITY ADJUSTMENT VALUES	53
		I2CDIS: I ² C DISABLE	
		TS1, TS2: TEST 1, 2	
	5.10	ASTC: Self-Test Control	52
	5.9	CNTL2: CONTROL 2	52
	5.8	CNTL1: Control 1	51
	5.7	ST2: Status 2	51



Document Number: RM-MPU-9250A-00 Revision: 1.4 Release Date: 9/9/2013

Revision History

Revision Date	Revision	Description
9/9/2013	1.4	Initial release



Document Number: RM-MPU-9250A-00

Revision: 1.4

Release Date: 9/9/2013

2 Purpose and Scope

This document provides preliminary information regarding the register map and descriptions for the Motion Processing Unit™ MPU-9250™. This document should be used in conjunction with the MPU-9250 Product Specification (PS-MPU-9250A-00) for detailed features, specifications, and other product information.



Document Number: RM-MPU-9250A-00

Revision: 1.4 Release Date: 9/9/2013

Register Map for Gyroscope and Accelerometer 3

The following table lists the register map for the gyroscope and accelerometer in the MPU-9250 MotionTracking device.

Addr (Hex)	Addr (Dec.)	Register Name	Serial I/F	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
00	0	SELF_TEST_X_GYRO	R/W				xg_st_d	ata [7:0]			
01	1	SELF_TEST_Y_GYRO	R/W				yg_st_d	ata [7:0]			
02	2	SELF_TEST_Z_GYRO	R/W				zg_st_d	ata [7:0]			
0D	13	SELF_TEST_X_ACCEL	R/W				XA_ST_D	ATA [7:0]			
0E	14	SELF_TEST_Y_ACCEL	R/W				YA_ST_D	ATA [7:0]			
0F	15	SELF_TEST_Z_ACCEL	R/W				ZA_ST_D	ATA [7:0]			
13	19	XG_OFFSET_H	R/W				X_OFFS_	USR [15:8]			
14	20	XG_OFFSET_L	R/W				X_OFFS_	USR [7:0]			
15	21	YG_OFFSET_H	R/W				Y_OFFS_	USR [15:8]			
16	22	YG_OFFSET_L	R/W				Y_OFFS_	USR [7:0]			
17	23	ZG_OFFSET_H	R/W				Z_OFFS_	USR [15:8]			
18	24	ZG_OFFSET_L	R/W				Z_OFFS_	USR [7:0]			
19	25	SMPLRT_DIV	R/W				SMPLRT	_DIV[7:0]			
1A	26	CONFIG	R/W	=	FIFO_ MODE	E	CT_SYNC_SET[2	::0]		DLPF_CFG[2:0]	
1B	27	GYRO_CONFIG	R/W	XGYRO_Ct en	YGYRO_Ct en	ZGYRO_Ct en	GYRO_FS	S_SEL [1:0]	-	FCHOIC	E_B[1:0]
1C	28	ACCEL_CONFIG	R/W	ax_st_en	ay_st_en	az_st_en	ACCEL_F	S_SEL[1:0]		-	
1D	29	ACCEL_CONFIG 2	R/W		,	-		ACCEL_F	CHOICE_B	A_DLP	F_CFG
1E	30	LP_ACCEL_ODR	R/W			-			Lposc_c	ksel [3:0]	
1F	31	WOM_THR	R/W				WOM_Thre	eshold [7:0]			
23	35	FIFO_EN	R/W	TEMP _FIFO_EN	GYRO_XO UT	GYRO_YO UT	GYRO_ZO UT	ACCEL	SLV2	SLV1	SLV0
24	36	I2C_MST_CTRL	R/W	MULT _MST_EN	WAIT _FOR_ES	SLV_3 _FIFO_EN	I2C_MST _P_NSR		I2C_MST	_CLK[3:0]	
25	37	I2C_SLV0_ADDR	R/W	I2C_SLV0 _RNW				I2C_ID_0 [6:0]			
26	38	I2C_SLV0_REG	R/W				I2C_SLV0	_REG[7:0]			
27	39	I2C_SLV0_CTRL	R/W	I2C_SLV0 _EN	I2C_SLV0 _BYTE_SW	I2C_SLV0 _REG_DIS	I2C_SLV0 _GRP		I2C_SLV0	_LENG[3:0]	
28	40	I2C_SLV1_ADDR	R/W	I2C_SLV1 _RNW				I2C_ID_1 [6:0]			
29	41	I2C_SLV1_REG	R/W				I2C_SLV1	_REG[7:0]			
2A	42	I2C_SLV1_CTRL	R/W	I2C_SLV1 _EN	I2C_SLV1 _BYTE_SW	I2C_SLV1 _REG_DIS	I2C_SLV1 _GRP		I2C_SLV1	_LENG[3:0]	
2B	43	I2C_SLV2_ADDR	R/W	I2C_SLV2 _RNW				I2C_ID_2 [6:0]			
2C	44	I2C_SLV2_REG	R/W				I2C_SLV2	_REG[7:0]			
2D	45	I2C_SLV2_CTRL	R/W	I2C_SLV2 _EN	I2C_SLV2 _BYTE_SW	I2C_SLV2 _REG_DIS	I2C_SLV2 _GRP		I2C_SLV2	_LENG[3:0]	
2E	46	I2C_SLV3_ADDR	R/W	I2C_SLV3 _RNW							
2F	47	I2C_SLV3_REG	R/W		I2C_SLV3_REG[7:0]						
30	48	I2C_SLV3_CTRL	R/W	I2C_SLV3 _EN	3 I2C_SLV3 I2C_SLV3 I2C_SLV3 I2C_SLV3 I2C_SLV3_LENG [3:0]						
31	49	I2C_SLV4_ADDR	R/W	I2C_SLV4 _RNW	2C SLV4						
32	50	I2C_SLV4_REG	R/W	I2C_SLV4_REG[7:0]							
33	51	I2C_SLV4_DO	R/W		I2C_SLV4_DO[7:0]						
34	52	I2C_SLV4_CTRL	R/W	I2C_SLV4 _EN	SLV4_DON						



Document Number: RM-MPU-9250A-00 Revision: 1.4 Release Date: 9/9/2013

Addr (Hex)	Addr (Dec.)	Register Name	Serial I/F	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
35	53	I2C_SLV4_DI	R		I2C_SLV4_DI[7:0]					•	
36	54	I2C_MST_STATUS	R	PASS_ THROUGH	I2C_SLV4 _DONE	I2C_LOST _ARB	I2C_SLV4 _NACK	I2C_SLV3 _NACK	I2C_SLV2 _NACK	I2C_SLV1 _NACK	I2C_SLV0 _NACK
37	55	INT_PIN_CFG	R/W	ACTL	OPEN	LATCH _INT_EN	INT_ANYR D _2CLEAR	ACTL_FSY NC	FSYNC _INT_MOD E_EN	BYPASS _EN	-
38	56	INT_ENABLE	R/W	-	WOM_EN	-	FIFO _OFLOW _EN	FSYNC_INT _EN	-	-	RAW_RDY_ EN
3A	58	INT_STATUS	R	-	WOM_INT	-	FIFO _OFLOW _INT	FSYNC _INT	-	-	RAW_DATA _RDY_INT
3B	59	ACCEL_XOUT_H	R				ACCEL_XC	UT_H[15:8]			
3C	60	ACCEL_XOUT_L	R				ACCEL_X	OUT_L[7:0]			
3D	61	ACCEL_YOUT_H	R				ACCEL_YC	UT_H[15:8]			
3E	62	ACCEL_YOUT_L	R				ACCEL_Y	OUT_L[7:0]			
3F	63	ACCEL_ZOUT_H	R				ACCEL_ZC	UT_H[15:8]			
40	64	ACCEL_ZOUT_L	R				ACCEL_Z	OUT_L[7:0]			
41	65	TEMP_OUT_H	R				TEMP_OL	JT_H[15:8]			
42	66	TEMP_OUT_L	R				TEMP_O	UT_L[7:0]			
43	67	GYRO_XOUT_H	R				GYRO_XO	UT_H[15:8]			
44	68	GYRO_XOUT_L	R				GYRO_X	OUT_L[7:0]			
45	69	GYRO_YOUT_H	R				GYRO_YO	UT_H[15:8]			
46	70	GYRO_YOUT_L	R				GYRO_YO	OUT_L[7:0]			
47	71	GYRO_ZOUT_H	R				GYRO_ZO	UT_H[15:8]			
48	72	GYRO_ZOUT_L	R				GYRO_ZO	OUT_L[7:0]			
49	73	EXT_SENS_DATA_00	R				EXT_SENS_I	DATA_00[7:0]			
4A	74	EXT_SENS_DATA_01	R				EXT_SENS_I	DATA_01[7:0]			
4B	75	EXT_SENS_DATA_02	R				EXT_SENS_I	DATA_02[7:0]			
4C	76	EXT_SENS_DATA_03	R				EXT_SENS_I	DATA_03[7:0]			
4D	77	EXT_SENS_DATA_04	R				EXT_SENS_I	DATA_04[7:0]			
4E	78	EXT_SENS_DATA_05	R				EXT_SENS_I	DATA_05[7:0]			
4F	79	EXT_SENS_DATA_06	R				EXT_SENS_I	DATA_06[7:0]			
50	80	EXT_SENS_DATA_07	R				EXT_SENS_I	DATA_07[7:0]			
51	81	EXT_SENS_DATA_08	R				EXT_SENS_I	DATA_08[7:0]			
52	82	EXT_SENS_DATA_09	R				EXT_SENS_I	DATA_09[7:0]			
53	83	EXT_SENS_DATA_10	R				EXT_SENS_I	DATA_10[7:0]			
54	84	EXT_SENS_DATA_11	R				EXT_SENS_I	DATA_11[7:0]			
55	85	EXT_SENS_DATA_12	R				EXT_SENS_I	DATA_12[7:0]			
56	86	EXT_SENS_DATA_13	R				EXT_SENS_I	DATA_13[7:0]			
57	87	EXT_SENS_DATA_14	R				EXT_SENS_I	DATA_14[7:0]			
58	88	EXT_SENS_DATA_15	R				EXT_SENS_I	DATA_15[7:0]			
59	89	EXT_SENS_DATA_16	R				EXT_SENS_I	DATA_16[7:0]			
5A	90	EXT_SENS_DATA_17	R				EXT_SENS_I	DATA_17[7:0]			
5B	91	EXT_SENS_DATA_18	R				EXT_SENS_I	DATA_18[7:0]			
5C	92	EXT_SENS_DATA_19	R				EXT_SENS_I	DATA_19[7:0]			
5D	93	EXT_SENS_DATA_20	R	EXT_SENS_DATA_20[7:0]							
5E	94	EXT_SENS_DATA_21	R	EXT_SENS_DATA_21[7:0]							
5F	95	EXT_SENS_DATA_22	R	EXT_SENS_DATA_22[7:0]							
60	96	EXT_SENS_DATA_23	R	EXT_SENS_DATA_23[7:0]							
63	99	I2C_SLV0_DO	R/W	I2C_SLV0_DO[7:0]							
64	100	I2C_SLV1_DO	R/W				I2C_SLV	1_DO[7:0]			
65	101	I2C_SLV2_DO	R/W				I2C_SLV	2_DO[7:0]			



Document Number: RM-MPU-9250A-00

Revision: 1.4

Release Date: 9/9/2013

Addr (Hex)	Addr (Dec.)	Register Name	Serial I/F	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
66	102	I2C_SLV3_DO	R/W				I2C_SLV	3_DO[7:0]			
67	103	I2C_MST_DELAY_CTRL	R/W	DELAY_ES _SHADOW	-	-	I2C_SLV4 _DLY_EN	I2C_SLV3 _DLY_EN	I2C_SLV2 _DLY_EN	I2C_SLV1 _DLY_EN	I2C_SLV0 _DLY_EN
68	104	SIGNAL_PATH_RESET	R/W	-	-	-	-	-	GYRO _RST	ACCEL _RST	TEMP _RST
69	105	MOT_DETECT_CTRL	R/W	ACCEL_INT EL_EN	ACCEL_INT EL_MODE		-		-		-
6A	106	USER_CTRL	R/W	-	FIFO_EN	I2C_MST _EN	I2C_IF _DIS	-	FIFO _RST	I2C_MST _RST	SIG_COND _RST
6B	107	PWR_MGMT_1	R/W	H_RESET	SLEEP	CYCLE	GYRO_ STANDBY	PD_PTAT		CLKSEL[2:0]	
6C	108	PWR_MGMT_2	R/W		-	DIS_XA	DIS_YA	DIS_ZA	DIS_XG	DIS_YG	DIS_ZG
72	114	FIFO_COUNTH	R/W		-				FIFO_CNT[12:8]		
73	115	FIFO_COUNTL	R/W				FIFO_C	CNT[7:0]			
74	116	FIFO_R_W	R/W				D[7:0]			
75	117	WHO_AM_I	R				WHOA	MI[7:0]			
77	119	XA_OFFSET_H	R/W				XA_OF	S [14:7]			
78	120	XA_OFFSET_L	R/W		XA_OFFS [6:0] -					-	
7A	122	YA_OFFSET_H	R/W	YA_OFFS [14:7]							
7B	123	YA_OFFSET_L	R/W		YA_OFFS [6:0]				-		
7D	125	ZA_OFFSET_H	R/W		ZA_OFFS [14:7]				•		
7E	126	ZA_OFFSET_L	R/W				ZA_OFFS [6:0]				-

Table 1 MPU-9250 mode register map for Gyroscope and Accelerometer

Note: Register Names ending in _H and _L contain the high and low bytes, respectively, of an internal register value.

In the detailed register tables that follow, register names are in capital letters, while register values are in capital letters and italicized. For example, the ACCEL_XOUT_H register (Register 59) contains the 8 most significant bits, ACCEL_XOUT[15:8], of the 16-bit X-Axis accelerometer measurement, ACCEL_XOUT.

The reset value is 0x00 for all registers other than the registers below.

- Register 107 (0x01) Power Management 1
- Register 117 (0x71) WHO_AM_I



Document Number: RM-MPU-9250A-00

Revision: 1.4

Release Date: 9/9/2013

4 Register Descriptions

This section describes the function and contents of each register within the MPU-9250. All the descriptions relate to the default MPU-9250 mode of operation.

4.1 Registers 0 to 2 - Gyroscope Self-Test Registers

Serial IF: R/W Reset value: 0x00

REGISTER	BITS	FUNCTION
SELF_TEST_X_GYRO	XG_ST_DATA[7:0]	The value in this register indicates the self test output generated during manufacturing tests. This value is to be used to check against subsequent self test outputs performed by the end user.
SELF_TEST_Y_GYRO	YG_ST_DATA[7:0]	The value in this register indicates the self test output generated during manufacturing tests. This value is to be used to check against subsequent self test outputs performed by the end user.
SELF_TEST_Z_GYRO	ZG_ST_DATA[7:0]	The value in this register indicates the self test output generated during manufacturing tests. This value is to be used to check against subsequent self test outputs performed by the end user.

For details of the MPU-9250 self-test implementation, please refer to the following document: AN-MPU-9250A-03, MPU-9250 Accelerometer, Gyroscope and Compass Self-Test Implementation.

4.2 Registers 13 to 15 – Accelerometer Self-Test Registers

Serial IF: R/W Reset value: 0x00

REGISTER	BITS	FUNCTION
SELF_TEST_X_ACCEL	XA_ST_DATA[7:0]	The value in this register indicates the self test output generated during manufacturing tests. This value is to be used to check against subsequent self test outputs performed by the end user.
SELF_TEST_Y_ACCEL	YA_ST_DATA[7:0]	The value in this register indicates the self test output generated during manufacturing tests. This value is to be used to check against subsequent self test outputs performed by the end user.
SELF_TEST_Z_ACCEL	ZA_ST_DATA[7:0]	The value in this register indicates the self test output generated during manufacturing tests. This value is to be used to check against subsequent self test outputs performed by the end user.

For details of the MPU-9250 self-test implementation, please refer to the following document: AN-MPU-9250A-03, MPU-9250 Accelerometer, Gyroscope and Compass Self-Test Implementation.



Document Number: RM-MPU-9250A-00

Revision: 1.4 Release Date: 9/9/2013

Registers 19 to 24 - Gyro Offset Registers 4.3

Serial IF: R/W Reset value: 0x00

BIT	NAME	FUNCTION				
		High byte, Low	byte in USR register (14h)			
		OffsetLSB=	X_OFFS_USR * 4 / 2^FS_SEL			
		OffsetDPS=	X_OFFS_USR * 4 / 2^FS_SEL / Gyro_Sensitivity			
[7:0]	V OFFC HCD[45:0]	Nominal	FS_SEL = 0			
[7:0]	X_OFFS_USR[15:8]	Conditions	Gyro_Sensitivity = 2^16 LSB / 500dps			
		Max	999.969 dps			
		Min	-1000 dps			
		Step	0.0305 dps			
[7:0]	X_OFFS_USR[7:0]	Low byte, High	byte in USR register (13h)			
		High byte, Low	byte in USR register (16h)			
		OffsetLSB=	Y_OFFS_USR * 4 / 2^FS_SEL			
	Y_OFFS_USR[15:8]	OffsetDPS=	Y_OFFS_USR * 4 / 2^FS_SEL / Gyro_Sensitivity			
[7:0]		Nominal	FS_SEL = 0			
[7.0]		Conditions	Gyro_Sensitivity = 2^16 LSB / 500dps			
		Max	999.969 dps			
		Min	-1000 dps			
		Step	0.0305 dps			
[7:0]	Y_OFFS_USR[7:0]	Low byte, High	byte in USR register (15h)			
		High byte, Low byte in USR register (18h)				
		OffsetLSB=	Z_OFFS_USR * 4 / 2^FS_SEL			
		OffsetDPS=	Z_OFFS_USR * 4 / 2^FS_SEL / Gyro_Sensitivity			
[7:0]	Z_OFFS_USR[15:8]	Nominal	FS_SEL = 0			
[7.0]	Z_OFF3_U3K[15.6]	Conditions	Gyro_Sensitivity = 2^16 LSB / 500dps			
		Max	999.969 dps			
		Min	-1000 dps			
		Step	0.0305 dps			
[7:0]	Z_OFFS_USR[7:0]	Low byte, High	byte in USR register (17h)			



Document Number: RM-MPU-9250A-00

Revision: 1.4

Release Date: 9/9/2013

These registers are used to remove DC bias from the gyro sensor data output for X, Y and Z axes. The values in these registers are subtracted from the gyro sensor values before going into the sensor registers. Please refer to registers 67 to 72 for units.

4.4 Register 25 - Sample Rate Divider

Serial IF: R/W Reset value: 0x00

BIT	NAME	FUNCTION
[7:0]	SMPLRT_DIV[7:0]	Divides the internal sample rate (see register CONFIG) to generate the sample rate that controls sensor data output rate, FIFO sample rate. NOTE: This register is only effective when Fchoice = 2'b11 (fchoice_b register bits are 2'b00), and (0 < dlpf_cfg < 7), such that the average filter's output is selected (see chart below).
		This is the update rate of sensor register.
		SAMPLE_RATE= Internal_Sample_Rate / (1 + SMPLRT_DIV)

Data should be sampled at or above sample rate; SMPLRT_DIV is only used for1kHz internal sampling.

4.5 Register 26 - Configuration

BIT	NAME	FUNCTION
[7]	-	Reserved
[6]	FIFO_MODE	When set to '1', when the fifo is full, additional writes will not be written to fifo. When set to '0', when the fifo is full, additional writes will be written to the fifo, replacing the oldest data.



Document Number: RM-MPU-9250A-00

Revision: 1.4

Release Date: 9/9/2013

FE 01	EVE OVALO OFTIO OL	TE 11 (1 E0)	(1)		
[5:3]	EXT_SYNC_SET[2:0]	Enables the FS	YNC pin data to be sa	mplea.	
			EXT_SYNC_SET	FSYNC bit location	
			0	function disabled	
			1	TEMP_OUT_L[0]	
			2	GYRO_XOUT_L[0]	
			3	GYRO_YOUT_L[0]	
			4	GYRO_ZOUT_L[0]	
			5	ACCEL_XOUT_L[0]	
			6	ACCEL_YOUT_L[0]	
			7	ACCEL_ZOUT_L[0]	
		Fsync toggles, t latched value is	he latched value togg captured by the samp	t strobes. This will be only the strobes. This will be only the strobe. This is a strobe that have fsync strobes	ain until the new requirement for
[2:0]	DLPF_CFG[2:0]	For the DLPF to 2'b00.	be used, fchoice[1:0] must be set to 2'b11,	fchoice_b[1:0] is
		See table 3 belo	ow.		

The DLPF is configured by *DLPF_CFG*, when *FCHOICE_B* [1:0] = 2b'00. The gyroscope and temperature sensor are filtered according to the value of *DLPF_CFG* and *FCHOICE_B* as shown in the table below. Note that FCHOICE mentioned in the table below is the inverted value of *FCHOICE_B* (e.g. FCHOICE=2b'00 is same as FCHOICE_B=2b'11).

FCH	IOICE			Gyroscope			re Sensor
<1>	<0>	DLPF_CFG	Bandwidth (Hz)	Delay (ms)	Fs (kHz)	Bandwidth (Hz)	Delay (ms)
х	0	х	8800	0.064	32	4000	0.04
0	1	х	3600	0.11	32	4000	0.04
1	1	0	250	0.97	8	4000	0.04
1	1	1	184	2.9	1	188	1.9
1	1	2	92	3.9	1	98	2.8
1	1	3	41	5.9	1	42	4.8
1	1	4	20	9.9	1	20	8.3
1	1	5	10	17.85	1	10	13.4
1	1	6	5	33.48	1	5	18.6
1	1	7	3600	0.17	8	4000	0.04

4.6 Register 27 - Gyroscope Configuration



Document Number: RM-MPU-9250A-00

Revision: 1.4 Release Date: 9/9/2013

Serial IF: R/W Reset value: 0x00

BIT	NAME	FUNCTION
[7]	XGYRO_Cten	X Gyro self-test
[6]	YGYRO_Cten	Y Gyro self-test
[5]	ZGYRO_Cten	Z Gyro self-test
		Gyro Full Scale Select:
		00 = +250dps
[4:3]	GYRO_FS_SEL[1:0]	01= +500 dps
		10 = +1000 dps
		11 = +2000 dps
[2]	-	Reserved
[1:0]	Fchoice_b[1:0]	Used to bypass DLPF as shown in table 1 above. NOTE: Register is Fchoice_b (inverted version of Fchoice), table 1 uses Fchoice (which is the inverted version of this register).

Register 28 – Accelerometer Configuration 4.7

Serial IF: R/W Reset value: 0x00

BIT	NAME	FUNCTION
[7]	ax_st_en	X Accel self-test
[6]	ay_st_en	Y Accel self-test
[5]	az_st_en	Z Accel self-test
[4:3]	ACCEL_FS_SEL[1:0]	Accel Full Scale Select: ±2g (00), ±4g (01), ±8g (10), ±16g (11)
[2:0]	-	Reserved

Register 29 – Accelerometer Configuration 2 4.8

Serial IF: R/W



Document Number: RM-MPU-9250A-00

Revision: 1.4

Release Date: 9/9/2013

BIT	NAME	FUNCTION
[7:6]	Reserved	
[5:4]	Reserved	
[3]	accel_fchoice_b	Used to bypass DLPF as shown in table 2 below. NOTE: This register contains accel_fchoice_b (the inverted version of accel_fchoice as described in the table below).
[2:0]	A_DLPFCFG	Accelerometer low pass filter setting as shown in table 2 below.

Accelerometer Data Rates and Bandwidths (Normal Mode)

			Outp	out	
ACCEL_FCHOICE	A_DLPF_CFG	Bandwidth (Hz)	Delay (ms)	Noise Density (ug/rtHz)	Rate (kHz)
0	X	1.13 K	0.75	250	4
1	0	460	1.94	250	1
1	1	184	5.80	250	1
1	2	92	7.80	250	1
1	3	41	11.80	250	1
1	4	20	19.80	250	1
1	5	10	35.70	250	1
1	6	5	66.96	250	1
1	7	460	1.94	250	1

The data output rate of the DLPF filter block can be further reduced by a factor of 1/(1+SMPLRT_DIV), where SMPLRT_DIV is an 8-bit integer. Following is a small subset of ODRs that are configurable for the accelerometer in the normal mode in this manner (Hz):

3.91, 7.81, 15.63, 31.25, 62.50, 125, 250, 500, 1K

The following table lists the approximate accelerometer filter bandwidths available in the low-power mode of operation.

In the low-power mode of operation, the accelerometer is duty-cycled. Fchoice=0 for all options.

Accelerometer Data Rates and Bandwidths (Low-Power Mode)

	ODR	Ot	tput	
ACCEL_FCHOICE	(Hz)	Bandwidth (Hz)	Delay (ms)	
0	0.24	1.1 k	1	
0	0.49	1.1 k	1	
0	0.98	1.1 k	1	
0	1.95	1.1 k	1	



Document Number: RM-MPU-9250A-00

Revision: 1.4

Release Date: 9/9/2013

0	3.91	1.1 k	1
0	7.81	1.1 k	1
0	15.63	1.1 k	1
0	31.25	1.1 k	1
0	62.50	1.1 k	1
0	125	1.1 k	1
0	250	1.1 k	1
0	500	1.1 kHz	1

As you can see from the tables above, some of the ODRs can be configured in the normal accelerometer mode as well as low power mode.

For further details on how to configure the individual ODRs, please refer to register 30 Low Power Accelerometer ODR Control.

4.9 Register 30 – Low Power Accelerometer ODR Control

Serial IF: R/W Reset value: 0x00

BIT	NAME	FUNCTION			
[7:4]	Reserved				
				g up the chip to take a Dutput Data Rate.	sample of accel
			Lposc_clksel	Output Frequency (Hz)	
			0	0.24	
			1	0.49	
			2	0.98	
			3	1.95	
			4	3.91	
[3:0]	lposc_clksel[3:0]		5	7.81	
			6	15.63	
			7	31.25	
			8	62.50	
			9	125	
			10	250	
			11	500	
			12-15	RESERVED	



Document Number: RM-MPU-9250A-00

Revision: 1.4 Release Date: 9/9/2013

4.10 Register 31 - Wake-on Motion Threshold

Serial IF: R/W Reset value: 0x00

BIT	NAME	FUNCTION
[7:0]	WOM_Threshold	This register holds the threshold value for the Wake on Motion Interrupt for accel x/y/z axes. LSB = 4mg. Range is 0mg to 1020mg.

For more details on how to configure the Wake-on-Motion interrupt, please refer to section 5 in the MPU-9250 Product Specification document.

4.11 Register 35 - FIFO Enable

Serial IF: R/W

BIT	NAME	FUNCTION
[7]	TEMP_OUT	1 – Write TEMP_OUT_H and TEMP_OUT_L to the FIFO at the sample rate; If enabled, buffering of data occurs even if data path is in standby.
		0 – function is disabled
[6]	GYRO_XOUT	1 – Write GYRO_XOUT_H and GYRO_XOUT_L to the FIFO at the sample rate; If enabled, buffering of data occurs even if data path is in standby.
		0 – function is disabled
[5]	GYRO YOUT	1 – Write GYRO_YOUT_H and GYRO_YOUT_L to the FIFO at the sample rate; If enabled, buffering of data occurs even if data path is in standby. 0 – function is disabled
	_	NOTE: Enabling any one of the bits corresponding to the Gyros or Temp data paths, data is buffered into the FIFO even though that data path is not enabled.
[4]	GYRO_ZOUT	1 – Write GYRO_ZOUT_H and GYRO_ZOUT_L to the FIFO at the sample rate; If enabled, buffering of data occurs even if data path is in standby. 0 – function is disabled
[3]	ACCEL	1 – write ACCEL_XOUT_H, ACCEL_XOUT_L, ACCEL_YOUT_H, ACCEL_YOUT_L, ACCEL_ZOUT_H, and ACCEL_ZOUT_L to the FIFO at the sample rate;
		0 – function is disabled



Document Number: RM-MPU-9250A-00

Revision: 1.4 Release Date: 9/9/2013

BIT	NAME	FUNCTION
[2]	SLV_2	1 – write EXT_SENS_DATA registers associated to SLV_2 (as determined by I2C_SLV0_CTRL, I2C_SLV1_CTRL, and I2C_SL20_CTRL) to the FIFO at the sample rate;
		0 – function is disabled
[1]	SLV_1	1 – write EXT_SENS_DATA registers associated to SLV_1 (as determined by I2C_SLV0_CTRL and I2C_SLV1_CTRL) to the FIFO at the sample rate;
		0 – function is disabled
		1 – write EXT_SENS_DATA registers associated to SLV_0 (as determined by I2C_SLV0_CTRL) to the FIFO at the sample rate;
[0]	SLV_0	0 – function is disabled
		NOTE: See I2C_SLV3_CTRL register to enable this feature for SLV_3

Note: For further information regarding the association of EXT_SENS_DATA registers to particular slave devices, please refer to Registers 73 to 96.

4.12 Register 36 – I2C Master Control

Serial IF: R/W

BIT	NAME	FUNCTION
[7]	MULT_MST_EN	Enables multi-master capability. When disabled, clocking to the I2C_MST_IF can be disabled when not in use and the logic to detect lost arbitration is disabled.
[6]	WAIT_FOR_ES	Delays the data ready interrupt until external sensor data is loaded. If I2C_MST_IF is disabled, the interrupt will still occur.
[5]	SLV_3_FIFO_EN	1 – write EXT_SENS_DATA registers associated to SLV_3 (as determined by I2C_SLV0_CTRL and I2C_SLV1_CTRL and I2C_SLV2_CTRL) to the FIFO at the sample rate; 0 – function is disabled
[4]	I2C_MST_P_NSR	This bit controls the I2C Master's transition from one slave read to the next slave read. If 0, there is a restart between reads. If 1, there is a stop between reads.



Document Number: RM-MPU-9250A-00

Revision: 1.4 Release Date: 9/9/2013

BIT	NAME	FUNCTION				
		I2C_MST_CLK i 9250 internal 8N following table:	s a 4 bit unsigno I/Hz clock. It se	ed value which co ts the I ² C maste	onfigures a div r clock speed	rider on the according
			I2C_MST_CLK	I ² C Master Clock Speed	8MHz Clock Divider	
			0	348 kHz	23	
			1	333 kHz	24	
			2	320 kHz	25]
	I2C_MST_CLK [3:0]		3	308 kHz	26	
			4	296 kHz	27	
3:0]			5	286 kHz	28	
3.0]			6	276 kHz	29	
			7	267 kHz	30	
			8	258 kHz	31	
			9	500 kHz	16	
			10	471 kHz	17	
			11	444 kHz	18	
			12	421 kHz	19	
			13	400 kHz	20	
			14	381 kHz	21	
			15	364 kHz	22	

 $\underline{\text{Note}} : \text{For further information regarding the association of EXT_SENS_DATA registers to particular slave devices, please refer to Registers 73 to 96.}$



Document Number: RM-MPU-9250A-00

Revision: 1.4 Release Date: 9/9/2013

4.13 Registers 37 to 39 – I²C Slave 0 Control

Register 37 - I2C_SLV0_ADDR

Serial IF: R/W

Reset value: 0x00

BIT	NAME	FUNCTION
[7]	I2C_SLV0_RNW	1 – Transfer is a read
[/]		0 – Transfer is a write
[6:0]	I2C_ID_0[6:0]	Physical address of I2C slave 0

Register 38 - I2C_SLV0_REG

Serial IF: R/W

Reset value: 0x00

BIT	NAME	FUNCTION
[7:0]	I2C_SLV0_REG[7:0]	I2C slave 0 register address from where to begin data transfer

Register 39 - I2C_SLV0_CTRL

Serial IF: R/W

BIT	NAME	FUNCTION
[7]	I2C_SLV0_EN	1 – Enable reading data from this slave at the sample rate and storing data at the first available EXT_SENS_DATA register, which is always EXT_SENS_DATA_00 for I2C slave 0. 0 – function is disabled for this slave



Document Number: RM-MPU-9250A-00

Revision: 1.4 Release Date: 9/9/2013

BIT	NAME	FUNCTION	
[6]	I2C_SLV0_BYTE_SW	 1 – Swap bytes when reading both the low and high byte of a word. Note there is nothing to swap after reading the first byte if I2C_SLV0_REG[0] = 1, or if the last byte read has a register address Isb = 0. For example, if I2C_SLV0_REG = 0x1, and I2C_SLV0_LENG = 0x4: The first byte read from address 0x1 will be stored at EXT_SENS_DATA_00, the second and third bytes will be read and swapped, so the data read from address 0x2 will be stored at EXT_SENS_DATA_02, and the data read from address 0x3 will be stored at EXT_SENS_DATA_01, The last byte read from address 0x4 will be stored at EXT_SENS_DATA_03 o – no swapping occurs, bytes are written in order read. 	
[5]	I2C_SLV0_REG_DIS	When set, the transaction does not write a register value, it will only read data, or write data	
[4]	I2C_SLV0_GRP	External sensor data typically comes in as groups of two bytes. This bit is used to determine if the groups are from the slave's register address 0 and 1, 2 and 3, etc, or if the groups are address 1 and 2, 3 and 4, etc O indicates slave register addresses 0 and 1 are grouped together (odd numbered register ends the group). 1 indicates slave register addresses 1 and 2 are grouped together (even numbered register ends the group). This allows byte swapping of registers that are grouped starting at any address.	
[3:0]	I2C_SLV0_LENG[3:0]	Number of bytes to be read from I2C slave 0	

4.14 Registers 40 to 42 – I²C Slave 1 Control

Register 40 - I2C_SLV1_ADDR

Serial IF: R/W Reset value: 0x00

BIT	NAME	FUNCTION
[7]	I2C_SLV1_RNW	1 – Transfer is a read
[/]		0 – Transfer is a write
[6:0]	I2C_ID_1[6:0]	Physical address of I2C slave 1



Document Number: RM-MPU-9250A-00

Revision: 1.4 Release Date: 9/9/2013

Register 41 - I2C_SLV1_REG

Serial IF: R/W Reset value: 0x00

BIT	NAME	FUNCTION
[7:0]	I2C_SLV1_REG[7:0]	I2C slave 1 register address from where to begin data transfer

Register 42 - I2C_SLV1_CTRL

Serial IF: R/W

BIT	NAME	FUNCTION
[7]	I2C_SLV1_EN	The entire of the sample rate and storing data at the first available EXT_SENS_DATA register as determined by I2C_SLV1_EN and I2C_SLV1_LENG. Output to the sample rate and storing data at the first available EXT_SENS_DATA register as determined by I2C_SLV1_EN and I2C_SLV1_LENG.



Document Number: RM-MPU-9250A-00

Revision: 1.4 Release Date: 9/9/2013

BIT	NAME	FUNCTION	
[6]	I2C_SLV1_BYTE_SW	1 – Swap bytes when reading both the low and high byte of a word. Note there is nothing to swap after reading the first byte if I2C_SLV1_REG[0] = 1, or if the last byte read has a register address lsb = 0.	
		For example, if I2C_SLV1_EN = 0x1, and I2C_SLV1_LENG = 0x3 (to show swap has to do with I2C slave address not EXT_SENS_DATA address), and if I2C_SLV1_REG = 0x1, and I2C_SLV1_LENG = 0x4:	
		 The first byte read from address 0x1 will be stored at EXT_SENS_DATA_03 (slave 0's data will be in EXT_SENS_DATA_00, EXT_SENS_DATA_01, and EXT_SENS_DATA_02), the second and third bytes will be read and swapped, so the data read from address 0x2 will be stored at EXT_SENS_DATA_04, and the data read from address 0x3 will be stored at EXT_SENS_DATA_05, The last byte read from address 0x4 will be stored at EXT_SENS_DATA_06 	
		0 – no swapping occurs, bytes are written in order read.	
[5]	I2C_SLV1_REG_DIS	When set, the transaction does not write a register value, it will only read data, or write data	
[4]	I2C_SLV1_GRP	External sensor data typically comes in as groups of two bytes. This bit is used to determine if the groups are from the slave's register address 0 and 1, 2 and 3, etc, or if the groups are address 1 and 2, 3 and 4, etc	
		0 indicates slave register addresses 0 and 1 are grouped together (odd numbered register ends the group). 1 indicates slave register addresses 1 and 2 are grouped together (even numbered register ends the group). This allows byte swapping of registers that are grouped starting at any address.	
[3:0]	I2C_SLV1_LENG[3:0]	Number of bytes to be read from I2C slave 1	

4.15 Registers 43 to 45 – I²C Slave 2 Control

Register 43 - I2C_SLV2_ADDR

Serial IF: R/W



Document Number: RM-MPU-9250A-00

Revision: 1.4 Release Date: 9/9/2013

Reset value: 0x00

BIT	NAME	FUNCTION
[7]	I2C_SLV2_RNW	1 – Transfer is a read
[/]		0 – Transfer is a write
[6:0]	I2C_ID_2[6:0]	Physical address of I2C slave 2

Register 44 - I2C_SLV2_REG

Serial IF: R/W Reset value: 0x00

BIT	NAME	FUNCTION
[7:0]	I2C_SLV2_REG[7:0]	I2C slave 2 register address from where to begin data transfer

Register 45 - I2C_SLV2_CTRL

Serial IF: R/W Reset value: 0x00

BIT	NAME	FUNCTION
[7]	I2C_SLV2_EN	1 – Enable reading data from this slave at the sample rate and storing data at the first available EXT_SENS_DATA register as determined by I2C_SLV0_EN, I2C_SLV0_LENG, I2C_SLV1_EN and I2C_SLV1_LENG. 0 – function is disabled for this slave
[6]	I2C_SLV2_BYTE_SW	1 – Swap bytes when reading both the low and high byte of a word. Note there is nothing to swap after reading the first byte if I2C_SLV2_REG[0] = 1, or if the last byte read has a register address lsb = 0.
		See I2C_SLV1_CTRL for an example.
		0 – no swapping occurs, bytes are written in order read.
[5]	I2C_SLV2_REG_DIS	When set, the transaction does not write a register value, it will only read data, or write data



Document Number: RM-MPU-9250A-00

Revision: 1.4

Release Date: 9/9/2013

BIT	NAME	FUNCTION
		External sensor data typically comes in as groups of two bytes. This bit is used to determine if the groups are from the slave's register address 0 and 1, 2 and 3, etc, or if the groups are address 1 and 2, 3 and 4, etc
[4]	I2C_SLV2_GRP	0 indicates slave register addresses 0 and 1 are grouped together (odd numbered register ends the group). 1 indicates slave register addresses 1 and 2 are grouped together (even numbered register ends the group). This allows byte swapping of registers that are grouped starting at any address.
[3:0]	I2C_SLV2_LENG[3:0]	Number of bytes to be read from I2C slave 2

4.16 Registers 46 to 48 – I²C Slave 3 Control

Register 46 - I2C_SLV3_ADDR

Serial IF: R/W

Reset value: 0x00

BIT	NAME	FUNCTION
[7]	I2C SLV3 RNW	1 – Transfer is a read
[,]	120_02/0_1(1400	0 – Transfer is a write
[6:0]	I2C_ID_3[6:0]	Physical address of I2C slave 3

Register 47 - I2C_SLV3_REG

Serial IF: R/W

Reset value: 0x00

BIT	NAME	FUNCTION
[7:0]	I2C_SLV3_REG[7:0]	I2C slave 3 register address from where to begin data transfer

Register 48 - I2C_SLV3_CTRL

Serial IF: R/W



Document Number: RM-MPU-9250A-00

Revision: 1.4 Release Date: 9/9/2013

BIT	NAME	FUNCTION
[7]	I2C_SLV3_EN	1 – Enable reading data from this slave at the sample rate and storing data at the first available EXT_SENS_DATA register as determined by I2C_SLV0_EN, I2C_SLV0_LENG, I2C_SLV1_EN, I2C_SLV1_LENG, I2C_SLV2_EN and I2C_SLV2_LENG. 0 – function is disabled for this slave
[6]	I2C_SLV3_BYTE_SW	 1 – Swap bytes when reading both the low and high byte of a word. Note there is nothing to swap after reading the first byte if I2C_SLV3_REG[0] = 1, or if the last byte read has a register address lsb = 0. See I2C_SLV1_CTRL for an example. 0 – no swapping occurs, bytes are written in order read.
[5]	I2C_SLV0_REG_DIS	When set, the transaction does not write a register value, it will only read data, or write data
[4]	I2C_SLV3_GRP	External sensor data typically comes in as groups of two bytes. This bit is used to determine if the groups are from the slave's register address 0 and 1, 2 and 3, etc, or if the groups are address 1 and 2, 3 and 4, etc 0 indicates slave register addresses 0 and 1 are grouped together (odd numbered register ends the group). 1 indicates slave register addresses 1 and 2 are grouped together (even numbered register ends the group). This allows byte swapping of registers that are grouped starting at any address.
[3:0]	I2C_SLV3_LENG[3:0]	Number of bytes to be read from I2C slave 3

4.17 Registers 49 to 53 – I²C Slave 4 Control

Register 49 - I2C_SLV4_ADDR

Serial IF: R/W

Reset value: 0x00

BIT	NAME	FUNCTION
[7] I2C_SLV4_RNW	1 – Transfer is a read	
	120_0674_1(1111	0 – Transfer is a write
[6:0]	I2C_ID_4[6:0]	Physical address of I2C slave 4

Register 50 - I2C_SLV4_REG

Serial IF: R/W



Document Number: RM-MPU-9250A-00

Revision: 1.4 Release Date: 9/9/2013

Reset value: 0x00

Е	BIT	NAME	FUNCTION
[7:0]	I2C_SLV4_REG[7:0]	I2C slave 4 register address from where to begin data transfer

Register 51 - I2C_SLV4_DO

Serial IF: R/W Reset value: 0x00

BIT	NAME	FUNCTION
[7:0]	I2C_SLV4_DO[7:0]	Data to be written to I2C Slave 4 if enabled.

Register 52 - I2C_SLV4_CTRL

Serial IF: R/W Reset value: 0x00

BIT	NAME	FUNCTION
[7]	I2C_SLV4_EN	1 – Enable data transfer with this slave at the sample rate. If read command, store data in I2C_SLV4_DI register, if write command, write data stored in I2C_SLV4_DO register. Bit is cleared when a single transfer is complete. Be sure to write I2C_SLV4_DO first
		0 – function is disabled for this slave
[6]	SLV4_DONE_INT_EN	1 – Enables the completion of the I2C slave 4 data transfer to cause an interrupt.
		0 – Completion of the I2C slave 4 data transfer will not cause an interrupt.
[5]	I2C_SLV4_REG_DIS	When set, the transaction does not write a register value, it will only read data, or write data
[4:0]	I2C_MST_DLY	When enabled via the I2C_MST_DELAY_CTRL, those slaves will only be enabled every (1+I2C_MST_DLY) samples (as determined by the SMPLRT_DIV and DLPF_CFG registers.

Register 53 - I2C_SLV4_DI

Serial IF: R



Document Number: RM-MPU-9250A-00

Revision: 1.4 Release Date: 9/9/2013

BIT	NAME	FUNCTION
[7:0]	I2C_SLV4_DI[7:0]	Data read from I2C Slave 4.

4.18 Register 54 – I²C Master Status

Serial IF: R/C

BIT	NAME	FUNCTION
[7]	PASS_THROUGH	Status of FSYNC interrupt – used as a way to pass an external interrupt through this chip to the host. If enabled in the INT_PIN_CFG register by asserting bit FSYNC_INT_EN and if the FSYNC signal transitions from low to high, this will cause an interrupt. A read of this register clears all status bits in this register.
[6]	I2C_SLV4_DONE	Asserted when I2C slave 4's transfer is complete, will cause an interrupt if bit I2C_MST_INT_EN in the INT_ENABLE register is asserted, and if the SLV4_DONE_INT_EN bit is asserted in the I2C_SLV4_CTRL register.
[5]	I2C_LOST_ARB	Asserted when I2C slave looses arbitration of the I2C bus, will cause an interrupt if bit I2C_MST_INT_EN in the INT_ENABLE register is asserted.
[4]	I2C_SLV4_NACK	Asserted when slave 4 receives a nack, will cause an interrupt if bit I2C_MST_INT_EN in the INT_ENABLE register is asserted.
[3]	I2C_SLV3_NACK	Asserted when slave 3 receives a nack, will cause an interrupt if bit I2C_MST_INT_EN in the INT_ENABLE register is asserted.
[2]	I2C_SLV2_NACK	Asserted when slave 2 receives a nack, will cause an interrupt if bit I2C_MST_INT_EN in the INT_ENABLE register is asserted.
[1]	I2C_SLV1_NACK	Asserted when slave 1 receives a nack, will cause an interrupt if bit I2C_MST_INT_EN in the INT_ENABLE register is asserted.
[0]	I2C_SLV0_NACK	Asserted when slave 0 receives a nack, will cause an interrupt if bit I2C_MST_INT_EN in the INT_ENABLE register is asserted.



Document Number: RM-MPU-9250A-00

Revision: 1.4 Release Date: 9/9/2013

4.19 Register 55 – INT Pin / Bypass Enable Configuration

Serial IF: R/W Reset value: 0x00

BIT	NAME	FUNCTION
[7]	ACTL	1 – The logic level for INT pin is active low.
[,]		0 – The logic level for INT pin is active high.
[6]	OPEN	1 – INT pin is configured as open drain.
[0]	OI LIV	0 – INT pin is configured as push-pull.
[5]	LATCH_INT_EN	1 – INT pin level held until interrupt status is cleared.
[0]	LATON_INT_EN	0 – INT pin indicates interrupt pulse's is width 50us.
[4]	INT_ANYRD_2CLEAR	1 – Interrupt status is cleared if any read operation is performed.
ניין		0 – Interrupt status is cleared only by reading INT_STATUS register
[3]	ACTL_FSYNC	1 – The logic level for the FSYNC pin as an interrupt is active low.
[0]		0 – The logic level for the FSYNC pin as an interrupt is active high.
[2]	FSYNC_INT_MODE_EN	1 – This enables the FSYNC pin to be used as an interrupt. A transition to the active level described by the ACTL_FSYNC bit will cause an interrupt. The status of the interrupt is read in the I2C Master Status register PASS_THROUGH bit.
		0 – This disables the FSYNC pin from causing an interrupt.
[1]	BYPASS_EN	When asserted, the i2c_master interface pins(ES_CL and ES_DA) will go into 'bypass mode' when the i2c master interface is disabled. The pins will float high due to the internal pull-up if not enabled and the i2c master interface is disabled.
[0]	RESERVED	

4.20 Register 56 – Interrupt Enable

Serial IF: R/W Reset value: 0x00

BIT	NAME	FUNCTION
[7]	RESERVED	



Document Number: RM-MPU-9250A-00

Revision: 1.4 Release Date: 9/9/2013

BIT	NAME	FUNCTION
[6]	WOM_EN	1 – Enable interrupt for wake on motion to propagate to interrupt pin.0 – function is disabled.
[5]	RESERVED	
[4]	FIFO_OVERFLOW_EN	1 – Enable interrupt for fifo overflow to propagate to interrupt pin.0 – function is disabled.
[3]	FSYNC_INT_EN	1 – Enable Fsync interrupt to propagate to interrupt pin.0 – function is disabled.
[2]	RESERVED	
[1]	RESERVED	
[0]	RAW_RDY_EN	1 – Enable Raw Sensor Data Ready interrupt to propagate to interrupt pin. The timing of the interrupt can vary depending on the setting in register 36 I2C_MST_CTRL, bit [6] WAIT_FOR_ES. 0 – function is disabled.

4.21 Register 58 – Interrupt Status

Serial IF: R/C

BIT	NAME	FUNCTION
[7]	Reserved	
[6]	WOM_INT	1 – Wake on motion interrupt occurred.
[5]	Reserved	
[4]	FIFO_OVERFLOW_INT	1 – Fifo Overflow interrupt occurred. Note that the oldest data is has been dropped from the fifo.
[3]	FSYNC_INT	1 – Fsync interrupt occurred.
[2]	Reserved	
[1]	Reserved	
[0]	RAW_DATA_RDY_INT	1 – Sensor Register Raw Data sensors are updated and Ready to be read. The timing of the interrupt can vary depending on the setting in register 36 I2C_MST_CTRL, bit [6] WAIT_FOR_ES.



Document Number: RM-MPU-9250A-00

Revision: 1.4

Release Date: 9/9/2013

4.22 Registers 59 to 64 - Accelerometer Measurements

Name: ACCEL_XOUT_H

Serial IF: SyncR

Reset value: 0x00 (if sensor disabled)

BIT	NAME	FUNCTION
[7:0]	D[7:0]	High byte of accelerometer x-axis data.

Name: ACCEL_XOUT_L

Serial IF: SyncR

Reset value: 0x00 (if sensor disabled)

BIT	NAME	FUNCTION
[7:0]	D[7:0]	Low byte of accelerometer x-axis data.

Name: ACCEL_YOUT_H

Serial IF: SyncR

Reset value: 0x00 (if sensor disabled)

BIT	NAME	FUNCTION
[7:0]	D[7:0]	High byte of accelerometer y-axis data.

Name: ACCEL_YOUT_L

Serial IF: SyncR

Reset value: 0x00 (if sensor disabled)

BIT	NAME	FUNCTION
[7:0]	D[7:0]	Low byte of accelerometer y-axis data.

Name: ACCEL_ZOUT_H

Serial IF: SyncR



Document Number: RM-MPU-9250A-00

Revision: 1.4 Release Date: 9/9/2013

BIT	NAME	FUNCTION
[7:0]	D[7:0]	High byte of accelerometer z-axis data.

Name: ACCEL_ZOUT_L

Serial IF: SyncR

BIT	NAME	FUNCTION
[7:0]	D[7:0]	Low byte of accelerometer z-axis data.



Document Number: RM-MPU-9250A-00

Revision: 1.4

Release Date: 9/9/2013

4.23 Registers 65 and 66 - Temperature Measurement

Name: TEMP_OUT_H

Serial IF: SyncR

Reset value: 0x00 (if sensor disabled)

BIT	NAME	FUNCTION
[7:0]	D[7:0]	High byte of the temperature sensor output

Name: TEMP_OUT_L

Serial IF: SyncR

Reset value: 0x00 (if sensor disabled)

BIT	NAME	FUNCTION
[7:0]	D[7:0]	Low byte of the temperature sensor output:
		TEMP_degC = ((TEMP_OUT - RoomTemp_Offset)/Temp_Sensitivity) + 21degC
		Where Temp_degC is the temperature in degrees C measured by the temperature sensor. TEMP_OUT is the actual output of the temperature sensor.

4.24 Registers 67 to 72 – Gyroscope Measurements

Name: GYRO_XOUT_H

Serial IF: SyncR

Reset value: 0x00 (if sensor disabled)

BIT	NAME	FUNCTION
[7:0]	D[7:0]	High byte of the X-Axis gyroscope output

Name: GYRO_XOUT_L

Serial IF: SyncR

BIT	NAME	FUNCTION	



Document Number: RM-MPU-9250A-00

Revision: 1.4

Release Date: 9/9/2013

BIT	NAME	FUNCTION	
	D[7:0] GY	Low byte of the X-Axis gyroscope output	
[7:0]		GYRO_XOUT =	Gyro_Sensitivity * X_angular_rate
[7.0]		Nominal	FS_SEL = 0
		Conditions	Gyro_Sensitivity = 131 LSB/(°/s)

Name: GYRO_YOUT_H

Serial IF: SyncR

Reset value: 0x00 (if sensor disabled)

BIT	NAME	FUNCTION	
[7:0]	D[7:0]	High byte of the Y-Axis gyroscope output	

Name: GYRO_YOUT_L

Serial IF: SyncR

Reset value: 0x00 (if sensor disabled)

BIT	NAME	FUNCTION	
		Low byte of the Y-	Axis gyroscope output
[7:0]	D[7:0]	GYRO_YOUT =	Gyro_Sensitivity * Y_angular_rate
		Nominal	FS_SEL = 0
		Conditions	Gyro_Sensitivity = 131 LSB/(°/s)

Name: GYRO_ZOUT_H

Serial IF: SyncR

Reset value: 0x00 (if sensor disabled)

BIT NAME F		FUNCTION	
[7:0]	D[7:0]	High byte of the Z-Axis gyroscope output	

Name: GYRO_ZOUT_L

Serial IF: SyncR



Document Number: RM-MPU-9250A-00

Revision: 1.4

Release Date: 9/9/2013

BIT	NAME	FUNCTION	
	D[7:0]	Low byte of the Z-Axis gyroscope output	
[7:0]		GYRO_ZOUT =	Gyro_Sensitivity * Z_angular_rate
[7.0]		Nominal	FS_SEL = 0
		Conditions	Gyro_Sensitivity = 131 LSB/(°/s)

4.25 Registers 73 to 96 - External Sensor Data

 $EXT_SENS_DATA_00 - 23$

Serial IF: SyncR Reset value: 0x00

24 registers with the same description as below:

BIT	NAME	FUNCTION
[7:0]	D[7:0]	Sensor data read from external I2C devices via the I2C master interface. The data stored is controlled by the I2C_SLV(0-4)_ADDR, I2C_SLV(0-4)_REG, and I2C_SLV(0-4)_CTRL registers

Description:

These registers store data read from external sensors by the Slave 0, 1, 2, and 3 on the auxiliary I²C interface. Data read by Slave 4 is stored in I2C_SLV4_DI (Register 53).

External sensor data is written to these registers at the Sample Rate as defined in Register 25. This access rate can be reduced by using the Slave Delay Enable registers (Register 103).

Data is placed in these external sensor data registers according to I2C_SLV0_CTRL, I2C_SLV1_CTRL, I2C_SLV2_CTRL, and I2C_SLV3_CTRL (Registers 39, 42, 45, and 48). When more than zero bytes are read (I2C_SLVx_LEN > 0) from an enabled slave (I2C_SLVx_EN = 1), the slave is read at the Sample Rate (as defined in Register 25) or delayed rate (if specified in Register 52 and 103). During each sample cycle, slave reads are performed in order of Slave number. If all slaves are enabled with more than zero bytes to be read, the order will be Slave 0, followed by Slave 1, Slave 2, and Slave 3.

Each enabled slave will have EXT_SENS_DATA registers associated with it by number of bytes read (*I2C_SLVx_LEN*) in order of slave number, starting from EXT_SENS_DATA_00. Note that this means enabling or disabling a slave may change the higher numbered slaves' associated registers. Furthermore, if fewer total bytes are being read from the external sensors as a result of such a change, then the data remaining in the registers which no longer have an associated slave device (i.e. high numbered registers) will remain in these previously allocated registers unless reset.

If the sum of the read lengths of all SLVx transactions exceed the number of available EXT_SENS_DATA registers, the excess bytes will be dropped. There are 24 EXT_SENS_DATA



Document Number: RM-MPU-9250A-00

Revision: 1.4

Release Date: 9/9/2013

registers and hence the total read lengths between all the slaves cannot be greater than 24 or some bytes will be lost.

<u>Note</u>: Slave 4's behavior is distinct from that of Slaves 0-3. For further information regarding the characteristics of Slave 4, please refer to Registers 49 to 53.

Example:

Suppose that Slave 0 is enabled with 4 bytes to be read ($I2C_SLV0_EN = 1$ and $I2C_SLV0_LEN = 4$) while Slave 1 is enabled with 2 bytes to be read, ($I2C_SLV1_EN = 1$ and $I2C_SLV1_LEN = 2$). In such a situation, EXT_SENS_DATA _00 through _03 will be associated with Slave 0, while EXT_SENS_DATA _04 and 05 will be associated with Slave 1.

If Slave 2 is enabled as well, registers starting from EXT_SENS_DATA_06 will be allocated to Slave 2.

If Slave 2 is disabled while Slave 3 is enabled in this same situation, then registers starting from EXT_SENS_DATA_06 will be allocated to Slave 3 instead.

Register Allocation for Dynamic Disable vs. Normal Disable

If a slave is disabled at any time, the space initially allocated to the slave in the EXT_SENS_DATA register, will remain associated with that slave. This is to avoid dynamic adjustment of the register allocation.

The allocation of the EXT_SENS_DATA registers is recomputed only when (1) all slaves are disabled, or (2) the *I2C_MST_RST* bit is set (Register 106).

This above is also true if one of the slaves gets NACKed and stops functioning.



Document Number: RM-MPU-9250A-00

Revision: 1.4

Release Date: 9/9/2013

4.26 Register 99 – I²C Slave 0 Data Out

I2C_SLV0_DO

Serial IF: R/W

Reset value: 0x00

BIT	NAME	FUNCTION
[7:0]	I2C_SLV0_DO	Data out when slave 0 is set to write

For further information regarding Slave 1 control, please refer to Registers 37 to 39.

4.27 Register 100 - I²C Slave 1 Data Out

I2C_SLV1_DO

Serial IF: R/W

Reset value: 0x00

BIT	NAME	FUNCTION
[7:0]	I2C_SLV1_DO	Data out when slave 1 is set to write

For further information regarding Slave 1 control, please refer to Registers 40 to 42.

4.28 Register 101 - I²C Slave 2 Data Out

I2C_SLV2_DO

Serial IF: R/W

Reset value: 0x00

BIT	NAME	FUNCTION
[7:0]	I2C_SLV2_DO	Data out when slave 2 is set to write

For further information regarding Slave 2 control, please refer to Registers 43 to 45.

4.29 Register 102 – I²C Slave 3 Data Out



Document Number: RM-MPU-9250A-00

Revision: 1.4 Release Date: 9/9/2013

I2C_SLV3_DO

Serial IF: R/W

Reset value: 0x00

BIT	NAME	FUNCTION
[7:0]	I2C_SLV3_DO	Data out when slave 3 is set to write

For further information regarding Slave 2 control, please refer to Registers 46 to 48.

4.30 Register 103 – I²C Master Delay Control

I2C_MST_DELAY_CTRL

Serial IF: R/W

BIT	NAME	FUNCTION
[7]	DELAY_ES_SHADOW	Delays shadowing of external sensor data until all data is received
[6:5]	Reserved	
[4]	I2C_SLV4_DLY_EN	When enabled, slave 4 will only be accessed (1+I2C_MST_DLY) samples as determined by SMPLRT_DIV and DLPF_CFG
[3]	I2C_SLV3_DLY_EN	When enabled, slave 3 will only be accessed (1+I2C_MST_DLY) samples as determined by SMPLRT_DIV and DLPF_CFG
[2]	I2C_SLV2_DLY_EN	When enabled, slave 2 will only be accessed 1+I2C_MST_DLY) samples as determined by SMPLRT_DIV and DLPF_CFG
[1]	I2C_SLV1_DLY_EN	When enabled, slave 1 will only be accessed 1+I2C_MST_DLY) samples as determined by SMPLRT_DIV and DLPF_CFG
[0]	I2C_SLV0_DLY_EN	When enabled, slave 0 will only be accessed 1+I2C_MST_DLY) samples as determined by SMPLRT_DIV and DLPF_CFG



Document Number: RM-MPU-9250A-00

Revision: 1.4

Release Date: 9/9/2013

4.31 Register 104 - Signal Path Reset

SIGNAL_PATH_RESET

Serial IF: R/W

Reset value: 0x00

BIT	NAME	FUNCTION
[7:3]	Reserved	
[2]	GYRO_RST	Reset gyro digital signal path. Note: Sensor registers are not cleared. Use SIG_COND_RST to clear sensor registers.
[1]	ACCEL_RST	Reset accel digital signal path. Note: Sensor registers are not cleared. Use SIG_COND_RST to clear sensor registers.
[0]	TEMP_RST	Reset temp digital signal path. Note: Sensor registers are not cleared. Use SIG_COND_RST to clear sensor registers.

4.32 Register 105 - Accelerometer Interrupt Control

ACCEL_INTEL_CTRL

Serial IF: R/W

Reset value: 0x00

BIT	NAME	FUNCTION
[7]	ACCEL_INTEL_EN	This bit enables the Wake-on-Motion detection logic.
[6]	ACCEL_INTEL_MODE	This bit defines 1 = Compare the current sample with the previous sample. 0 = Not used.
[5:0]	Reserved	

Please refer to the Wake-on-Motion Interrupt section of the MPU-9250 Product Specification for additional details.

4.33 Register 106 - User Control

Name: USER_CTRL

Serial IF: R/W



Document Number: RM-MPU-9250A-00

Revision: 1.4 Release Date: 9/9/2013

BIT	NAME	FUNCTION
[7]	Reserved	
		1 – Enable FIFO operation mode.
[6]	FIFO_EN	0 – Disable FIFO access from serial interface. To disable FIFO writes by dma, use FIFO_EN register. To disable possible FIFO writes from DMP, disable the DMP.
		1 – Enable the I2C Master I/F module; pins ES_DA and ES_SCL are isolated from pins SDA/SDI and SCL/ SCLK.
[5]	I2C_MST_EN	0 – Disable I2C Master I/F module; pins ES_DA and ES_SCL are logically driven by pins SDA/SDI and SCL/ SCLK.
		NOTE: DMP will run when enabled, even if all internal sensors are disabled, except when the sample rate is set to 8Khz.
[4]	1 – Reset I2C Slave module and put the serial interface in SPI mode only. This bit auto clears after one clock cycle.	
[3]	Reserved	
[2]	FIFO_RST	1 – Reset FIFO module. Reset is asynchronous. This bit auto clears after one clock cycle.
	I2C_MST_RST	1 – Reset I2C Master module. Reset is asynchronous. This bit auto clears after one clock cycle.
[1]		NOTE: This bit should only be set when the I2C master has hung. If this bit is set during an active I2C master transaction, the I2C slave will hang, which will require the host to reset the slave.
[0]	SIG_COND_RST	Reset all gyro digital signal path, accel digital signal path, and temp digital signal path. This bit also clears all the sensor registers. SIG_COND_RST is a pulse of one clk8M wide.

4.34 Register 107 – Power Management 1

Name: PWR_MGMT_1

Serial IF: R/W

Reset value: (Depends on PU_SLEEP_MODE bit, see below)

BIT	NAME	FUNCTION
[7]	H_RESET	1 – Reset the internal registers and restores the default settings. Write a 1 to set the reset, the bit will auto clear.
[6]	SLEEP	When set, the chip is set to sleep mode (After OTP loads, the PU_SLEEP_MODE bit will be written here)



Document Number: RM-MPU-9250A-00

Revision: 1.4 Release Date: 9/9/2013

BIT	NAME	FUNCT	ON
[6]	CYCLE	betweer	et, and SLEEP and STANDBY are not set, the chip will cycle is sleep and taking a single sample at a rate determined by CEL_ODR register
[5]		register	When all accelerometer axis are disabled via PWR_MGMT_2 bits and cycle is enabled, the chip will wake up at the rate ned by the respective registers above, but will not take any samples.
[4]	GYRO_STANDBY	When set, the gyro drive and pll circuitry are enabled, but the sense paths are disabled. This is a low power mode that allows quick enabling of the gyros.	
[3]	PD_PTAT	Power d	own internal PTAT voltage generator and PTAT ADC
		Code	Clock Source
		0	Internal 20MHz oscillator
	CLKSEL[2:0]	1	Auto selects the best available clock source – PLL if ready, else use the Internal oscillator
		2	Auto selects the best available clock source – PLL if ready, else use the Internal oscillator
		3	Auto selects the best available clock source – PLL if ready, else use the Internal oscillator
[2:0]		4	Auto selects the best available clock source – PLL if ready, else use the Internal oscillator
		5	Auto selects the best available clock source – PLL if ready, else use the Internal oscillator
		6	Internal 20MHz oscillator
		7	Stops the clock and keeps timing generator in reset
		(After O	TP loads, the inverse of PU_SLEEP_MODE bit will be written to _[0])

4.35 Register 108 – Power Management 2

Name: PWR_MGMT_2

Serial IF: R/W

BIT	NAME	FUNCTION
[7:6]	Reserved	



Document Number: RM-MPU-9250A-00

Revision: 1.4

Release Date: 9/9/2013

BIT	NAME	FUNCTION
[5]	DISABLE XA	1 – X accelerometer is disabled
[0]	DIOADEL_XX	0 – X accelerometer is on
[4]	DISABLE_YA	1 – Y accelerometer is disabled
ניין	DISABLE_TA	0 – Y accelerometer is on
[3]	DISABLE ZA	1 – Z accelerometer is disabled
[3]	DISABLE_ZA	0 – Z accelerometer is on
[2]	DISABLE XG	1 – X gyro is disabled
[2]	DISABLE_XG	0 – X gyro is on
[1]	DISABLE YG	1 – Y gyro is disabled
ניז	DISABLE_TG	0 – Y gyro is on
[0]	DISABLE ZG	1 – Z gyro is disabled
[0]	DIOADEL_ZO	0 – Z gyro is on

The MPU-9250 can be put into Accelerometer Only Low Power Mode using the following steps:

- (i) Set CYCLE bit to 1
- (ii) Set SLEEP bit to 0
- (iii) Set TEMP_DIS bit to 1
- (iv) Set DIS_XG, DIS_YG, DIS_ZG bits to 1

The bits mentioned in the steps (i) to (iii) can be found in Power Management 1 register (Register 107).

In this mode, the device will power off all devices except for the primary I²C interface, waking only the accelerometer at fixed intervals to take a single measurement.

4.36 Register 114 and 115 - FIFO Count Registers

Name: FIFO_COUNTH

Address: 114

Serial IF: Read Only Reset value: 0x00

BIT	NAME	FUNCTION
[7:5]	Reserved	



Document Number: RM-MPU-9250A-00

Revision: 1.4

Release Date: 9/9/2013

BIT	NAME	FUNCTION		
[4:0]	FIFO_CNT[12:8]	High Bits, count indicates the number of written bytes in the FIFO. Reading this byte latches the data for both FIFO_COUNTH, and FIFO_COUNTL.		

FIFO_COUNTL Address: 115

Serial IF: Read Only Reset value: 0x00

BIT	NAME	FUNCTION		
[7:0]	FIFO_CNT[7:0]	Low Bits, count indicates the number of written bytes in the FIFO. NOTE: Must read FIFO_COUNTH to latch new data for both FIFO_COUNTH and FIFO_COUNTL.		

4.37 Register 116 - FIFO Read Write

Name: FIFO_R_W Serial IF: R/W Reset value: 0x00

BIT NAME FUNCTION

[7:0] D[7:0] Read/Write command provides Read or Write operation for the FIFO.

Description:

This register is used to read and write data from the FIFO buffer.

Data is written to the FIFO in order of register number (from lowest to highest). If all the FIFO enable flags (see below) are enabled and all External Sensor Data registers (Registers 73 to 96) are associated with a Slave device, the contents of registers 59 through 96 will be written in order at the Sample Rate.

The contents of the sensor data registers (Registers 59 to 96) are written into the FIFO buffer when their corresponding FIFO enable flags are set to 1 in FIFO_EN (Register 35). An additional flag for the sensor data registers associated with I²C Slave 3 can be found in I2C_MST_CTRL (Register 36).

If the FIFO buffer has overflowed, the status bit FIFO_OFLOW_INT is automatically set to 1. This bit is located in INT_STATUS (Register 58). When the FIFO buffer has overflowed, the oldest data will be lost and new data will be written to the FIFO unless register 26 CONFIG, bit[6] FIFO_MODE = 1.



Document Number: RM-MPU-9250A-00

Revision: 1.4

Release Date: 9/9/2013

If the FIFO buffer is empty, reading this register will return the last byte that was previously read from the FIFO until new data is available. The user should check *FIFO_COUNT* to ensure that the FIFO buffer is not read when empty.

4.38 Register 117 - Who Am I

Name: WHOAMI Serial IF: Read Only Reset value: 0x68

BIT	NAME	FUNCTION
[7:0]	WHOAMI	Register to indicate to user which device is being accessed.

This register is used to verify the identity of the device. The contents of *WHO_AM_I* is an 8-bit device ID. The default value of the register is 0x71.

4.39 Registers 119, 120, 122, 123, 125, 126 Accelerometer Offset Registers

For MPU-9250 mode:

Name: XA_OFFS_H

Address: 119
Serial IF: R/W
Reset value: 0x00

BIT	NAME	FUNCTION
[7:0]	XA_OFFS[14:7]	Upper bits of the X accelerometer offset cancellation. +/- 16g Offset cancellation in all Full Scale modes, 15 bit 0.98-mg steps

Name: XA_OFFS_L

Address: 120 Serial IF: R/W Reset value: 0x00

BIT	NAME	FUNCTION
[7:1]	XA_OFFS[6:0]	Lower bits of the X accelerometer offset cancellation. +/- 16g Offset cancellation in all Full Scale modes, 15 bit 0.98-mg steps



Document Number: RM-MPU-9250A-00

Revision: 1.4

Release Date: 9/9/2013

BIT	NAME	FUNCTION
[0]	Reserved	

Name: YA_OFFS_H

Address: 122 Serial IF: R/W

Reset value: 0x00

BIT	NAME	FUNCTION
[7:0]	YA_OFFS[14:7]	Upper bits of the Y accelerometer offset cancellation. +/- 16g Offset cancellation in all Full Scale modes, 15 bit 0.98-mg steps

Name: YA_OFFS_L

Address: 123 Serial IF: R/W

Reset value: 0x00

BIT	NAME	FUNCTION	
[7:1]	[7:1] YA_OFFS[6:0] Lower bits of the Y accelerometer offset cancellation. +/- 16g Offset cancellation in all Full Scale modes, 15 bit 0.98-mg steps		
[0]	Reserved		

Name: ZA_OFFS_H

Address: 125 Serial IF: R/W

Reset value: 0x00

BI	NAME	FUNCTION
[7:	0] ZA_OFFS[14:7]	Upper bits of the Z accelerometer offset cancellation. +/- 16g Offset cancellation in all Full Scale modes, 15 bit 0.98-mg steps

Name: ZA_OFFS_L

Address: 126 Serial IF: R/W



Document Number: RM-MPU-9250A-00 Revision: 1.4 Release Date: 9/9/2013

BIT	NAME	FUNCTION	
[7:1]	ZA_OFFS[6:0]	Lower bits of the Z accelerometer offset cancellation. +/- 16g Offset cancellation in all Full Scale modes, 15 bit 0.98-mg steps	
[0]	Reserved		



Document Number: RM-MPU-9250A-00

Revision: 1.4

Release Date: 9/9/2013

5 Register Map for Magnetometer

The register map for the MPU-9250's Magnetometer (AK8963) section is listed below.

Name	Address	READ/ WRITE	Description	Bit width	Explanation
WIA	00H	READ	Device ID	8	
INFO	01H	READ	Information	8	
ST1	02H	READ	Status 1	8	Data status
HXL	03H			8	V avia data
HXH	04H			8	X-axis data
HYL	05H	READ	Measurement data	8	Vd- d-t-
HYH	06H	I I I	Modern of Market	8	Y-axis data
HZL	07H			8	Z-axis data
HZH	08H			8	Z-axis data
ST2	09H	READ	Status 2	8	Data status
CNTL	0AH	READ/ WRITE	Control	8	
RSV	0BH	READ/ WRITE	Reserved	8	DO NOT ACCESS
ASTC	0CH	READ/ WRITE	Self-test	8	
TS1	0DH	READ/ WRITE	Test 1	8	DO NOT ACCESS
TS2	0EH	READ/ WRITE	Test 2	8	DO NOT ACCESS
I2CDIS	0FH	READ/ WRITE	I ² C disable	8	
ASAX	10H	READ	X-axis sensitivity adjustment value	8	Fuse ROM
ASAY	11H	READ	Y-axis sensitivity adjustment value	8	Fuse ROM
ASAZ	12H	READ	Z-axis sensitivity adjustment value	8	Fuse ROM

Table 2 Register Table

Addresses from 00H to 0CH and from 10H to 12H are compliant with automatic increment function of serial interface respectively. Values of addresses from 10H to 12H can be read only in Fuse access mode. In other modes, read data is not correct.



Document Number: RM-MPU-9250A-00

Revision: 1.4

Release Date: 9/9/2013

5.1 Register Map Description

Addr	Register Name	D7	D6	D5	D4	D3	D2	D1	D0
Read-on	ly Register								
00H	WIA	0	1	0	0	1	0	0	0
01H	INFO	INFO7	INFO6	INFO5	INFO4	INFO3	INFO2	INFO1	INFO0
02H	ST1	0	0	0	0	0	0	DOR	DRDY
03H	HXL	HX7	HX6	HX5	HX4	HX3	HX2	HX1	HX0
04H	HXH	HX15	HX14	HX13	HX12	HX11	HX10	HX9	HX8
05H	HYL	HY7	HY6	HY5	HY4	HY3	HY2	HY1	HY0
06H	HYH	HY15	HY14	HY13	HY12	HY11	HY10	HY9	HY8
07H	HZL	HZ7	HZ6	HZ5	HZ4	HZ3	HZ2	HZ1	HZ0
H80	HZH	HZ15	HZ14	HZ13	HZ12	HZ11	HZ10	HZ9	HZ8
09H	ST2	0	0	0	BITM	HOFL	0	0	0
Write/rea	d Register								
0AH	CNTL1	0	0	0	0	MODE3	MODE2	MODE1	MODE0
0BH	CNTL2	0	0	0	0	0	0	0	SRST
0CH	ASTC	-	SELF	-	-	-	-	-	-
0DH	TS1	-	-	-	-	-	-	-	-
0EH	TS2	-	-	-	-	-	-	-	-
0FH	I2CDIS	I2CDIS7	I2CDIS6	I2CDIS5	I2CDIS4	I2CDIS3	I2CDIS2	I2CDIS1	I2CDIS0
Read-on	ly Register								
10H	ASAX	COEFX7	COEFX6	COEFX5	COEFX4	COEFX3	COEFX2	COEFX1	COEFX0
11H	ASAY	COEFY7	COEFY6	COEFY5	COEFY4	COEFY3	COEFY2	COEFY1	COEFY0
12H	ASAZ	COEFZ7	COEFZ6	COEFZ5	COEFZ4	COEFZ3	COEFZ2	COEFZ1	COEFZ0

Table 3 Register Map

Note: When VDD is turned ON, POR function works and all registers of AK893 are initialized.

TS1 and TS2 are test registers for shipment test. Do not use these registers.

RSV is reserved register. Do not use this register.



Document Number: RM-MPU-9250A-00

Revision: 1.4

Release Date: 9/9/2013

5.2 Detailed Descriptions for Magnetometer Registers

This section details each register within the MPU-9250's Magnetometer section.

5.3 WIA: Device ID

Addr	Register name	D7	D6	D5	D4	D3	D2	D1	D0			
	Read-only register											
00H	WIA	0	1	0	0	1	0	0	0			

Device ID of AKM. It is described in one byte and fixed value.

48H: fixed

5.4 INFO: Information

Addr	Register name	D7	D6	D5	D4	D3	D2	D1	D0			
	Read-only register											
01H	INFO	INFO7	INFO6	INFO5	INFO4	INFO3	INFO2	INFO1	INFO0			

INFO[7:0]: Device information for AKM.

5.5 ST1: Status 1

Addr	Register name	D7	D6	D5	D4	D3	D2	D1	D0			
	Read-only register											
02H	ST1	0	0	0	0	0	0	0	DRDY			
	Reset	0	0	0	0	0	0	0	0			

DRDY: Data Ready

"0": Normal

"1": Data is ready

DRDY bit turns to "1" when data is ready in single measurement mode or self-test mode. It returns to "0" when any one of ST2 register or measurement data register (HXL to HZH) is read.

DOR: Data Overrun

"0": Normal

"1": Data overrun

DOR bit turns to "1" when data has been skipped in continuous measurement mode or external trigger measurement mode. It returns to "0" when any one of ST2 register or measurement data register (HXL~HZH) is read.



Document Number: RM-MPU-9250A-00

Revision: 1.4

Release Date: 9/9/2013

5.6 HXL to HZH: Measurement Data

Addr	Register name	D7	D6	D5	D4	D3	D2	D1	D0			
	Read-only register											
03H	HXL	HX7	HX6	HX5	HX4	HX3	HX2	HX1	HX0			
04H	HXH	HX15	HX14	HX13	HX12	HX11	HX10	HX9	HX8			
05H	HYL	HY7	HY6	HY5	HY4	HY3	HY2	HY1	HY0			
06H	HYH	HY15	HY14	HY13	HY12	HY11	HY10	HY9	HY8			
07H	HZL	HZ7	HZ6	HZ5	HZ4	HZ3	HZ2	HZ1	HZ0			
08H	HZH	HZ15	HZ14	HZ13	HZ12	HZ11	HZ10	HZ9	HZ8			
	Reset	0	0	0	0	0	0	0	0			

Measurement data of magnetic sensor X-axis/Y-axis/Z-axis

HXL[7:0]: X-axis measurement data lower 8bit

HXH[15:8]: X-axis measurement data higher 8bit

HYL[7:0]: Y-axis measurement data lower 8bit

HYH[15:8]: Y-axis measurement data higher 8bit

HZL[7:0]: Z-axis measurement data lower 8bit HZH[15:8]: Z-axis measurement data higher 8bit

Measurement data is stored in two's complement and Little Endian format. Measurement range of each axis is from -32760 ~ 32760 decimal in 16-bit output.

Measurement	data (each axis) [1	5:0]	Magnetic flux
Two's complement	Hex	Decimal	density [μT]
0111 1111 1111 1000	7FF8	32760	4912(max.)
			I
0000 0000 0000 0001	0001	1	0.15
0000 0000 0000 0000	0000	0	0
1111 1111 1111 1111	FFFF	-1	-0.15
1	l	I	l
1000 0000 0000 1000	8008	-32760	-4912(min.)

Table 4 Measurement data format



Document Number: RM-MPU-9250A-00

Revision: 1.4

Release Date: 9/9/2013

5.7 ST2: Status 2

Addr	Register name	D7	D6	D5	D4	D3	D2	D1	D0			
	Read-only register											
09H	ST2	0	0	0	BITM	HOFL	0	0	0			
Reset 0			0	0	0	0	0	0	0			

HOFL: Magnetic sensor overflow

"0": Normal

"1": Magnetic sensor overflow occurred

In single measurement mode, continuous measurement mode, external trigger measurement mode and self-test mode, magnetic sensor may overflow even though measurement data regiseter is not saturated. In this case, measurement data is not correct and HOFL bit turns to "1". When next measurement stars, it returns to "0".

BITM: Output bit setting (mirror)

"0": 14-bit output "1": 16-bit output

Mirror data of BIT bit of CNTL1 register.

ST2 register has a role as data reading end register, also. When any of measurement data register is read in continuous measurement mode or external trigger measurement mode, it means data reading start and taken as data reading until ST2 register is read. Therefore, when any of measurement data is read, be sure to read ST2 register at the end.

5.8 CNTL1: Control 1

Addr	Register name	D7	D6	D5	D4	D3	D2	D1	D0			
	Read-only register											
0AH	0AH											
	Reset	0	0	0	0	0	0	0	0			

MODE[3:0]: Operation mode setting

"0000": Power-down mode

"0001": Single measurement mode

"0010": Continuous measurement mode 1 "0110": Continuous measurement mode 2 "0100": External trigger measurement mode

"1000": Self-test mode

"1111": Fuse ROM access mode Other code settings are prohibited

BIT: Output bit setting

"0": 14-bit output "1": 16-bit output



Document Number: RM-MPU-9250A-00

Revision: 1.4

Release Date: 9/9/2013

When each mode is set, AK8963 transits to set mode.

When CNTL register is accessed to be written, registers from 02H to 09H are initialized.

5.9 CNTL2: Control 2

Addr	Register name	D7	D6	D5	D4	D3	D2	D1	D0			
	Read-only register											
0BH	CNTL2	0	0	0	0	0	0	0	SRST			
	Reset	0	0	0	0	0	0	0				

SRST: Soft reset

"0": Normal "1": Reset

When "1" is set, all registers are initialized. After reset, SRST bit turns to "0" automatically.

5.10 ASTC: Self-Test Control

Addr	Register name	D7	D6	D5	D4	D3	D2	D1	D0			
	Write/read register											
0CH	OCH ASTC - SELF											
	Reset	0	0	0	0	0	0	0	0			

SELF: Self-test control

"0": Normal

"1": Generate magnetic field for self-test

Do not write "1" to any bit other than SELF bit in ASTC register. If "1" is written to any bit other than SELF bit, normal measurement cannot be done.

5.11 TS1, TS2: Test 1, 2

Addr	Register name	D7	D6	D5	D4	D3	D2	D1	D0			
	Write/read register											
0DH	TS1	-	-	-	-	-	-	-	-			
0EH	TS2	-	-	-	-	-	-	-	-			
	Reset	0	0	0	0	0	0	0	0			

TS1 and TS2 registers are test registers for shipment test. Do not use these registers.

5.12 I2CDIS: I²C Disable

Addr	Register name	D7	D6	D5	D4	D3	D2	D1	D0			
	Write/read register											
0FH	0FH I2CDIS I2CDIS7 I2CDIS6 I2CDIS5 I2CDIS4 I2CDIS3 I2CDIS2 I2CDIS1 I2CDIS0											
	Reset	0	0	0	0	0	0	0				



Document Number: RM-MPU-9250A-00

Revision: 1.4

Release Date: 9/9/2013

This register disables I^2C bus interface. I^2C bus interface is enabled in default. To disable I^2C bus interface, write "00011011" to I2CDIS register. Then I^2C bus interface is disabled.

Once I²C bus interface is disabled, it is impossible to write other value to I2CDIS register. To enable I2C bus interface, reset AK8963 or input start condition 8 times continuously.

5.13 ASAX, ASAY, ASAZ: Sensitivity Adjustment values

Addr	Register name	D7	D6	D5	D4	D3	D2	D1	D0
Read-only register									
10H	ASAX	COEFX7	COEFX6	COEFX5	COEFX4	COEFX3	COEFX2	COEFX1	COEFX0
11H	ASAY	COEFY7	COEFY6	COEFY5	COEFY4	COEFY3	COEFY2	COEFY1	COEFY0
12H	ASAZ	COEFZ7	COEFZ6	COEFZ5	COEFZ4	COEFZ3	COEFZ2	COEFZ1	COEFZ0
Reset		-	-	-	-	-	-	-	-

Sensitivity adjustment data for each axis is stored to fuse ROM on shipment.

ASAX[7:0]: Magnetic sensor X-axis sensitivity adjustment value ASAY[7:0]: Magnetic sensor Y-axis sensitivity adjustment value ASAZ[7:0]: Magnetic sensor Z-axis sensitivity adjustment value

■ Sensitivity Adjustment

The sensitivity adjustment is done by the equation below;

$$Hadj = H \times \left(\frac{(ASA - 128) \times 0.5}{128} + 1\right),$$

where H is the measurement data read out from the measurement data register, ASA is the sensitivity adjustment value, and Hadj is the adjusted measurement data.



Document Number: RM-MPU-9250A-00

Revision: 1.4

Release Date: 9/9/2013

6 Advanced Hardware Features

The MPU-9250 includes advanced hardware features that support Android that can be enabled and disabled through simple hardware register settings. The advanced hardware features are not initially enabled after device power up, and must be individually enabled and configured. The following motion-based functions are supported and do not require an external hub or microprocessor:

- Android Orientation
- Step Count, Step Detection
- Significant Motion Detection
- Batch mode
- Low Power Quaternion (3, 6, 9 axis)

Features supported for embedded applications include:

- · Pedometer, Directional Tap
- Low Power Quaternion (3, 6, 9 axis)

Features supported for Windows 8 UMDF implementation (no external hub required) include:

Quaternion Output with CS/CSI filtering

For further details please see the Application Note "Programming Sequence for DMP Hardware Functions."



Document Number: RM-MPU-9250A-00

Revision: 1.4

Release Date: 9/9/2013

This information furnished by InvenSense is believed to be accurate and reliable. However, no responsibility is assumed by InvenSense for its use, or for any infringements of patents or other rights of third parties that may result from its use. Specifications are subject to change without notice. InvenSense reserves the right to make changes to this product, including its circuits and software, in order to improve its design and/or performance, without prior notice. InvenSense makes no warranties, neither expressed nor implied, regarding the information and specifications contained in this document. InvenSense assumes no responsibility for any claims or damages arising from information contained in this document, or from the use of products and services detailed therein. This includes, but is not limited to, claims or damages based on the infringement of patents, copyrights, mask work and/or other intellectual property rights.

Certain intellectual property owned by InvenSense and described in this document is patent protected. No license is granted by implication or otherwise under any patent or patent rights of InvenSense. This publication supersedes and replaces all information previously supplied. Trademarks that are registered trademarks are the property of their respective companies. InvenSense sensors should not be used or sold in the development, storage, production or utilization of any conventional or mass-destructive weapons or for any other weapons or life threatening applications, as well as in any other life critical applications such as medical equipment, transportation, aerospace and nuclear instruments, undersea equipment, power plant equipment, disaster prevention and crime prevention equipment.

InvenSense® is a registered trademark of InvenSense, Inc. MPUTM, MPU-9250TM, MPU-6000TM, MPU-6050TM, Digital Motion Processor → DMP → Motion Processing Unit → MotionFusion → and MotionApps → are trademarks of InvenSense, Inc.

©2013 InvenSense, Inc. All rights reserved.

