Antenna				Params		
PK	id	INTEGER	+	PK, FK	id	INTEGER
	NGR	TEXT			Date	TEXT
	Longitude_Latitude	TEXT			Ensemble	TEXT
	Site_Height	INTEGER			Licence	TEXT
	Aerial_height_m	REAL			Ensemble_Area	TEXT
	Power_kW	REAL			EID	TEXT
	Dir_Max_ERP	REAL			DAB_Multiplex	TEXT
			•		Transmitter_Area	TEXT
					Site	TEXT
					Freq	REAL
					Block	TEXT