CAMERA CARE

Harmful Elements



Dirt | Dust | Sand | Water | Smoke | Humidity

Gear

1. Brush





A brush is a handy tool for cleaning your lens. You can use it on the exposed glass elements and the plastic exterior. Not designed for internal use.

2. Hand Airblower



This tool provides a burst of air, designed to remove dust from the inside of your camera body.

3. Q-Tip



Use these to clean the hard to reach nooks and crannies of your lens and camera.

4. Cleaning Cloth



Keep front glass element free of smudges.

5. Isopropyl Alcohol

Remove dirt and grime from the contacts.