Inspect User Guide

Version T-2022.03, March 2022



Copyright and Proprietary Information Notice

© 2022 Synopsys, Inc. This Synopsys software and all associated documentation are proprietary to Synopsys, Inc. and may only be used pursuant to the terms and conditions of a written license agreement with Synopsys, Inc. All other use, reproduction, modification, or distribution of the Synopsys software or the associated documentation is strictly prohibited.

Destination Control Statement

All technical data contained in this publication is subject to the export control laws of the United States of America. Disclosure to nationals of other countries contrary to United States law is prohibited. It is the reader's responsibility to determine the applicable regulations and to comply with them.

Disclaimer

SYNOPSYS, INC., AND ITS LICENSORS MAKE NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Trademarks

Synopsys and certain Synopsys product names are trademarks of Synopsys, as set forth at https://www.synopsys.com/company/legal/trademarks-brands.html. All other product or company names may be trademarks of their respective owners.

Free and Open-Source Licensing Notices

If applicable, Free and Open-Source Software (FOSS) licensing notices are available in the product installation.

Third-Party Links

Any links to third-party websites included in this document are for your convenience only. Synopsys does not endorse and is not responsible for such websites and their practices, including privacy practices, availability, and content.

www.synopsys.com

	Conventions	11
	Customer Support	11
1.	Introducing Inspect Functionality	13
	Inspect Functionality	13
	User Interface	14
	Datasets Group Box	15
	Curves Group Box	15
	Plot Area	15
	Supported File Types and Data Formats	16
	Data Formats	16
	Parameter Files	17
	Save Files	17
	Starting the Tool From the Command Line	17
	Examples of Using Command-Line Options	18
2.	Basic Operations Using the User Interface	20
	Loading Datasets	20
	Reloading Datasets	20
	Updating Datasets Automatically	20
	Applying Plotting Actions	21
	Zoom Operations	22
	Working With Scripts	22
	Creating Scripts	22
	Running Scripts	23
	Preferences	23
	Saving Files	24
	Evananting Cumra Data	0.

Saving Curves in PNG Format. 3. Working With Curves. Selecting Multiple Projects and Groups. Creating Curves. Automatically Generated Curve Names and Legend Text. Selecting and Unselecting Curves. Changing the Attributes of a Curve Example: Display a Curve With Data Points and No Lines Between Point Moving the Legend. Reordering Curves. Creating Curves.	26 26 27 27 28
Selecting Multiple Projects and Groups Creating Curves Automatically Generated Curve Names and Legend Text Selecting and Unselecting Curves Changing the Attributes of a Curve Example: Display a Curve With Data Points and No Lines Between Point Moving the Legend Reordering Curves	26 26 26 27 27 28 ts 29
Creating Curves Automatically Generated Curve Names and Legend Text Selecting and Unselecting Curves Changing the Attributes of a Curve Example: Display a Curve With Data Points and No Lines Between Poin Moving the Legend Reordering Curves.	26 27 27 28
Automatically Generated Curve Names and Legend Text	27 27 28
Selecting and Unselecting Curves. Changing the Attributes of a Curve Example: Display a Curve With Data Points and No Lines Between Poin Moving the Legend Reordering Curves.	27 28
Changing the Attributes of a Curve	28
Example: Display a Curve With Data Points and No Lines Between Poin Moving the Legend	
Reordering Curves	
-	30
Creating Curves	30
Creating Curves Automatically When Loading Files	30 30 31 es 32 32
Deleting Curves	33
4. Configuring the View	34
Modifying Axes	34 34 34 35 35
Configuring the Plot Area. Changing Attributes of Plot Area Adding Labels Displaying the Dataset of a Curve Cleaning Up the Plot Area Sampling Points in the Plot Area	37 37 39 40 40

5.	Curve Interpolation and Operations	42
	Curve Operations	42
	Limitation of the X-Axis Values of the Dataset	43
	More Than One Curve in a Formula	43
	Handling Datasets in Formula Processing	44
	Dataset Created for Result Curves	45
	Curve Handling on Interpolation	46
	Determining the Scale (Linear or Logarithmic) of Curves	46
6.	Formulas and Macros	47
	Using Formulas	47
	Formula Library	47
	Using Macros	51
	Example: ADD Macro	51
	Example: DIFFMULT Macro	51
7.	Using the Scripting Language	52
	Overview of the Scripting Language	52
	General-Purpose Commands	53
	ft_scalar	53
	Reading and Writing Files	53
	cv_write	53
	fi_writeBitmap	54
	fi_writeEps	54
	fi_writePs	55
	graph_load	55
	graph_write	56
	param_load	56
	param_write	56
	proj_getDataSet	57 57
	proj_getList	57
	proj_getNodeList	57 50
	proj_load	58 58
	proj_unioau	58

Creating, Displaying, and Deleting Curves	59
cv_create	59
cv_createDS	59
cv_createFromScript	60
cv_createWithFormula	60
cv_delete	61
cv_display	61
cv_logScale, cv_log10Scale	61
cv_split	62
cv_split_disc	62
Changing Attributes	63
cv_lineColor	63
cv_lineStyle	63
cv_renameCurve	63
cv_set_interpol	64
cv_setCurveAttr	64
gb_setpreferences	65
gr_createLabel	65
gr_deleteLabel	65
gr_formatAxis	66
gr_mappedAxis	66
gr_precision	66
gr_setAxisAttr	67
gr_setGeneralAttr	67
gr_setGridAttr	68
gr_setLegendAttr	68
gr_setLegendPos	69
gr_setTitleAttr	69
Accessing Curve Data	69
cv_getVals	69
cv_getValsX	70
cv_getValsY	70
cv_getXaxis	70
cv_getYaxis	71
cv_printVals	71
Transforming Curve Data	71
cv_abs	71
ov dolPto	72

	cv_inv	72
	cv_reset	72
	Extracting Parameters	73
	f_Gamma	73
	f_gm	73
	f_hideInternalCurves	74
	f_IDSS	74
	f_KP	74
	f_Ron	75
	f_Rout	75
	f_showInternalCurves	75
	f_TetaG	76
	f_VT	76
	f_VT1	77
	f_VT2	77
	Computing	77
	cv_compute	77
	cv_getZero	78
	macro_define	78
	Controlling Scripts	78
	script_break	78
	script_exit	79
	script_sleep	79
		79
	Examples of Using the Scripting Language	79 79
	Computing the Dose of Implanted Arsenic	80
	Creating a Macro to Compute vt	00
8.	Working With Script Libraries	81
	Loading Libraries	81
		81
	Adding a Site Library	
	Extraction Library	82
	cv_linTransCurve	82
	cv_scaleCurve	83
	ExtractBVi	83
	ExtractBVv	84
	ExtractEarlyV	84

	ExtractGm
	ExtractGmb
	ExtractIoff
	ExtractMax
	ExtractRon
	ExtractSS
	ExtractValue
	ExtractVtgm
	ExtractVtgmb
	ExtractVti
	FilterTable
	Syntax of FilterTable
The	extend Library
	cv_addCurve
	cv_addDataset
	cv_angularMap
	cv_autoIncrStyle
	cv_disp
	cv_exists
	cv_getGlobalExtrema
	cv_getLocalExtrema
	cv_getNames
	cv_getRange
	cv_getXmax
	cv_getXmin
	cv_getYmax
	cv_getYmin
	cv_integrate
	cv_isVisible
	cv_linFit
	cv_linTrans
	cv_monotonicX
	cv_nextColor
	cv_nextLine
	cv_nextSymbol
	cv_resetColor
	cv_resetFillColor
	cv_resetLine
	ov roaatStylo

cv_round cv_scale cv_setFillColor cv_setSymbol cv_sort cv_write dbputs ds_getValue fi_readTxtFile fi_readTxtFileHeader
cv_setFillColor cv_setSymbol cv_sort cv_write dbputs ds_getValue fi_readTxtFile
cv_setSymbol. cv_sort cv_write dbputs ds_getValue fi_readTxtFile.
cv_sort cv_write dbputs ds_getValue fi_readTxtFile
cv_write dbputs ds_getValue fi_readTxtFile
dbputs
ds_getValue
fi_readTxtFile
_
fi readTxtFileHeader
-
gr_axis
gr_resetAxis
gr_setStyle
ldiff
lintersect
Itranspose
lunion
proj_check
proj_datasetExists
proj_getGroups
proj_groupExists
proj_loadPlx
The PhysicalConstants Library
IC-CAP Model Parameter Extraction Library
Exporting Data
Header Information
userInput
iccapInput
output
Array Data
Curve Comparison Library
cvcmp_CompareTwoCurves
cvcmp_DeltaTwoCurves
Deferences

Α.	Elements of User Interface	123
	Toolbar Buttons	123
	File Menu	124
	Edit Menu	125
	Curve Menu	126
	Script Menu	127
	Extensions Menu	128
	Help Menu	128
В.	Known Limitations	129
	The diff(formula) and integr(formula) Operators	129
	The vecvalx(formula) and vecvaly(formula) Operators	129
	No Support for Right Y-Axes	130

About This Guide

The Inspect tool is a curve display and analysis program. It works with curves specified at discrete points. Inspect allows users to work interactively with data using both a graphical user interface and a scripting language.

For additional information, see:

- The TCAD Sentaurus™ release notes, available on the Synopsys® SolvNetPlus support site (see Accessing SolvNetPlus on page 12)
- Documentation available on the SolvNetPlus support site

Conventions

The following conventions are used in Synopsys documentation.

Convention	Description
Bold text	Identifies a selectable icon, button, menu, or tab. It also indicates the name of a field or an option.
Courier font	Identifies text that is displayed on the screen or that the user must type. It identifies the names of files, directories, paths, parameters, keywords, and variables.
Italicized text	Used for emphasis, the titles of books and journals, and non-English words. It also identifies components of an equation or a formula, a placeholder, or an identifier.
Key+Key	Indicates keyboard actions, for example, Ctrl+I (press the I key while pressing the Control key).
Menu > Command	Indicates a menu command, for example, File > New (from the File menu, choose New).

Customer Support

Customer support is available through the Synopsys SolvNetPlus customer support website and by contacting the Synopsys support center.

Accessing SolvNetPlus

The SolvNetPlus support site includes an electronic knowledge base of technical articles and answers to frequently asked questions about Synopsys tools. The site also gives you access to a wide range of Synopsys online services, which include downloading software, viewing documentation, and entering a call to the Support Center.

To access the SolvNetPlus site:

- 1. Go to https://solvnetplus.synopsys.com.
- 2. Enter your user name and password. (If you do not have a Synopsys user name and password, follow the instructions to register.)

Contacting Synopsys Support

If you have problems, questions, or suggestions, you can contact Synopsys support in the following ways:

- Go to the Synopsys Global Support Centers site on www.synopsys.com. There you can
 find email addresses and telephone numbers for Synopsys support centers throughout
 the world.
- Go to either the Synopsys SolvNetPlus site or the Synopsys Global Support Centers site and open a case (Synopsys user name and password required).

Contacting Your Local TCAD Support Team Directly

Send an email message to:

- support-tcad-us@synopsys.com from within North America and South America
- support-tcad-eu@synopsys.com from within Europe
- support-tcad-ap@synopsys.com from within Asia Pacific (China, Taiwan, Singapore, Malaysia, India, Australia)
- support-tcad-kr@synopsys.com from Korea
- support-tcad-jp@synopsys.com from Japan

Introducing Inspect Functionality

This chapter introduces the Inspect tool and its user interface.

Inspect Functionality

The Inspect tool can display and analyze curves. It features a user interface, a scripting language, and an interactive language for computations with curves.

An Inspect curve is a sequence of points defined by a one-dimensional array of x-coordinates and y-coordinates (floating-point values). An array of coordinates that can be mapped to one of the axes is referred to as a *dataset*. In Inspect, datasets can be combined and mapped to the x-axis and y-axis to create and display a curve.

The Inspect tool works on data consisting of *groups* of datasets. Each group consists of two or more datasets of equal length, where elements with an identical index represent related values. Datasets in a group can be divided into *named groups*. By pairing related values of two datasets from the same group, points (or nodes) of a discrete curve are obtained.

Usually, a dataset represents a physical quantity, such as voltage, current, or time. Groups of datasets represent functionally related physical quantities, for example, measurements of current and voltage, and the times at which these measurements are taken. Named groups represent semantically related datasets, for example, meshing results at one of several contacts of a semiconductor device.

In addition to its name, a dataset can have other attributes associated with it, for example, the name of the physical quantity represented by the dataset, the name of the unit in which this quantity has been measured, the preferred color of the curve when it is visualized, and interpolating function. Depending on the particular input file format, this information can be stored partially in the data file and partially in separate files.

The Inspect tool can read different data formats and file formats (see Data Formats on page 16).

Data in TDR and TIF formats contains the names of the physical quantities that datasets represent. The TDR and TIF formats allow you to split a dataset group into named groups.

User Interface

Data in XGRAPH format always has groups consisting of two datasets only. Additional dataset attributes are specified inside the file with appropriate keywords.


To distinguish datasets from different data files, the datasets from one data file are grouped into a *project*. The name of the data file without an extension is taken as the project name. When more than one file with the same name is loaded, Inspect adds the suffix .n to the project name, where n is the smallest number not yet used as a suffix for another project name.

User Interface

The user interface of the Inspect tool has the following work areas (see Figure 1):

- Datasets group box
- Curves group box
- · Plot area

Figure 1 Main window showing work areas



Menus and toolbar buttons are documented in Appendix A on page 123.

The status line at the bottom of the main window displays information about the current Inspect session and the position of the pointer in the plot area.

Datasets Group Box

This group box has the following panes for selecting and combining datasets to create curves:

- The *top pane* lists the currently loaded data files (or *projects*). In the example shown in Figure 1 on page 14, only one data file n57_des has been loaded (the file extension is not displayed).
- The *middle pane* lists the names of the dataset groups belonging to the selected data file. A group having one or more datasets can correspond to an electrode or a thermode of a device. Datasets that do not belong to any group are also displayed. In Figure 1, hTave and hTmax are independent datasets. In addition, drain, source, substrate, and gate are groups, each having several datasets.
- The bottom pane lists the names of the datasets belonging to the selected group.

The **To X-Axis**, **To Left Y-Axis**, and **To Right Y-Axis** buttons map datasets to a particular axis.

Curves Group Box

This group box has one pane that displays the names of existing curves, and it has the following buttons:

- Click **New** to create a curve using the formula library (see Creating Curves Using Formulas on page 31).
- Click **Edit** to change the graphical attributes of a curve (see Changing the Attributes of a Curve on page 28).
- Click **Delete** to remove curves that are selected in the pane.
- Click **Delete All** to remove all curves in the pane.

Plot Area

The plot area is where curves are drawn. The toolbar buttons are used to change the coordinate system for zooming sessions, to display or remove the legend text, to change the order in which curves are displayed, and to switch between linear and logarithmic scale.

Supported File Types and Data Formats

This section describes the supported file types and data formats.

Data Formats

Inspect works with different file formats, which contain a series of points, described by x-coordinates and y-coordinates, representing datasets. Inspect handles and displays these datasets as curves.

Table 1 Supported data formats

Data format	Description
CSV	Comma-separated value format, which is recognized by many applications. The file extension is .csv.
PLT	Plain text format for 1D curves.
PLX	Format generated by Sentaurus Process.
TDR	Format recognized by most Synopsys TCAD tools. The file extension is .tdr.
TIF	Synopsys TCAD format for I–V curves, recognized by most Synopsys TCAD tools. The file extension is $.ivl$. For a description of the TIF format, see $Taurus^{TM}$ $Visual$ $User Guide$, Data Formats.
TXT	Tab-delimited text format. The file extension is .txt. Each curve is written into a block with the curve name, and the x- and y-data.
XGRAPH	Each curve is written into a block with the curve name, and the x- and y-data. The file extension is .xy. Typically, there is one xy data–point pair per line. Each value or column is separated by space, tabs, commas, semicolons, or colons. For more information, go to http://www.xgraph.org .
XMGR	Format used by the shareware xy plotting tool Xmgr. The file extension is .xmgr. For more information, go to https://plasma-gate.weizmann.ac.il/Xmgr/.

Parameter Files

When the Inspect tool is customized interactively according to user preferences, the current setup can be stored in a parameter file, which usually has the extension .par. In a parameter file, Inspect stores the following information:

- · Plot area attributes
- Coordinate area attributes
- Axes attributes
- User-defined macros
- Printer setup
- Curve attributes

When the Inspect tool starts, it looks for a parameter file named <code>inspect.par</code> in the current directory. If such a file is found, then the tool loads it and sets the plot settings, macros, and printer setup according to the values in this file. If no file is found in the current directory, then the tool looks for a parameter file named <code>inspect.par</code> in the <code>STDB</code> directory. If no file is found, then the tool uses the default values.

You can also load a parameter file explicitly when starting the tool or during its execution.

Curve attributes saved in the parameter file are not applied automatically to curves in the tool. To do this, you must specify the command-line option <code>-applyCurveAttr</code> when starting Inspect.

Save Files

The entire current state of Inspect (projects, curves, and settings) can be saved to a save file, which is used to restore the saved state at any time and usually has the .sav extension.

Data from all loaded projects is also stored in a save file. This means that for restoring the saved state, the data files are no longer necessary.

Starting the Tool From the Command Line

You can start the Inspect tool from the command line by typing:

```
inspect [<options>] [<FILES>]
```

You can also specify options (see Table 2 on page 18) and files on the command line. See Examples of Using Command-Line Options on page 18.

Chapter 1: Introducing Inspect Functionality

Starting the Tool From the Command Line

The <FILES> arguments can be one or several data files, or a save file that is loaded when Inspect is started. Inspect automatically distinguishes between data files and save files.

Note:

You can also start Inspect from Sentaurus Workbench.

Table 2 Command-line options

Option	Description
-applyCurveAttr	Applies curve attributes saved in a parameter file (.par) and a save file (.sav).
-batch	If specified, then the Inspect tool does not open the user interface while executing a script file.
-c FILE ¹	Reads the specified setup file after Inspect is launched.
-display	Sets the display to use.
-f FILE ¹	Executes the specified script file after Inspect is launched.
-geometry	Sets the size and position of the main window of the Inspect tool.
-h[elp]	Displays information about the command-line options.
-m FILE ¹	Executes the specified macro file after Inspect is launched.
-oldInterpol	Forces the Inspect tool to use the interpolation criteria of earlier versions.
-oldplx	Loads a .plx file and automatically creates curves with the old scheme.
-v[ersion]	Prints the version of the Inspect tool.
-verbose	Displays all messages.

^{1.} Simulation results (.plt, .tdr, .ivl) files as well as save (.sav) files.

Examples of Using Command-Line Options

The Inspect tool starts in interactive mode and loads datasets from the n53_des.plt file:

```
inspect n53_des.plt
```

Inspect starts in interactive mode, loads three data files, and reads the plot area, axes, macros, and printer setup from the parameter file mySetup.par:

```
inspect file1.plt file2.plt file3.plt -c mySetup.par
```

Chapter 1: Introducing Inspect Functionality

Starting the Tool From the Command Line

The Inspect tool starts in interactive mode and executes the bipolar.cmd script file:

inspect -f bipolar.cmd

The Inspect tool starts in batch mode and executes the bipolar.cmd script file:

inspect -batch -f bipolar.cmd

Basic Operations Using the User Interface

This chapter describes the basic operations using the Inspect user interface.

Loading Datasets

You must open a data file to load a dataset.

To load a dataset:

- 1. Choose File > Load Dataset, or press Ctrl+L.
 - The Load Dataset dialog box opens.
- 2. Select a data file by changing the **Files of type** field if needed.
- 3. Click **Open** or double-click a file to open it.

Reloading Datasets

You can reload displayed datasets if the file is updated while viewing it in the Inspect tool.

To reload a dataset:

► Choose File > Update Datasets, or press Ctrl+U.

Updating Datasets Automatically


If a dataset displayed in the plot area is updated frequently by other tools, then it can be useful to reload the dataset frequently so that refreshed data is shown in the plot area.

Applying Plotting Actions

To update datasets automatically:

1. Choose File > Automatically Update Datasets.

The Automatic Update dialog box opens.



- 2. Select Enable.
- 3. Set the time (in seconds) between reloads.
- 4. Click OK.

Applying Plotting Actions

When working with multiple datasets of a similar structure, it is useful to apply several plotting actions made on one dataset to other datasets. These plotting actions include creating curves (explicitly and by formula) and changing curve attributes. Inspect stores the set of actions made on the current dataset.

To repeat plotting actions for another dataset:

- 1. Select the dataset or datasets.
- 2. Choose Edit > Redo Last Plot, or press Ctrl+E.

All plotting actions are applied to the selected datasets.

This feature is helpful when datasets contain data of a similar structure, for example, projects with groups of the same names. Otherwise, it can happen that the current dataset does not contain some data necessary for creating a curve. In this case, Inspect generates an error message.

Note:

The Inspect tool stores plotting actions applied to the currently selected dataset only. When you select another dataset, the accumulated set of stored actions is cleaned up.

Zoom Operations

To perform zoom operations on curves displayed in the plot area, use the relevant toolbar buttons (see Table 7 on page 123).

Working With Scripts

In Inspect, any sequence of operations can be stored and reproduced using scripts (see Chapter 7 on page 52). The recorded operations are repeated when the script is executed. The following operations can be recorded in a script:

- Loading and unloading projects
- · Loading and saving the current project
- Changing axis attributes
- · Exporting, creating, and deleting curves
- · Changing curve attributes
- Transforming actions on curves
- Any use of the formula library to create other curves

Creating Scripts

To create a script:

1. Choose Script > Record > Start.

The Record Script File dialog box opens.

- 2. Select or create a script file, and click **Save**.
 - Inspect starts to store every operation until you stop recording.
- 3. Choose Script > Record > Stop.

Running Scripts

To run a script:

1. Choose **Script** > **Run Script**, or press Ctrl+R.

The Run Script File dialog box opens.

- 2. Select a script file.
- 3. Click Open.


Preferences

In Inspect, preferences relate to the precision of values handled for curve coordinates and the interpolation method used to operate on and display curves.

To set the preferences:

Choose File > Preferences.

The Preferences dialog box opens.



- 2. In the **Precision** box, select the number that indicates how many decimal digits are used to handle coordinates for curve points.
- 3. If required, select **Use Old Interpolation** to force Inspect to use the interpolation criteria of earlier versions to handle all computations with curves.
- 4. Click OK.

Saving Files

To save files, you can either:

- Choose **File > Save Setup** to save the current setup in a parameter .par file.
- Choose File > Save All to save the entire current state of the Inspect tool in a .sav file.

Exporting Curve Data

Curve data can be written to data files in different formats (see Data Formats on page 16). You can select different formats from the **File > Export** command.

To export curve data in TDR format:

1. Choose File > Export > TDR.

The Write .tdr File dialog box opens.

- 2. Select or create a TDR file.
- 3. Click Save.

Printing Curves Shown in the Plot Area

Curves shown in the plot area can be printed as a single image.

To print curves shown in the plot area:

1. Choose File > Print, or press Ctrl+P.

The Printer Setup dialog box opens.

On the Windows operating system, a standard print dialog box is displayed. On Linux operating systems, a special print dialog box opens.

2. Specify the print configuration as required.

Note:

In the **Command** field, you can specify a command for using the printer.



3. Click OK.

Saving Curves in PNG Format

Curves shown in the plot area can be saved as a bitmap file in PNG format. This bitmap file can be imported into applications for documentation and reporting purposes.

To save curves in PNG file format:

- Choose File > Write Bitmap, or press Ctrl+W.
 The Write PNG bitmap file dialog box opens.
- 2. Enter the name of the file.
- 3. Click Save.

You can save the curves shown in the plot area in a <code>.png</code> file directly from your Inspect script using the <code>fi_writeBitmap</code> command (see <code>fi_writeBitmap</code> on page 54). This is a screen-image exporting method that works when Inspect starts in interactive mode.

Note:

Since this exporting method is based on the X11 utility xwd, it works only if a valid DISPLAY is available, that is, an X server is required.

Working With Curves

This chapter describes how to create and work with curves using the Inspect user interface.

Selecting Multiple Projects and Groups

The Inspect tool displays curves that are formed by datasets from different data files.

You select projects and groups from the Datasets group box (see Datasets Group Box on page 15). If you select more than one group, only the dataset names that exist in all the selected groups appear in the bottom pane.

In Figure 1 on page 14, if you select two groups (drain and source) in the middle pane, then the OuterVoltage, InnerVoltage, QuasiFermiPotential, DisplacementCurrent, eCurrent, and hCurrent dataset names appear in the bottom pane. If you select the group hTmax, in addition, no dataset names are displayed in the bottom pane because no datasets with identical names exist in all the selected groups.

Note:

The names of datasets must be identical. Datasets, themselves, can be different.

When more than one project is loaded, the same rule applies. Consequently, Inspect shows only common groups and datasets of multiple-selected projects in the middle and bottom panes of the Datasets group box.

Creating Curves

The first curve displayed in Figure 1 on page 14 maps time to the x-axis and TotalCurrent of drain to the left y-axis.

To create a curve:

- 1. Select the dataset group time in the middle pane of the Datasets group box.
- 2. Click To X-Axis.

Chapter 3: Working With Curves

Automatically Generated Curve Names and Legend Text

- 3. Select the group drain in the middle pane of the Datasets group box.
- 4. Select the dataset TotalCurrent from the bottom pane of the Datasets group box.
- 5. Click To Left Y-Axis.

The Inspect tool draws a curve in the plot area using these two datasets. The name of the curve is generated automatically using names and other attributes of groups and datasets (and possibly projects). The upper-right corner of the plot area shows the legend, which displays curve names and drawing styles.

The second curve is created in the same way: time is mapped to the x-axis and TotalCurrent from source is mapped to the left y-axis. The next curve is created with time mapped to the x-axis and TotalCurrent from substrate mapped to the right y-axis.

When these steps are completed, the main window resembles Figure 1 on page 14.

Automatically Generated Curve Names and Legend Text

When a curve is created, a default name for it is generated. With plot files (TDR or TIF files), the name is a combination of the physical quantity name and the group name of the y-dataset if the dataset belongs to a group.

For example, if the physical quantity name is OuterVoltage and the dataset belongs to a group named drain, the curve name is OuterVoltage_drain.

With XGRAPH files, a default name is created using the data file name and the comment line preceding the dataset pair in the file. If the generated curve name already exists, an .n suffix is added, where n is the smallest number not yet used as a suffix in another name.

In addition to a name, a curve has legend text, which identifies the curve in the plot area. When a curve is created, the corresponding text is initialized with the curve name.

Selecting and Unselecting Curves

To select a curve, click the curve name in the Curves group box, or click the curve name in the legend.

After selection, the curve name is highlighted in the Curves group box, the plot area, and the legend.

To unselect a curve, right-click in the plot area.

Changing the Attributes of a Curve

A curve is displayed according to its attributes. When a curve is created, default values are assigned to all attributes. A curve is drawn with lines connecting nodes and, optionally, with node markers.

To change the attributes of a curve:

Double-click a curve in the plot area or in the Curves group box.
 The Curve Attributes dialog box opens (see Figure 2 on page 29).

- 2. On the **General** tab, change the axis to which the curve is mapped, if required.
- 3. On the **Line** tab, change the following attributes of lines:

Color Default color is assigned from a list of colors that are not assigned to existing curves.

Style When all available colors are exhausted, a line drawing style is assigned from a list of styles, so that each curve has a unique combination of color and style.

Width Line width in pixels. Default: 1

4. On the **Marker** tab, change the following attributes of node markers:

Shape No node markers by default.

Size Size of markers in pixels. Default: 5


Outline Color It is the same as the line color by default.

Outline Width Width of markers in pixels. Default: 1

Fill Color It is the same as the line color by default.

- 5. On the **Interpolation** tab, change the interpolation used on the x-axis and y-axis, if required.
- 6. Click Apply.
- 7. Click **OK**.

Figure 2 Curve Attributes dialog box with all tabs shown



Example: Display a Curve With Data Points and No Lines Between Points

To display a curve with data points and no lines between these points:

- Double-click a curve in the plot area or in the Curves group box.
 The Curve Attributes dialog box opens (see Figure 2).
- 2. Click the Marker tab.

Chapter 3: Working With Curves

Moving the Legend

- 3. In the **Shape** box, select **circle**.
- 4. Click the **Line** tab.
- 5. Set Width to 0.
- 6. Click Apply.
- 7. Click OK.

Moving the Legend

To move the legend in the plot area:

▶ Use the middle mouse button and drag the legend to its new location.

Reordering Curves

You can change the order in which curves are displayed in the plot area to distinguish one curve from another, for example, if some have a significant intersection.

To reorder curves, choose one of the following options from the **Curve** menu (see Curve Menu on page 126) or click the corresponding toolbar button:

- Drawing Order > Move to Front
- Drawing Order > Move to Back
- Drawing Order > Move Forward
- Drawing Order > Move Backward

Creating Curves

You can create curves in different ways.

Creating Curves Automatically When Loading Files

When a PLT, TDR, or TIF file is loaded, the Inspect tool does not create curves immediately in the plot area. This is because a curve might be formed from any pair of datasets belonging to different groups and only a few of these are likely to interest users. Curves must be created explicitly, when required, by mapping pairs of datasets to x-axes and y-axes.

When a PLX or an XGRAPH file is loaded, Inspect creates curves automatically in the plot area, from the pairs of datasets defined in the loaded file, with the y-dataset being mapped to the left y-axis. The y-dataset can be remapped later to the right y-axis.


Creating Curves Using Formulas

You can create curves by applying formulas to existing curves (see Using Formulas on page 47).

To create a curve using a formula:

1. In the Curves group box, click New.

The Create Curve dialog box opens.



- 2. In the Curves pane, click a curve to highlight it.
- 3. In the **Name** field, enter the name of the new curve.

The Inspect tool provides a default.

- 4. In the **Formula** field, enter the formula to be used to create the curve.
- 5. Map the curve to either the left y-axis or the right y-axis.
- 6. Click Apply.
- 7. Click OK.

Example: Create a Curve That Is the Difference Between Two Curves

To create a curve that is the difference between two curves:

1. In the Curves group box, click **New**.

The Create Curve dialog box opens.

2. In the Curves pane, click a curve to highlight it.

The curve name appears in the **Formula** field enclosed by angle brackets.

- 3. Type a hyphen after the closing angle bracket in the **Formula** field.
- 4. Double-click a different curve in the Curves pane.

The name of the second curve appears in the **Formula** field.

- 5. Select the axis to which the new curve is mapped.
- 6. Click Apply.
- 7. Click OK.

The new curve is displayed in the plot area.


Creating Curves Using Macros and Library Formulas

You can create and handle new curves using macros and library formulas included in the Inspect tool. You can create macros using the Macro Editor, which allows you to select existing macro functions, different operations, and formulas from the libraries (see Figure 3 on page 33). For more information about using macros, see Using Macros on page 51.

Macros are stored in the file <code>inspect_macro.par</code> in the <code>stdB</code> directory. This file is created automatically the first time the Inspect tool is run. Initially, it stores predefined macros. You can then add or modify macros using the Macro Editor.

To open the Macro Editor, choose **Edit** > **Define Macros**.

Figure 3 Macro Editor



Deleting Curves

You can delete either selected curves or all curves listed in the Curves group box.

To delete selected curves:

- 1. Select the curves in the Curves group box.
- 2. Click Delete.
- 3. Confirm the deletion.

To delete all curves:

- 1. Click Delete All.
- 2. Confirm the deletion.

Configuring the View

This chapter describes how to modify the way in which Inspect displays loaded datasets.

Modifying Axes

This section describes different ways you can modify the axes.

Scaling an Axis

You can scale the x-axis, the left y-axis, and the right y-axis. The scale of each axis can be changed independently.

To change the scale of an axis:

- 1. Click the relevant toolbar button:
 - The button switches on logarithmic scale on the x-axis.
 - The button switches on logarithmic scale on the left y-axis.
 - The Y2 button switches on logarithmic scale on the right y-axis.
- 2. Click the corresponding toolbar button again to switch off logarithmic scale for an axis.

When logarithmic scale is switched off, the axis reverts to linear scale.

Handling Data When Axes Set to Logarithmic Scale

If an axis is set to logarithmic scale, Inspect handles data in the following way:

- Negative values are set to positive.
- Zero values are set to 1e-20.

When an axis switches to linear scale, data is restored to its original values.

Limits of Axes Set to Logarithmic Scale

When an axis is set to linear scale, you can set the minimum and maximum values of the axis.

When an axis is set to logarithmic scale, Inspect might be unable to set an axis to the given values. In this case, Inspect sets the minimum and maximum values of the axis to the nearest power of 10 values.

Changing Attributes of Axes

To change the attributes of axes:

- Choose Edit > Axes, or press Ctrl+A, or double-click any axis in the plot area.
 The Axes dialog box opens (see Figure 4 on page 36).
- 2. Click the required tabs to change attributes.
- 3. Click **OK** or **Apply** to accept the changes.

For example, to change the x-axis from linear scale to logarithmic scale:

- 1. Click the **X-Axis** tab.
- 2. Click the **Scale** tab.
- 3. Select **Log**.
- 4. Click **OK** or **Apply** to accept the changes.

Figure 4 Axes dialog box



Configuring the Plot Area

This section describes different ways you can modify the plot area.

Changing Attributes of Plot Area

You can change the appearance of the plot area and modify attributes such as the name of the plot area, the legend text that references the displayed curves, the plot frame, and the grid.


To change the attributes of the plot area:

- 1. Choose **Edit** > **Plot Area**, or press Ctrl+G.
 - The Plot Area dialog box opens (see Figure 5 on page 38).
- 2. Click the required tabs to change attributes.
- 3. Click **OK** or **Apply** to accept the changes.

For example, to change the position of the legend text in the plot area:

- 1. Click the **Legend** tab.
- 2. In the **Position** box, select the new position.
- 3. Click **OK** or **Apply** to accept the changes.

Figure 5 Plot Area dialog box showing all tabs




Adding Labels

You can add labels to the plot area. These labels provide useful information about the mapped curves. Labels can be edited and removed from the plot area.

To add a label:

1. Choose Edit > Labels > Add.

The Labels dialog box opens.



- 2. In the **Text** field, type the label text.
- 3. Select a color and font for the label.
- 4. Click **OK** or **Apply** to insert the new label in the plot area.

To move a label:

- 1. Select a label in the plot area using the middle mouse button.
- 2. Move the label inside the plot area as required and release the middle mouse button.

To delete a label:

1. Choose **Edit** > **Labels** > **Remove**.

The pointer changes to the delete mode.

2. In the plot area, click the label to be removed.

When the label is removed, the pointer reverts to the standard mode.


Displaying the Dataset of a Curve

Each curve displayed in the plot area has an associated dataset.

To view the points (data) included in the dataset of a specific curve:

- 1. Select a curve from the Curves group box.
- 2. Choose **Curve** > **Curve Data**, or press Ctrl+D.

The Curve Data dialog box opens, showing a table of the x-coordinates and y-coordinates for each point in the datasets represented by the selected curve.



- 3. Highlight a data point in the table.
- 4. Click **Delete** to remove it from the displayed curve.

Cleaning Up the Plot Area

You can clean up the plot area, in which case, all existing curves are deleted, the legend is removed, and the plot area is reinitialized.

To clean up the plot area:

► Choose Edit > Clean Plot Area, or click the toolbar button.

Sampling Points in the Plot Area

To sample points in the plot area:

1. Choose Curve > Inspector.

The Inspector dialog box opens (see Figure 6).

2. In the plot area, select the first point by clicking a specific location (usually on a curve).

Chapter 4: Configuring the View

Configuring the Plot Area


3. Drag the pointer to a second location (usually on another curve) to mark the second point.

Note:

The Inspector dialog box works only for the x-axis and left y-axis.

Positions are represented by circles that are connected by a line. The Inspector dialog box shows different values calculated from the two selected positions.

Figure 6 Example of using Inspector dialog box to sample points in the plot area




Curve Interpolation and Operations

This chapter discusses curve interpolation and operations.

Curve Operations

A curve is defined as a set of two or more (x, y) points. Each curve has its own set of points called datasets. Inspect can display the resulting (continuous) curve by plotting all data points and completing the curve with a graphical linear interpolation method. Figure 7 shows three different curves, each defined by different datasets.

Figure 7 Different curves displayed as lines



The Inspect tool offers different operations with curves. This requires an efficient way to handle curves and to create datasets for curves resulting from operations with other curves.

Some operations result in a new curve or a scalar value. These operations include the sum of two or more curves, integration, differentiation, and the maximum value on the y-axis or the x-axis.

Limitation of the X-Axis Values of the Dataset

Note:

Only curve segments that have x-axis values monotonically increasing or decreasing can be used in a formula.


Curves used in a formula are checked for monotonically increasing or decreasing values inside the range defined by the current zoom level in the plot area. This means formulas apply only to the currently displayed points. By defining the optimal zoom level for the selected curves, it is possible to cut off curve segments that do not have monotonically increasing or decreasing x-values.

This general rule has *one exception*. An Inspect formula can involve only one curve with nonmonotonous x-axis values. In this case, Inspect splits this curve into monotonous segments of x-axis values, applies the formula to those segments, and builds the resulting curve automatically. For example, a scaling formula can be applied to a curve that is nonmonotonous on the x-axis. However, calculating the sum of two curves, where both curves are nonmonotonous on the x-axis, is not possible.

More Than One Curve in a Formula

If a formula includes more than one curve, Inspect interpolates all curves to a common x-axis dataset. This is demonstrated in the following example.

The data points of curves A, B, and C are marked with circles, squares, and diamonds, respectively. The points in the resulting curve are marked with plus signs. The formula used is $\langle A \rangle + \langle B \rangle + \langle C \rangle$. The resulting curve includes points of all three input curves:



Chapter 5: Curve Interpolation and Operations

Curve Operations

The Inspect tool creates an array of all x-coordinates of all curves that are used in a formula and interpolates those curves to obtain y-values for each of the new x-values added to each curve.

Handling Datasets in Formula Processing

The following examples illustrate the dataset handling method that the Inspect tool uses to work with more than one curve in a formula (see Figure 8).

Curve 1: $y = x^2$, linear scale on x

Χ	1	10	20	30	40	50	60	70
Υ	1	100	400	900	1600	2500	3600	4900

Curve 2: $y = x^2$, logarithmic scale on x

Х	1	2	4	8	16	32	64
Υ	2	4	16	64	256	1024	4096

The combined set of x-coordinates needed to produce the resulting curve (the sum of both curves) is:

Resulting curve: $y = 2x^2$


Х	1	2	4	8	10	16	20	30	32	40	50	60	64

The last point of Curve 1 (x = 70) is not included because no data is available beyond x = 64 in Curve 2.

For y-values, interpolation is performed on Curve 1 and Curve 2 to fill the gaps and sum both curves. Therefore, y-values for this resulting curve are:

Y 2 8 32 128 200 512 800 1800 2048 3200 5000 7200 81
--

Figure 8 Resulting plot showing curves



Dataset Created for Result Curves

For each curve created by a formula that involves more than one curve, Inspect generates a new dataset. During the Inspect session, this dataset is stored in a special project called <code>AuxProject</code>. When the current project is saved in a file, the <code>AuxProject</code> is also saved; otherwise, this project with all its datasets is lost when Inspect is closed.

The datasets in AuxProject are handled in the same way as datasets from loaded data files.

Curve Handling on Interpolation

The Inspect tool handles both linear-scaled and logarithmic-scaled curves. Each curve is treated independently. Therefore, when working with two curves, one with linear scale and the other with logarithmic scale, the Inspect tool:

- Creates new points for the first curve for all x-values of the second curve using a linear interpolation method
- Creates new points for the second curve for all x-values of the first curve using a logarithmic interpolation method
- Operates with the common set of points

Determining the Scale (Linear or Logarithmic) of Curves

Deciding how to handle a curve involves analyzing its slope, which is defined as:

$$\frac{dy}{dx} = \frac{y_{i1} - y_i}{x_{i1} - x_i} \tag{1}$$

First, the curve is treated as linear, and the minimum (MinSlope) and maximum (MaxSlope) slopes are calculated.

Second, a quotient is created:

$$\frac{\text{MaxSlope}}{\text{MinSlope}} \tag{2}$$

The same calculation is performed by treating:

- · The x-axis as logarithmically scaled
- · The y-axis as logarithmically scaled
- Both axes as logarithmically scaled

Of these four values, the one closest to 1.0 indicates the best way of handling the curve.

Formulas and Macros

This chapter describes how to use formulas and macros in Inspect.

Using Formulas

The Inspect tool recognizes two variable types: curve and scalar. Mixed curve—curve and curve—scalar operations are evaluated as follows:

- 1. The range of the result of a curve—curve operation is the intersection of the x-range of the operands.
- 2. When one operand is a curve and the other is a scalar, the respective operation is performed as a scalar operation on each element of the curve operand.

The binary operators that can be used are +, -, *, /, and $^{\land}$ (power operator).

Formula Library

The formula library allows you to perform some basic calculations on one or more curves. The result can be a new curve or a scalar value (see Table 3 on page 48). The following examples show how the formula library is used:

```
sin (<curve_1> + 10) The result is a new curve. Inspect adds 10 to the y-value of each curve
point from curve_1 and computes the sinus.
maxslope(<curve_1>) The result is a scalar value, which is the maximum slope of curve_1.
```

Table 3 lists functions that create a new curve by applying a mathematical transformation to each element of the curve. These functions can also be applied to scalar values. Table 4 lists special functions that either require more than one parameter or do not return a curve. Table 5 lists functions that manage or compute fast Fourier transformation (FFT) and related operations.

Using Formulas

Note:

A curve can be defined by one point only, in which case, the curve is treated as a scalar input. Some curves require as input a *curve only*, that is, a curve that has at least two points.

Table 3 Standard mathematical functions

Function	Input type	Output type	Description
acos	curve	curve	Returns the arc cosine. The returned angle [radian] is given in the range 0 (zero) to π .
acosh	curve	curve	Returns the inverse hyperbolic cosine. Curve values must be greater than or equal to 1.
asin	curve	curve	Returns the arc sine. The returned angle [radian] is given in the range from $-\pi/2$ to $\pi/2$.
asinh	curve	curve	Returns the inverse hyperbolic sine.
atan	curve	curve	Returns the arc tangent. The returned angle [radian] is given in the range from $-\pi/2$ to $\pi/2$.
atanh	curve	curve	Returns the inverse hyperbolic tangent. Curve values must be between –1 and 1 (excluding –1 and 1).
cbrt	curve	curve	Returns the cube root.
ceil	curve	curve	Rounds up each element to the smallest integer not less than itself.
cos	curve	curve	Returns the cosine.
cosh	curve	curve	Returns the hyperbolic cosine.
diff	curve only	curve	Returns the first derivative of the curve.
erf	curve	curve	Returns an error function of the curve values.
erfc	curve	curve	Returns the complementary error function of the curve values.
exp	curve	curve	Returns the number raised to the power of each curve value.
fabs	curve	curve	Returns the absolute value.

Table 3 Standard mathematical functions (Continued)

Function	Input type	Output type	Description
floor	curve	curve	Rounds down each element to the largest integer not greater than itself.
gamma	curve	curve	Returns the Gamma function.
integr	curve only	curve	Returns the integral of the curve.
j0	curve	curve	Returns the Bessel function of the first kind of order 0.
j1	curve	curve	Returns the Bessel function of the first kind of order 1.
lgamma	curve	curve	Returns the natural logarithm of the absolute value of the Gamma function.
log	curve	curve	Returns the natural logarithm of the given curve.
log10	curve	curve	Returns the base 10 logarithm of the given curve.
sin	curve	curve	Returns the sine.
sinh	curve	curve	Returns the hyperbolic sine.
sqrt	curve	curve	Returns the square root.
tan	curve	curve	Returns the tangent.
tanh	curve	curve	Returns the hyperbolic tangent.
у0	curve	curve	Returns the Bessel function of the second kind of order 0.
y1	curve	curve	Returns the Bessel function of the second kind of order 1.

Table 4 Special functions

Function	Input type	Output type	Description
pow	curve, scalar	curve	Returns the curve raised to the power of the given scalar.
tangent	curve, scalar	curve	Returns a curve that is tangent to the given curve, at the given x-value.

Table 4 Special functions (Continued)

Function	Input type	Output type	Description
vecmax	curve	scalar	Maximum y-value.
vecmin	curve	scalar	Minimum y-value.
vecvalx	curve, scalar	scalar	The x-value at a given y.
vecvaly	curve, scalar	scalar	The y-value at a given x.
veczero	curve	scalar	The x-value at $y = 0$.

Table 5 Fast Fourier transformation (FFT) and related functions

Function	Input type	Output type	Description
cfftim	curve_real, curve_imaginary	curve	Returns the imaginary part of the FFT of the given complex curve.
cfftre	curve_real, curve_imaginary	curve	Returns the real part of the FFT of the given complex curve.
cifftim	curve_real, curve_imaginary	curve	Returns the imaginary part of the inverse FFT of the given complex curve.
cifftre	curve_real, curve_imaginary	curve	Returns the real part of the inverse FFT of the given complex curve.
fftabs	curve_real, curve_imaginary	curve	Returns a vector holding the absolute value of the given complex curve.
fftim	curve	curve	Returns the imaginary part of the FFT of the given curve.
fftre	curve	curve	Returns the real part of the FFT of the given curve.
ifftim	curve	curve	Returns the imaginary part of the inverse FFT of the given curve.
ifftre	curve	curve	Returns the real part of the inverse FFT of the given curve.

Using Macros

Macros can define complex formulas. Inspect expands a macro by using the actual arguments specified in the call to the macro (see Figure 3 on page 33).

In a macro definition, the argument type must be specified. Types can be curve or scalar. This information is needed to expand the macro into the correct formula.

The syntax for argument placeholder specification is $<_{C}$ n> for curves and $<_{S}$ n> for scalars, where n is an integer value used to distinguish between different arguments; n must start with 1.

In the Inspect macro parser, the macro prototype is not specified explicitly. It is determined automatically from the formula that defines the macro. The order of arguments is determined by their first appearance in the formula and not by numbers in the argument placeholders.

Example: ADD Macro

The macro ADD is defined as:

```
<c 1> + <c 2>
```

This macro adds two curves. The macro prototype looks like:

```
ADD(<CURVE>, <CURVE>)
```

The argument placeholder <CURVE> must be replaced by an actual curve name.

Example: DIFFMULT Macro

The macro DIFFMULT is defined as:

```
diff(<c 1>) + (<s 3> * <c 2>)
```

This macro takes the derivative of a curve $<_{\mathbb{C}}$ 1> and adds to it a curve $<_{\mathbb{C}}$ 2> multiplied by a scalar $<_{\mathbb{S}}$ 3>. A call to this macro has the form:

```
DIFFMULT(<CURVE>, S, <CURVE>)
```

The argument placeholder <CURVE> must be replaced by an actual curve name, and S must be replaced by an expression that generates a scalar value.

Using the Scripting Language

This chapter describes the operations available using the Inspect scripting language.

Overview of the Scripting Language

In addition to the user interface, you can control the Inspect tool using a scripting language (see Working With Scripts on page 22). The scripting language allows you to manipulate and display data without using the user interface, and it is very useful for running complex calculations on datasets and displaying results. For example:

- Repeated manual actions can be recorded and run later by simple script invocation.
- Several computations using the formula library can be performed in one run.
- Results can be written automatically to a file.

You can write a script manually or create a script by recording actions performed in the user interface (see Creating Scripts on page 22).

The Inspect tool uses the tool command language (Tcl) as its scripting language. For more information about Tcl, go to http://www.tcl.tk.

Some commands have been added to Tcl (in the form of Tcl procedures) to perform application-specific actions. For more specific needs, you can create your own commands.

Most of the additional commands in Inspect return a status string. A return status not equal to 1 indicates an error. If an error occurs, Inspect prints an error message to the standard error output and terminates the execution of the script.

Note:

Arguments in braces are *optional*. The first term in the braces is the name of the argument, and the second term is the default value of the argument. For example, a command that has been defined as command {arg def_value} can be called as command (which is equivalent to command def_value) and also as command other_value.

General-Purpose Commands

This section describes general-purpose commands.

ft_scalar

ft_scalar variableName variableValue

Action Produces the following output line: DOE: variableName variableValue

If the current Inspect command file belongs to a Sentaurus Workbench project, then this output line results in the creation of a new Sentaurus Workbench extracted variable with

the name variableName and the value variableValue

(see Sentaurus™ Workbench User Guide, Extracted Variables).

Input variableName, name of the Sentaurus Workbench variable to extract

variableValue, value of this Sentaurus Workbench variable

Returns None

Reading and Writing Files

This section describes commands for reading and writing files.

cv_write

cv_write type fileName curveList

Action Writes (exports) the data of the specified curves to a file in the specified format.

Input type, output format to use: plt, xgraph, or xmgr

fileName, file to write

curveList, list of curve names

Returns Status of the write operation

fi_writeBitmap

fi_writeBitmap fileName

Action Writes the plot area to a PNG file.

Input fileName, file to write

Returns Status of the write operation

fi_writeEps

fi_writeEps fileName {orientation portrait} {height ""} {width ""}

Action

Writes the plot area to an EPS file. This command is not generated automatically when script recording is switched on. If height or width is not specified, the actual plot size is taken into account. Some examples are:

fi_writeEps test.eps

fi_writeEps test.eps landscape

fi_writeEps test.eps landscape 200 100

Input fileName, file to write

orientation, image orientation: portrait (default) or landscape

height, height of the saved image in pixels width, width of the saved image in pixels

Returns Status of the write operation

fi_writePs

```
fi_writePs fileName {orientation portrait} {printSize US_LETTER} {height ""}
{width ""} {offsetHeight ""} {offsetWidth ""} {sizeUnit ""}
```

Action

Writes the plot area to a PostScript® file. This command is not generated automatically when script recording is switched on. When height or width is not specified, the actual plot size is taken into account. Some examples are:

```
fi_writePs test.ps
fi_writePs test.ps landscape
fi_writePs test.ps landscape DIN_A4
fi_writePs test.ps portrait US_LETTER 450 300 5 5 m
```

Input fileName, file to write

orientation, image orientation: portrait (default) or landscape printSize, page size: US_LETTER (default), DIN_A3, or DIN_A4 height, height of the saved image in size units (sizeUnit) width, width of the saved image in size units (sizeUnit) offsetHeight, vertical page offset in size units (sizeUnit) offsetWidth, horizontal page offset in size units (sizeUnit) sizeUnit, unit for height, width, offsetHeight, and offsetWidth: i: inch (default), m: millimeter, c: centimeter

Returns Status of the write operation

graph_load

graph_load fileName

Action Loads the specified save file into Inspect. All currently loaded projects are deleted.

Input fileName, name of file to load

Returns Status of the load operation

graph_write

graph_write fileName

Action Saves the current state to a specified file.

Input fileName, name of file

Returns Status of the write operation

param_load

param_load fileName

Action Loads a parameter file.

Input fileName, name of file to load

Returns Status of the load operation

param_write

param_write fileName

Action Saves a parameter file.

Input fileName, name of file

Returns Status of the write operation

proj_getDataSet

proj_getDataSet projectName dataSetId

Action If no dataset is found, the return value is an empty list. For example, the following

commands set the variable x_{data} to the values of the dataset time and the variable

y_data to the values of the dataset data_1 of node_A:

set x_data [proj_getDataSet "tutorial_ins" "time"]

set y_data [proj_getDataSet "tutorial_ins" "node_A data_1"]

Input projectName, name of project

dataSetId, name of a dataset including its group name if applicable

Returns List of all the values of the dataset

proj_getList

proj_getList

Action Returns a list of all projects. If no projects are found, an empty list is returned.

Input None

Returns List of all loaded projects

proj_getNodeList

proj_getNodeList projectName

Action Returns a list of group names of the given project. If no groups have been found, an

empty list is returned.

Input projectName, name of project

Returns List of group names

proj_load

proj_load fileName

Action Loads a data file and creates a new project. The base name of the file is used as the

project name (see Data Formats on page 16).

Input fileName, name of file

Returns Status of the load operation

proj_unload

proj_unload projectName

Action Deletes a project and all the project-related curves.

Input projectName, name of project

Returns Status of the delete operation

proj_write

proj_write projectName fileName

Action Writes a project to a specified file.

Input projectName, name of project

fileName, name of file

Returns Status of the write operation

Creating, Displaying, and Deleting Curves

A dataset used for curve creation is identified by its data path, which consists of the project name, the group name when the dataset belongs to a group, and the dataset name.

cv_create

cv_create curveName xDataPath yDataPath {axis y}

Action

Creates a curve with the given name using the specified datasets without displaying it. The datasets must be already loaded; otherwise, an error is returned. For example, the following command creates a curve mycurve using the dataset time on the x-axis and the dataset OuterVoltage of the group Gate on the y-axis, with both datasets belonging to the project nmos_n7_des:

cv_create mycurve "nmos_n7_des time" "nmos_n7_des Gate OuterVoltage"

Input

curveName, unique name for the new curve

xDataPath, x-dataset data path yDataPath, y-dataset data path axis, axis to use; the default is y

Returns

Status of the create operation

cv_createDS

cv_createDS curveName xDataPath yDataPath {axis y}

Same as cv_create except that the curve is displayed. See cv_create.

cv_createFromScript

cv_createFromScript curveName xdata ydata {axis y}

Action

Creates a curve using the given name and data. If the number of values for x and y are not the same, the number of curve points is according to that of the smaller dataset. Curves created with this command are stored in AuxProject.

For example, the following command creates the curve <code>mycurve</code> defined by the specified data:

Input

curveName, unique name for the new curve xdata, list of data to use for the x-dataset ydata, list of data to use for the y-dataset axis, axis to use: y (default) or y2

Returns

Status of the create operation

cv_createWithFormula

cv_createWithFormula curveName formula xmin xmax ymin ymax

Action

Computes a new curve using the formula applied to the data of the argument curves within the given range. Setting the range to any nonnumeric value (for example, A) instructs the Inspect tool to set no limit in the corresponding direction.

For example, the following command creates the curve £3 using the entire data range of curves £1 and £2:

cv_createWithFormula f3 "<f1>+<f2>+10" A A A A

Input

curveName, unique name for the new curve

formula, formula or macro

xmin, xmax, ymin, ymax, range for which the formula is applied

Returns

Status of the create operation

Creating, Displaying, and Deleting Curves

cv_delete

cv_delete curveName

Action Deletes a curve.

Input curveName, name of curve

Returns Status of the delete operation

cv_display

cv_display curveName {axis y}

Action Displays a curve using the specified y-axis.

Input curveName, name of curve to display

axis, axis to use; the default is y

Returns None

cv_logScale, cv_log10Scale

```
cv_logScale curveName newCurveName {axis x}
cv_log10Scale curveName newCurveName {axis x}
```

Action Creates a new curve where all values on a given axis are transformed to a log (log10)

scale.

Input curveName, curve to transform

newCurveName, name of the new curve

axis, axis on which the curve is scaled; the default is x

Returns Status of the create operation

cv_split

cv_split curveName axis newCurveList

Action

Splits the input curve into several curves at the points where the x-values are nonmonotonic, that is, x[i + 1] < x[i]. The number of names for the new curves must match the actual number of created curves; otherwise, an error is returned.

This command is similar to choosing **Curve > Transform > Suppress Backtrace** (see Table 10 on page 126). The difference is that this command creates a set of new curves. With **Suppress Backtrace** selected, the backtrace lines are

suppressed only on the plot.

Input curveName, name of curve to split

axis, y-axis to map the new curves onto
newCurveList, list of names for new curves

Returns

Status of the operation

cv_split_disc

cv_split_disc curveName axis newCurveList

Action

Splits the input curve into several curves at the points where there are discontinuities, that is, x[i + 1] = x[i] and y[i + 1] != y[i].

The number of names for the new curves must match the actual number of created curves; otherwise, an error is returned.

Input

curveName, name of curve to split
axis, y-axis to map the new curves onto
newCurveList, list of names for new curves

Returns

Status of the operation

Changing Attributes

These commands change the attributes of the title, axes, curves, and legend.

cv_lineColor

cv_lineColor curveName color

Action Sets the color of the curve line.

Input curveName, name of curve

color, color of the curve line

Returns None

cv_lineStyle

cv_lineStyle curveName style

Action Sets the drawing style of the curve line.

Input curveName, name of curve

style, drawing style of the curve line: dashed, dotted, "long dashed", "long

dotted", **Or** solid

Returns None

cv_renameCurve

cv_renameCurve curveName newName

Action Renames a curve.

Input curveName, name of curve

newName, new name of curve

cv_set_interpol

cv_set_interpol curveId axis type

Action Sets the interpolation method to be applied to each particular dataset of a curve.

Input curveId, curve identification

axis, axis on which the interpolation is set: x or y type, interpolation method to set: AUTO, LIN, or LOG

Returns None

cv_setCurveAttr

 $\verb|cv_setCurveAttr| curveName| legend| color| style| width| shape| size| outColor| outWidth| fillColor|$

Action Sets curve-drawing attributes.

Input curveName, name of curve

legend, curve legend

color, color of the curve line

style, drawing style of the curve line: dashed, dotted, "long dashed", "long

dotted", **Or** solid

width, width of the curve line

shape, marker shape: none, circle, cross, diamond, plus, scross, splus, square, or

triangle

size, marker size

outColor, color of the marker outline
outWidth, width of the marker outline
fillColor, fill color of the marker

gb_setpreferences

gb_setpreferences type val

Action Sets new values for the preference options. The following options can be modified:

 ${\tt precision}. \ \textbf{Defines the precision used to display coordinate values in the status line};$

any integer can be set.

old_interpolation: Specifies whether the old interpolation is used to compute curves:

1: Activates old interpolation.

0: Deactivates old interpolation.

Input type, preference option to be modified

val, new value for option

Returns None

gr_createLabel

gr_createLabel label coordX coordY fontStr color

Action Creates a label in the plot area.

Input label, label text

coordX, x-coordinate
coordY, y-coordinate
fontStr, label font
color, label color

Returns Label ID

gr_deleteLabel

gr_deleteLabel labelId

Action Deletes a label from the plot area.

Input labelId, label ID

gr_formatAxis

gr_formatAxis axis format

Action Changes the format of the displayed axis.

Input axis, axis to be formatted

format, options are default, engineering, fixed, or scientific

Returns None

gr_mappedAxis

gr_mappedAxis axis yesno

Action Changes the visibility of an axis.

Input axis, specifies a y-axis: y or y2

yesno, specifies the axis visibility: True or False

Returns None

gr_precision

gr_precision axis prec

Action Changes the precision of a given axis.

Input axis, axis to be formatted

prec, numeric precision to be set for the axis

gr_setAxisAttr

gr_setAxisAttr axis title tfont min max color width font angle div scale {tcolor}

Action Sets the axis attributes.

Input axis, specifies an axis: x, y, or y2

title, axis title

tfont, font size of the axis title

min, max, minimum and maximum values of the axis

color, color of the axis
width, width of the axis line
font, font size of the tick label

angle, angle at which the tick labels are drawn

div, number of secondary ticks between the main ticks

scale, specifies linear (lin) or logarithmic (log) display of the axis

tcolor, color of the axis title

Returns None

gr_setGeneralAttr

gr_setGeneralAttr {showFrame true} {axesTight true} {backColor white}
{selectColor cyan}

Action Sets the general attributes of the plot.

Input showFrame, Boolean indicator of plot frame appearance; default is true

axesTight, Boolean indicator of the tightness of axes; default is true

backColor, plot background color; default is white selectColor, color of the selected curve; default is cyan

gr_setGridAttr

gr_setGridAttr {showGrid false} {gridAlign left} {minorTicks false}
{gridStyle "short dashed"} {gridColor black} {gridWidth 1}

Action Sets the grid attributes of the plot.

Input showGrid, Boolean indicator of grid appearance; default is false

gridAlign, grid alignment: left (default) or right

minorTicks, Boolean indicator of the appearance of minor ticks; default is false

gridStyle, attribute of the grid style: dashed, "dot-dashed", dotted,
"long dashed", "long dotted", "short dashed" (default), or solid

gridColor, color of the grid lines; default is black gridWidth, thickness of the grid lines; default is 1

Returns None

gr_setLegendAttr

gr_setLegendAttr $\{showFlag true\}$ $\{fontName helvetica\}$ $\{fontSize 10\}$ $\{fontStyle \{\}\}$ $\{backColor white\}$ $\{foreColor black\}$ $\{frameColor black\}$ $\{frameWidth 1\}$ $\{framePos right\}$ $\{frameAnchor n\}$

Action Sets the attributes of the legend.

Input showFlag, Boolean indicator of legend appearance

fontSize, legend font size; default is 10

fontStyle, legend font style: bold, italic, overstrike, or underline; default is an
empty list {}

backColor, legend background color; default is white foreColor, legend foreground color; default is black frameColor, legend frame color; default is black

frameWidth, legend frame width; default is 1

framePos, legend frame position: left, right (default), top, bottom, free, or plot

frameAnchor, legend frame anchor: n (default), e, s, w, ne, se, sw, or nw

gr_setLegendPos

 $gr_setLegendPos x y$

Action Changes the position of the displayed legend in the plot area.

Input x, new x-coordinate for the legend in the plot area

y, new y-coordinate for the legend in the plot area

Returns None

gr_setTitleAttr

gr_setTitleAttr title {fontSize 14} {just center}

Action Sets the title attributes.

Input title, title text

fontSize, size of title font; default is 14

just, title justification: center (default), left, or right

Returns None

Accessing Curve Data

These commands relate to accessing curve data.

cv_getVals

cv_getVals curveName

Action Returns a list of the x- and y-data. The x-data and y-data can be accessed using:

set xy [cv_getVals "f1"]
set x [lindex \$xy 0]
set y [lindex \$xy 1]

After this, the variables x and y hold the x- and y-datasets, respectively.

Input curveName, name of curve

Chapter 7: Using the Scripting Language

Accessing Curve Data

cv_getVals curveName

Returns List of the x- and y-data

cv_getValsX

cv_getValsX curveName

Action Returns a list that holds the x-dataset.

Input curveName, name of curve

Returns List of the x-data

cv_getValsY

cv_getValsY curveName

Action Returns a list that holds the y-dataset.

Input curveName, name of curve

Returns List of the y-data

cv_getXaxis

cv_getXaxis curveName

Action Returns the project name and the dataset ID using:

set answer [cv_getXaxis "myCurve"]
set projectName [lindex \$answer 0]
set dataSetId [lindex \$answer 1]

Input curveName, name of curve

Returns List with the project name and the dataset ID of the x-dataset

cv_getYaxis

cv_getYaxis curveName

Action Returns the project name and the dataset ID as for cv_getXaxis.

See cv getXaxis.

Input curveName, name of curve

Returns List with the project name and the dataset ID of the y-dataset

cv_printVals

cv_printVals curveName

Action Writes the x- and y-data of a curve to standard output.

Input curveName, name of curve

Returns List of the printed values

Transforming Curve Data

These commands change the way in which curve data is displayed without changing the curve datasets.

cv_abs

cv_abs curveName axis

Action Replaces negative values of the x- or y-dataset by their absolute values, depending on

the axis argument. This command has the same effect as choosing Curve >

Transform > Abs X or **Abs Y** (see Table 10 on page 126).

Input curveName, name of curve

axis, axis specifier

Returns Status of the operation

cv_delPts

cv_delPts curveName indexList

Action Deletes the points in the *indexList* from the set of points being displayed.

Input curveName, name of curve

indexList, list of indices of curve points

Returns Status of the delete operation

cv_inv

cv_inv curveName axis

Action Reflects a curve about the specified axis. This command is equivalent to choosing

Curve > Transform > Reflect X or Reflect Y (see Table 10 on page 126).

Input curveName, name of curve

axis, axis specifier

Returns Status of the operation

cv reset

cv_reset curveName

Action Restores the original appearance of the curve after a transformation. This command

is equivalent to choosing Curve > Restore Data (see Table 10 on page 126).

Input curveName, name of curve

Returns Status of the operation

Extracting Parameters

These commands extract standard parameters of semiconductor devices. Some arguments of the commands have default values that are used when an argument is not specified.

f_Gamma

f_Gamma VT1 VT2 VB1 VB2 const

Action Computes the body-effect parameter at two different source–substrate voltages. The

formula used to compute the body-effect parameter is:

Gamma = $(VT2 - VT1)/((const + VB2)^{1/2} - (const + VB1)^{1/2})$

Input *VT1*, *VT2*, two threshold voltages

VB1, VB2, two different source—substrate voltages

const, $2\phi_F$ where ϕ_F is the Fermi-level potential; default value is 0.8 V

Returns $[V^{1/2}]$ as a scalar or f_error in the case of an error

f_gm

f_gm curveName xmin xmax ymin ymax

Action Computes the maximum of transconductance for a given I_d – V_g curve.

Input curveName, curve used to calculate gm

xmin, xmax, ymin, ymax, range for computing the result; the default values correspond

to the full curve range

Returns Value of gm [A/V] of the curve or f_{error} in the case of an error

f_hideInternalCurves

f_hideInternalCurves

Action Hides the internally used curves created by the commands of this section.

See f_showInternalCurves on page 75.

Input None

Returns None

f_IDSS

f_IDSS curveName xmin xmax ymin ymax

Action Computes the saturation current.

Input curveName, I_d-V_d curve at the fixed gate-source voltage

xmin, xmax, ymin, ymax, range for computing the result; the default values

correspond to the full curve range

Returns Saturation current value or f_error in the case of an error

f KP

f_KP gm VDS

Action Computes the transconductance parameter.

Input gm, transconductance value

VDS, drain source voltage; default is 0.1

Returns KP [A/V 2] value or f_error in the case of an error

f Ron

f_Ron curveName xmin xmax ymin ymax

Action Computes the on-state resistance in the linear region.

Input curveName, I_d-V_d curve at the fixed gate-source voltage

xmin, xmax, ymin, ymax, range for computing the result; the default values correspond

to the full curve range

Returns Value of R_{on} [k Ω] or f_error in the case of an error

f_Rout

f_Rout curveName xmin xmax ymin ymax

Action Computes the output resistance in the saturation region.

Input curveName, I_d-V_d curve at the fixed gate-source voltage

xmin, xmax, ymin, ymax, range for computing the result; the default values correspond

to the full curve range

Returns Value of R_{out} [k Ω] or f_error in the case of an error

f_showInternalCurves

f_showInternalCurves axis

Action Displays the internally used curves created by the commands of this section.

See f_hideInternalCurves on page 74.

Input axis, axis to use; default is left

Returns None

f_TetaG

f_TetaG VT gm idvgs vgsvgs xmin xmax ymin ymax

Action Computes the mobility modulation TetaG using the formula:TetaG = gm(VGSlow)/

ID(VGShigh) - 1/(VGShigh - VT)

Input VT, threshold voltage value

gm, transconductance value

 $\begin{array}{l} \textit{idvgs}, \ \textit{I}_d \!\!-\!\! \textit{V}_g \ \textit{curve} \\ \textit{vgsvgs}, \ \textit{V}_g \!\!-\!\! \textit{V}_g \ \textit{curve} \end{array}$

xmin, xmax, ymin, ymax, range for computing the result; the default values correspond

to the full curve range

Returns Value of TetaG $[V^{-1}]$ or f_error in the case of an error

f VT

f_VT curveName xmin xmax ymin ymax

Action Computes the threshold voltage [V] of the g

Computes the threshold voltage [V] of the given curve. The formula used to compute the threshold voltage is:

VT = intercept(maxslope(curve))

Example 1: This statement computes V_{th} using default values for the range:

set vt1 [f_VT idvgs]

Example 2: This statement computes V_{th} using xmin=0.1 xmax=0.3 and default values for the y-range:

set vt2 [f_VT idvgs 0.1 0.3]

Input curveName, name of curve

xmin, xmax, ymin, ymax, range for computing the result; the default values correspond

to the full curve range

Returns Threshold voltage value or f_error in the case of an error

f_VT1

f_VT1 curveName xmin xmax ymin ymax

Action Computes the threshold voltage [V] of the given curve.

 V_{th} is typically extracted at $I_d = 0.1 \mu A/\mu m$.

Input curveName, name of curve

xmin, xmax, ymin, ymax, range for computing the result; the default values correspond

to the full curve range

Returns Threshold voltage value or f_error in the case of an error

f VT2

f_VT2 curveName

Action Computes the threshold voltage [V] of the given curve. The method used to extract

V_{th} is the intersection of MaxSlope and MinSlope lines in the log of the given curve.

Input curveName, name of curve

Returns Threshold voltage as a scalar value or f_error in the case of an error

Computing

This section describes computing commands.

cv_compute

cv_compute formula xmin xmax ymin ymax

Action Computes a scalar value using the formula.

Input formula, string with the formula to evaluate

xmin, xmax, ymin, ymax, range for which the formula is applied

Returns Scalar computation result

cv_getZero

cv_getZero curveName xmin xmax ymin ymax

Action Computes the x-coordinate of the point where the curve intersects the x-axis. If the

curve does not cross the x-axis, an empty string is returned.

Input curveName, name of curve

xmin, xmax, ymin, ymax, range for which the command applies

Returns The x-value where the curve intersects the x-axis

macro_define

macro_define macroName macroDef

Action Defines a macro, which can be used later for computations.

Input macroName, name of the macro

macroDef, macro definition

Returns Status of the operation

Controlling Scripts

This section describes commands for controlling scripts.

script_break

script_break

Action Suspends the execution of a script and passes control to the user interface. The script

execution can be resumed by choosing Script > Continue Script (see Table 11 on

page 127).

Input None

Returns None

script_exit

script_exit

Action Stops the execution of a script and exits Inspect.

Input None

Returns None

script_sleep

script_sleep sec

Action Stops the execution of a script for a given number of seconds.

Input sec, time in seconds

Returns None

Examples of Using the Scripting Language

This section presents examples of how to use the scripting language.

Computing the Dose of Implanted Arsenic

If As_Implant is the name of an As profile previously created, compute the dose of implanted As by integrating the profile. Limit the integration to portions of the curve with a concentration larger than 1e14 but without other limitations in depth or maximum concentration value:

If \mathtt{IdVg} is the name of an $\mathtt{I_{ds}}$ – $\mathtt{V_{gs}}$ curve previously created, compute a transconductance curve using \mathtt{diff} . Limit the computation to the window in the $\mathtt{I_d}$ – $\mathtt{V_g}$ curve defined by $\mathtt{Vmin} = 1.0 \ V$, $\mathtt{Vmax} = 4.0 \ V$, \mathtt{Id} _min = 1e-10, and \mathtt{Id} _max = 5e-6:

```
set gm [cv_compute "vecmax(diff(<IdVg>))" 1.0 4.0 1e-10 5e-6]
```

Creating a Macro to Compute Vt

Create a macro to compute V_t from the maximum of the second derivative of an I_d – V_g curve. Use $<_C$ n> as placeholders for curves and $<_S$ n> for scalars, where n represents the argument used in the macro and must start at 1. In the example, $<_C$ 1> should be an I_d – V_g curve and $<_S$ 2> is a multiplication factor:

```
macro_define Vt2d "<s 2>*vecvalx(diff(diff(<c 1>)),
     0.999*vecmax(diff(diff(<c 1>))))"
```

If \mathtt{IdVg} is the name of an I_{ds} – V_{gs} curve previously created, use the macro created to compute V_t in mV:

```
set Vt2 [cv_compute "Vt2d(<IdVg>,1e3)" A A A A]
```

Working With Script Libraries

This chapter describes how to work with script libraries in the Inspect tool.

The Inspect scripting language is complemented by libraries that provide additional functionality for specific operations such as curve comparison.

Loading Libraries

You use the load library command to load libraries:

```
load_library libraryName
```

where libraryName is a library identifier.

This command makes available all the functionality provided by the specified library.

All commands of a particular library have a common prefix, for example, iccap for commands provided by the IC-CAP model parameter extraction library (see IC-CAP Model Parameter Extraction Library on page 118).

Adding a Site Library

The \$STROOT_LIB/inspectlib directory stores all libraries as well as the lib_index file, which provides an index of all available libraries.

To add a library, the administrator (a person with write permissions to the TCAD distribution directory \$STROOT) copies the library to the \$STROOT_LIB/inspectlib directory and enters text in the index that describes the new library. The following fields must be provided:

```
<library_name> <library_prefix> <library_filename>
```

Extraction Library

where:

- library_name> is the name specified to call this library.
- library_prefix> is the prefix used for all commands.
- library filename> is the name of the file where all commands are implemented.

Extraction Library

The commands provided by this library extract parameters from I–V curves. You can load the library with the command:

```
load_library EXTRACT
```

The library is located at \$STROOT/\$STRELEASE/lib/inspectlib/EXTRACT.tcl. If you need to customize the library, you can create a local copy of the library and edit the scripts. In this case, the local version is loaded by sourcing the script:

```
source EXTRACT.tcl
```

cv linTransCurve

This command applies a linear transformation to the x- and y-values of a curve. It is called using:

```
cv_linTransCurve <Curve> <Xm> <Xb> <Ym> <Yb> <Axis>
```

where:

- <Curve> is the name of the curve.
- The x- and y-values of the curve are replaced by the transformed values given by $X' = X^* x_m + x_b$ and $Y' = Y^* y_m + y_b$, respectively.
- <Axis> can be either y or y2, and determines on which y-axis the transformed curve is displayed.

Example

Shift an I_d – V_{qs} curve by 0.55 V:

```
cv linTransCurve IdVgs 1 0.55 1.0 0.0 y
```

cv_scaleCurve

This command scales the x- and y-values of a curve. It is called using:

```
cv_scaleCurve <Curve> <XFactor> <YFactor> <Axis>
```

where:

- <Curve> is the name of the curve.
- The x- and y-values of the curve are multiplied by <xFactor> and <YFactor>, respectively.
- <Axis> can be either y or y2, and determines on which y-axis the scaled curve is displayed.

Example

Scale an I_d – V_{qs} curve from A/ μ m to mA/mm:

```
cv_scaleCurve IdVgs 1 1e6 y
```

ExtractBVi

Breakdown curves sometimes exhibit a pronounced snapback, in which case, another relevant definition is the bias voltage at which the current reaches a certain level. This type of extraction is performed with the ExtractBVi command. It is called using:

```
ExtractBVi <Name> <Curve> <Ilevel>
```

where:

- <Name> is the name of the extracted parameter.
- <Curve> is the name of the curve.
- <Ilevel> refers to the mentioned current level.

Example

```
ExtractBVi BVcboi VcIc 1e-12
```

results in output such as:

```
DOE: BVcboi 9.09e+00
BVi: 9.09e+00
```

ExtractBVv

The breakdown voltage can be defined as the maximum voltage that can be applied to a contact. The ExtractBVV command extracts this value. It is called using:

```
ExtractBVv <Name> <Curve> <Sign>
```

where:

- <Name> is the name of the extracted parameter.
- <Curve> is the name of the curve.
- <Sign> can take the values +1 (n-p-n) or -1 (p-n-p), and distinguishes different types of bipolar transistor. (In general, specify -1 if the breakdown occurs at a negative bias.)

Example

```
ExtractBVv BVcbov VcIc 1.0
```

results in output such as:

```
DOE: BVcbov 9.09e+00
BVv: 9.09e+00 V
```

ExtractEarlyV

This command extracts the Early voltage from an I_c–V_{ce} curve. It is called using:

```
ExtractEarlyV <Name> <Curve> <Vtarget>
```

where:

- <Name> is the name of the extracted parameter.
- <Vtarget> is the bias point at which the slope of the I_c-V_{ce} curve is determined for the computation of the Early voltage.

Example

```
ExtractEarlyV Va IcVc 1.25
```

results in output such as (where Ro is the output resistance and Va is the Early voltage):

```
DOE: Ro 3.283e+04
DOE: Va -1.836e+01
```

ExtractGm

This command extracts the maximum transconductance from an I_d – V_{gs} curve. It is called using:

```
ExtractGm <Name> <Curve> [<Type>]
```

where:

- <Name> is the name of the extracted parameter.
- <Curve> is to the name of the I_d - V_{as} curve.
- See ExtractVtgm on page 88 for details about Type.

Example

```
set gm [ExtractGm gmLin IdVg]
```

results in output such as:

```
DOE: gmLin 1.123e-04 gm: 1.123e-04 S/um Max gm is at Vg= 0.540 V
```

ExtractGmb

This command is the same as ExtractGm except that the ExtractGmb command uses parabolic interpolation to find the gate bias at which the maximum transconductance occurs (see ExtractGm).

For I_d–V_{gs} curves with a limited number of gate–bias sample points, better accuracy is achieved with the ExtractGmb command.

Extractloff

This command extracts the drain leakage current from an I_d-V_{gs} curve. It is called using:

```
ExtractIoff <Name> <Curve> <Voff>
```

where:

- <Name> is the name of the extracted parameter.
- <Curve> is the name of the I_d - V_{gs} curve (computed for a high drain bias).
- <Voff> defines the gate voltage at which the drain leakage current is extracted, typically, at a small nonzero value to avoid noise.

Extraction Library

Example

```
if { $Type == "nMOS" } { set SIGN 1.0 } \
else { set SIGN -1.0 }
set Ioff [ExtractIoff Ioff [expr $SIGN*1e-4]]
```

results in output such as:

```
DOE: Ioff 5.167e-11 Ioff: 5.167e-11 A/um
```

ExtractMax

This command extracts the maximum of a curve. It is called using:

```
ExtractMax <Name> <Curve>
```

where:

- <Name> is the name of the extracted parameter.
- curve> is the name of the curve.

Example

```
set IdSat [ExtractMax IdSat IdVg]
```

results in output such as:

```
DOE: IdSat 4.028e-04
Max: 4.028e-04
```

ExtractRon

This command extracts the on-state resistance from an I_d–V_{ds} curve. It is called using:

```
ExtractRon <Name> <Curve> <Von>
```

where:

- <Name> is the name of the extracted parameter.
- <curve> is the name of the I_d-V_{ds} curve (computed for a high gate bias).
- <von> defines the drain voltage at which the on-state resistance is extracted, typically, well beyond saturation.

Extraction Library

Example

```
set Ron [ExtractRon Ron IdVd 1.1]
```

results in output such as:

```
DOE: Ron 14909.555
Ron: 14909.555 Ohm um
```

ExtractSS

This command extracts the subthreshold voltage swing from an I_d - V_{gs} curve. It is called using:

```
ExtractSS <Name> <Curve> <Vgo>
```

where:

- <Name> is the name of the extracted parameter.
- <curve> is the name of the I_d-V_{as} curve.
- <Vgo> defines the gate voltage at which the slope is extracted. It should be a value well below the threshold voltage.

Note:

The slope might be *noisy* at the beginning of the curve or at very low current levels, so better results are often obtained when setting $v_{90} > 0$ V.

Example

```
set SS [ExtractSS SSlin IdVg($N) 0.01]
results in output such as:
DOE: SSlin 79.758
SS (subthreshold voltage swing): 79.758 mV/dec
```

ExtractValue

This command extracts the y-value at a given x-point. It is called using:

```
ExtractValue <Name> <Curve> <Xo>
```

where:

- <Name> is the name of the extracted parameter.
- <Curve> is the name of the curve.

Extraction Library

<xo> defines the x-point at which the value is extracted.

Example

```
set CggP [ExtractValue CgP Cgg 1.2]
results in output such as:

DOE: CgP 1.426e-15
CgP: 1.426e-15
```

Here, Cgg is the name of the Inspect total gate-capacitance versus the gate-voltage curve.

ExtractVtgm

This command extracts the threshold voltage from an I_d–V_{gs} curve using the maximum transconductance method. It is called using:

```
ExtractVtgm <Name> <Curve> [<Type>]
```

where:

- <Name> is the name of the extracted parameter as it appears in the Variable Values column of Sentaurus Workbench.
- <Curve> is the name of the I_d - V_{qs} curve.
- <Type> specifies the transistor type, which can be one of the following values:
 - nmos or nmosneg for NMOSFETs with a positive or negative drain current convention.
 - pmos or pmosneg for PMOSFETs with a positive or negative drain current convention.

The MOSFET threshold and transconductance extraction commands require prior knowledge of the transistor type and the sign convention for the drain current.

If $<_{\mathtt{Type}}>$ is omitted, then the transistor type is determined internally by analyzing the first and last points of the given curve.

The command ExtractVtgm passes the extracted value to Sentaurus Workbench and prints it to the log file. It also returns the value to Inspect.

```
set Vt [ExtractVtgm Vtgm IdVg]
results in output such as:
  DOE: Vtgm 0.392
Vt (Max gm method): 0.392 V
```

ExtractVtgmb

This is the same as ExtractVtgm except that the ExtractVtgmb command uses parabolic interpolation to find the gate bias at which the maximum transconductance occurs (see ExtractVtgm on page 88).

For I_d – V_{gs} curves with a limited number of gate–bias sample points, better accuracy is achieved with the <code>ExtractVtqmb</code> command.

ExtractVti

This command extracts the gate voltage from an I_d–V_{gs} curve at which the drain current exceeds a given current level. It is called using:

```
ExtractVti <Name> <Curve> <Ilevel>
```

where:

- <Name> is the name of the extracted parameter.
- <Curve> is the name of the I_d-V_{gs} curve.
- <Illevel> defines the drain current level at which to extract the gate voltage.

Example

```
set Vti [ExtractVti Vti IdVg 1e-7]
results in output such as:
   DOE: Vti 1.476
   Vti (Vg at Io=1.000e-06): 1.476 V
```

FilterTable

The FilterTable command processes data from the Sentaurus Workbench Family Tree to create a plot of one Sentaurus Workbench parameter as a function of another Sentaurus Workbench parameter for a certain subset of experiments. Threshold voltage roll-off plots are a typical application of this utility.

To better understand this utility, it is helpful to first consider the kind of data on which it is designed to operate.

In an Inspect script, you can use the dynamic preprocessing feature of Sentaurus Workbench @<parameter_name>:all@ to access a list of input parameters and extracted values for all Sentaurus Workbench experiments.

Extraction Library

For example:

```
set Types [list @Type:all@]
set Lgs [list @lgate:all@]
set Vts [list @Vt:all@]
set Ids [list @Id:all@]
```

Here, the Tcl list \mathtt{Types} contains, for all experiments, the values of the Sentaurus Workbench input parameter \mathtt{Type} , which for example can take the value \mathtt{nMOS} or \mathtt{pMOS} , depending on whether an NMOS or a PMOS structure is created in this experiment.

Similarly, the Tcl list $_{\tt Lgs}$ contains for all experiments a *parallel* list of values of another Sentaurus Workbench input parameter, which for example contains the value of the gate length of the given MOSFETs. The corresponding extracted parameter can be accessed in the same way. The Tcl lists $_{\tt Vts}$ and $_{\tt Lds}$ can contain the extracted values for the threshold voltage and the drain current for each respective experiment.

Note:

The values in the various lists might or might not be numeric, and they might not be ordered.

Syntax of FilterTable

The FilterTable command takes lists of Sentaurus Workbench parameters as arguments. The first two lists identify the x- and y-values, which will be processed to create a plot. The subsequent arguments control the conditions an experiment must fulfill to be included in the plot. These conditions are defined using optional pairs of a target value and a Sentaurus Workbench list.

The syntax of FilterTable is:

```
FilterTable XList YList [ConditionTarget1 ConditionList1] \
   [ConditionTarget2 ConditionList2] \
   [ConditionTarget3 ConditionList3] [...]
```

The command returns two lists of values:

- The first list contains a subset of the XList. The subset is restricted to the selected experiments. The values are given in ascending order.
- The second list contains the corresponding values of the YList.

In addition, FilterTable ignores all entries of YList that contain a nonnumeric value. You can use this feature to omit failed extractions.

The extend Library

In the tool input file that performs the extraction (for example, a previous Inspect instance), use the #set directive to preset the extracted variable to the value x:

```
#set Vt x
...
set Vt [ExtractVtgmb Vt IdVg]
```

The actual extraction process, here using the ExtractVtgmb command, overwrites the preset value x with the actual value. However, if the extraction process fails, the preset value persists.

For example, after preprocessing, Sentaurus Workbench preprocessor references such as <code>@Type:all@</code> are expanded and the resulting preprocessed file can look like:

```
set Types [list nMOS nMOS nMOS nMOS pMOS pMOS pMOS]
set Lgs [list 0.090 0.045 0.130 0.065 0.065 0.045 0.130 0.090]
set Vts [list 0.424 0.313 0.414 0.408 -0.344 -0.232 x -0.374]
set XYLists [FilterTable $Lgs $Vts "nMOS" $Types]
cv_createFromScript Vt_vs_Lg_nMOS [lindex $XYLists 0] \
    [lindex $XYLists 1] y
cv_display Vt_vs_Lg_nMOS y

set XYLists [FilterTable $Lgs $Vts "pMOS" $Types]
cv_createFromScript Vt_vs_Lg_pMOS [lindex $XYLists 0] \
    [lindex $XYLists 1] y
cv_display Vt_vs_Lg_pMOS y
```

This script creates two separate V_t roll-off curves: one for all nmos experiments and one for all pmos experiments. The values are shown in order and the data point for Type=pmos and Lg=0.130, for which the extraction failed (Vt=x), is omitted.

The extend Library

The extend library implements high-level commands to provide:

- Better control of curve attributes (cv_autoIncrStyle, cv_disp, cv_nextColor, cv_nextSymbol, cv_setFillColor)
- Curve manipulation (cv_addCurve, cv_addDataset, cv_linTrans, cv_monotonicX, cv_scale, cv_sort)
- Additional curve information (cv_getGlobalExtrema, cv_getLocalExtrema, cv_getNames, cv_getRange, cv_getXmax, cv_integrate, cv_linFit)
- Extraction of dataset information (ds_getValue, proj_datasetExists)
- A simple debug print function (dbputs)

The extend Library

- Functions to work with lists (ldiff, lintersect, ltranspose, lunion)
- An ASCII file import filter (fi_readTxtFileHeader)

You can load the library with the command:

```
load_library extend
```

The library is located at \$STROOT/\$STRELEASE/lib/inspectlib/extend.tcl.

If you need to customize the library, you can create a local copy of the library and edit the scripts. In this case, the local version is loaded by sourcing the script:

```
source extend.tcl
```

The commands of the library are described in the following sections. If a command is applied to a curve, the creation of the curve is not mentioned explicitly in the examples for brevity. For test purposes, curves can be created easily with the following line:

```
cv_createFromScript c1 {0 1} {1 2}
```

Note:

Arguments in braces are *optional*. The first term in the braces is the name of the argument, and the second term is the default value of the argument. For example, a command that has been defined as <code>command {arg def_value}</code> can be called as <code>command (which is equivalent to command def_value)</code> and also as <code>command other value</code>.

cv_addCurve

cv_addCurve cname cname2

Action Adds the y-values of the curve *cname2* to the y-values of the curve *cname*.

Input cname, cname2, name of curves

Returns None

```
cv_createFromScript c1 {0 1} {1 2}
cv_createFromScript c2 {0 1} {3 4}
cv_addCurve c1 c2
puts "y: [cv_getValsY c1]"
> y: 4 6
```

cv_addDataset

cv_addDataset cname xdset ydset

Action Adds the y-values of a dataset to an existing curve.

Input cname, name of curve to which datasets will be added

xdset, dataset name of the x-values to be added ydset, dataset name of the y-values to be added

Returns None

Example

```
# sum the total currents of nContact and nContact2
cv_addDataset iv "n4_des pContact OuterVoltage" \
    "n4_des nContact TotalCurrent"
cv_addDataset iv "n4_des pContact OuterVoltage" \
    "n4_des nContact2 TotalCurrent"
```

cv_angularMap

```
cv_angularMap cname {astart 0} {aend 360}
```

Action Maps a periodic curve to a fixed angular range of astart to aend.

For angular data, you might want to reduce all data points to the first period. For example, if a full circle with $0..360^{\circ}$ will be plotted, but datapoints with x-values higher than 360 exist, these should be mapped to the first period, that is, the y-value at x=361 will be added to the datapoint x=1.

Input cname, name of curve

astart, start of the angular range; default is 0 aend, end of the angular range; default is 360

Returns None

```
cv_createFromScript a {0 1 2 90 91 92} {1 2 3 4 5 6}
cv_angularMap a 0 90
puts [cv_getVals a]
-> {0 1 2 90} {1 7 9 4}
```

cv_autoIncrStyle

cv_autoIncrStyle {stylelist {color fillColor line symbol}} | off

Action Sets the curve attributes to be incremented by one whenever a curve is displayed

using cv_disp. The attributes are incremented in the order given by stylelist.

Input stylelist, list of options; default is {color fillColor line symbol}

off, switches off the automatic increment feature

Returns None

Example

```
# First increment color. If all colors are used, increment symbol
# and start with first color again.
cv_autoIncrStyle {color symbol}
cv_disp c1
cv_disp c2
```

cv_disp

```
cv_disp cname {label ""} {axis "y"}
```

Action

Displays a curve using the specified label and axis. Curve attributes are incremented by default, such that each displayed curve can be easily distinguished.

Additional control of the curve attributes is given by the following commands:

cv_autoIncrStyle, cv_nextColor, cv_nextLine, cv_nextSymbol, cv_resetColor, cv_resetFillColor, cv_resetLine, cv_resetStyle, cv_resetSymbol

Input cname, name of curve

label, specifies the curve label to be displayed in the legend; default is the curve

name

axis, specifies the axis to use: y (default) or y2

Controlling attributes manually makes most sense when cv_autoIncrStyle is

switched off.

Returns None

```
cv_disp iv "simulated IV" y
```

The extend Library

cv_exists

cv_exists cname

Action Checks whether a curve exists.

Input cname, name of curve

Returns 1 (the curve exists) or 0 (the curve does not exist)

Example

```
if {[cv_exists iv]} {puts "curve iv exists"}
```

cv_getGlobalExtrema

cv_getGlobalExtrema cname {type max}

Action Returns the global maximum or minimum of a curve as a list.

Input cname, name of curve

type, specifies either the global maximum (max) or the global minimum (min); default

is max

Returns If type equals max: {xmax ymax}

If type equals min: {xmin ymin}

```
set cmin [cv_getGlobalExtrema iv min]
puts "The minimum of the iv-curve is [lindex $cmin 1] and occurred at
   [lindex $cmin 0]"
```

cv_getLocalExtrema

```
cv_getLocalExtrema cname {type max}
```

Action Returns all local maxima or minima of a curve as a list.

Input cname, name of curve

type, specifies either the local maxima (max) or local minima (min); default is max

Returns If type equals max: {{xmax1 ymax1} {xmax2 ymax2} ...}

If type equals min: {{xmin1 ymin1} {xmin2 ymin2} ...}

Example

```
set cmax [cv_getLocalExtrema iv "max"]
puts "All maxima of the iv-curve: $cmax"
```

cv_getNames

cv_getNames

Action Returns all existing curve names.

Input None

Returns List of curve names

```
puts "the following curves exist currently: [cv_getNames]"
```

The extend Library

cv_getRange

cv_getRange cname

Action Returns the x- and y-range of a curve as a list.

Input cname, name of curve

Returns {xmin,xmax,ymin,ymax}

Example

puts "{xmin,xmax,ymin,ymax}: [cv_getRange iv]"

cv_getXmax

cv_getXmax cname

Action Returns the upper boundary of the x-values of a curve.

Input cname, name of curve

Returns xmax

Example

puts "upper boundary of the x values of iv: [cv_getXmax iv]"

cv_getXmin

cv_getXmin cname

Action Returns the lower boundary of the x-values of a curve.

Input cname, name of curve

Returns xmin

Example

puts "lower boundary of the x values of iv: [cv_getXmin iv]"

The extend Library

cv_getYmax

cv_getYmax cname

Action Returns the upper boundary of the y-values of a curve.

Input cname, name of curve

Returns ymax

Example

puts "upper boundary of the y values of iv: [cv_getYmax iv]"

cv_getYmin

cv_getYmin cname

Action Returns the lower boundary of the y-values of a curve.

Input cname, name of curve

Returns ymin

Example

puts "lower boundary of the y values of iv: [cv_getYmin iv]"

cv_integrate

```
\verb|cv_integrate| formula {xstart {}} {xend {}} {mode {}} {xdigits {}} \\
```

Action

Performs integration of a formula, and returns the integration value.

Input

formula, formula to be integrated as it is specified for cv_createWithFormula xstart, start of the integration interval; if not specified, the start of the curve is used xend, end of the integration interval; if not specified, the end of the curve is used mode, defines the integration mode:

- If not specified, then it is set to {}, which performs the Inspect internal integration using integr().
- sumup sums all y-values.
- trapez performs the integration using the trapezoidal rule.

xdigits, specifies the number of digits to determine whether two x-values are identical

When the formula contains more than one curve and these curves have different sets of x-values, summation is performed over all x-values.

Returns

Integration value

Example

```
# P_t is the time-dependent power
puts "energy in the first second is: [cv_integrate P_t 0 1 trapez]"
```

cv_isVisible

cv_isVisible cname

Action Checks whether a curve is displayed.

Input cname, name of curve

Returns 1 if curve is currently displayed; otherwise, 0

```
if {[cv_isVisible iv]} {puts "curve iv visible"}
```

cv_linFit

```
\verb|cv_linFit| formula {xstart {}} { xend {}} {}\}
```

Action

Performs a linear fit $y = A + B \cdot x$ to a curve formula.

Input

formula, formula to be fitted, as it is specified for cv_createWithFormula
xstart, start of the fit interval
xend, end of the fit interval

Returns Fit results as a list:

- (Estimate of) Intercept A
- (Estimate of) Slope B
- Standard deviation of \boldsymbol{y} relative to the fit correlation coefficient \boldsymbol{R}^2

Scales a curve linearly, and replaces x with $xm \cdot x + xb$ and y with $ym \cdot y + yb$.

- Number of degrees of freedom df
- Standard error of intercept A
- Significance level of A
- Standard error of slope B
- Significance level of B

Example

Action

Input

```
set res [cv_linFit "log(<cname>)"]
```

cv_linTrans

```
cv_linTrans cname xm \{xb\ 0\}\ \{ym\ 1\}\ \{yb\ 0\}
```

xm, slope of the x-values xb, offset of the x-values ym, slope of the y-values yb, offset of the y-values

cname, name of curve

Returns None

The extend Library

Example

```
# Scaling an IV curve given in A over V, to mA over mV.
# In addition, the curve had a current offset of 2A, which you want
# to remove.
cv_linTrans iv 1e3 0 1e3 -2000
```

cv_monotonicX

cv_monotonicX cname

Action Extracts the part of a curve where the x-values increase monotonically to the maximal

x-value.

Input cname, name of curve

Returns None

Example

```
cv_createFromScript iv {0 1 2 0 2 4} {1 2 3 4 5 6}
cv_monotonicX iv
puts "values: [cv_getVals iv]"
-->values: {0 2 4} {4 5 6}
```

cv_nextColor

cv_nextColor {cindex ""}

Action Sets the next color of the curve from the extend::COLORPALETTE list.

Input cindex, if cindex is specified, the specified entry from the extend::COLORPALETTE

list is taken; otherwise, the next entry is chosen

Controlling attributes manually makes most sense when cv_autoIncrStyle is

switched off.

Returns None

```
cv_autoIncrStyle off
cv_disp iv1
cv_nextColor
cv_disp iv2
```

cv_nextLine

cv_nextLine {cindex ""}

Action Sets the next line style of the curve from the extend::LINEPALETTE list.

Input cindex, if cindex is specified, then the specified entry from the

extend::LINEPALETTE list is taken; otherwise, the next entry is chosen. If the last line

style is reached, the first line style is returned again.

Controlling attributes manually makes most sense when cv_autoIncrStyle is

switched off.

Returns None

Example

cv_autoIncrStyle off
cv_disp iv1
cv_nextLine
cv_disp iv2

cv_nextSymbol

cv_nextSymbol {cindex ""}

Action Sets the next symbol type of the curve from the extend::SYMBOLPALETTE list.

Input cindex, if cindex is specified, then the specified entry from the

extend::SYMBOLPALETTE list is taken; otherwise, the next entry is chosen. If the last

symbol is reached, the first symbol is returned again.

Controlling attributes manually makes most sense when cv_autoIncrStyle is

switched off.

Returns None

Example

cv_autoIncrStyle off
cv_disp iv1
cv_nextSymbol
cv_disp iv2

The extend Library

cv_resetColor

cv_resetColor

Action Resets the color to the default entry that equals the first entry from the

extend::COLORPALETTE list.

Input None

Returns None

Example

cv_autoIncrStyle off
cv_disp iv1
cv_nextColor
cv_disp iv2
cv_resetColor
cv_nextSymbol
cv_disp iv3

cv_resetFillColor

cv_resetFillColor

Action Resets the fill color to white.

Input None

Returns None

Example

cv_autoIncrStyle off
cv_disp iv1
cv_nextColor
cv_disp iv2
cv_resetFillColor
cv_nextSymbol
cv_disp iv3

The extend Library

cv_resetLine

cv_resetLine

Action Resets the line style to the default entry that equals the first entry from the

extend::LINEPALETTE list.

Input None

Returns None

Example

cv_autoIncrStyle off
cv_disp iv1
cv_nextLine
cv_disp iv2
cv_resetLine
cv_nextSymbol
cv_disp iv3

cv_resetStyle

cv_resetStyle

Action Resets all curve style attributes such as color, fill color, symbol, and line style to their

default values.

Input None

Returns None

Example

cv_autoIncrStyle off
cv_disp iv1
cv_nextSymbol
cv_nextColor
cv_disp iv2
cv_resetStyle
cv_disp iv3

cv_resetSymbol

cv_resetSymbol

Action Resets the symbol to the default entry that equals the first entry from the

extend::SYMBOLPALETTE list.

Input None

Returns None

Example

```
cv_autoIncrStyle off
cv_disp iv1
cv_nextSymbol
cv_disp iv2
cv_resetSymbol
cv_nextColor
cv_disp iv3
```

cv_round

cv_round cname xdigits ydigits

Action Rounds off the x-data and y-data values to the specified number of digits.

Input cname, name of curve

xdigits, number of digits to be kept for x-values; default is -1 (no rounding) ydigits, number of digits to be kept for y-values; default is -1 (no rounding)

Returns None

```
cv_createFromScript c {1.01 5.05} {9.09 7.07}
cv_round c 1 1
puts "[cv_getVals c]"
=> {1 5.1} {9.1 7.1}
```

cv_scale

cv_scale cname xm ym

Action Scales a curve linearly, and replaces x with $xm \cdot x$ and y with $ym \cdot y$.

Input cname, name of curve

xm, scale applied to x-values ym, scale applied to y-values

Returns None

Example

```
# Scales a current over time given in A over s to mA over us.
cv_scale i_t 1e6 1e3
```

cv_setFillColor

```
cv_setFillColor {mode 1}
```

Action Switches the fill color on and off.

Input *mode*, sets the fill color:

- 1 fills the symbol with the curve color; default is 1
- 0 specifies the fill color is white

Returns None

Example

cv_autoIncrStyle off
cv_setSymbol 1
cv_disp iv1
cv_nextColor
cv_setFillColor 1
cv_disp iv2

cv_setSymbol

```
cv_setSymbol {mode 1}
```

Action Switches symbols on and off.

Input *mode*, sets the symbol:

• 1 specifies that the symbols are shown; default is 1

 $\bullet\,$ 0 specifies that the symbols are not shown

Returns None

Example

```
cv_autoIncrStyle off
cv_disp iv1
cv_nextColor
cv_setSymbol 1
cv_disp iv2
```

cv_sort

```
cv_sort cname {xdigits 20}
```

Action Sorts data points of a curve according to x-values, and removes duplicates.

Input cname, name of curve

xdigits, number of digits of x-value to determine whether two values are identical

Returns None

```
cv_createFromScript c {1 2 0.0001 3 0} {2 3 -1 4 1}
cv_sort c 3
puts "[cv_getVals c]"
==> {0 1 2 3} {1 2 3 4}
```

cv_write

cv_write type filename curveList

Action Exports curve data to a file. This command works like the native cv_write command

but, in addition, allows exporting data in CSV format, which is most suitable for

transferring data to spreadsheet applications.

Input type, type of file: csv, plt, xgraph, or xmgr

filename, name of file in which to export data

curveList, list of curves

Returns 1 if successful, 0 otherwise

Example

```
cv_write csv export.csv "idvg cv($n)"
```

dbputs

```
dbputs str {dbglevel 1}
```

Action Debugs output, where str is displayed in the log if the debug variable :: DEBUG is

greater than or equal to the debug level.

Input str, string to be printed to standard output

dbglevel, sets the debug level

Returns None

```
dbputs "test1"
set ::DEBUG 2
dbputs "test2"
dbputs "test3" 2
dbputs "test4" 3
set ::DEBUG 0
dbputs "test5"
==> test2, test3
```

ds_getValue

ds_getValue proj datasetName {index end}

Action Returns the *index*-th value of a dataset.

Input proj, project name of the loaded .plt file

datasetName, name of dataset

index, the index of the dataset item to return; counting starts with 0 and finishes with

end; default is end

Returns Real number

Example

```
proj_load n5_des.plt
puts "first value [ds_getValue n5_des "anode OuterVoltage" 0]"
puts "last value [ds_getValue n5_des "anode OuterVoltage"]"
```

fi_readTxtFile

fi_readTxtFile fname cname {columnIdx 1}

Action Reads in data from an ASCII file, where columns are separated by space. The

x-values are taken from the first column; the column to be used for the y-values can be specified. The file can contain comment lines starting with a hash character (#).

Input fname, name of ASCII file

cname, name of curve to be created

columnIdx, column index to be used for y-values; column-counting starts with 0;

default is the second column (columnIdx=1)

Returns None

```
fi_readTxtFile "am15g.txt" spec
```

fi_readTxtFileHeader

fi_readTxtFileHeader fname

Action Reads and returns the header line – a single line that is neither data nor comment.

Input fname, name of ASCII file

Returns List of strings

Example

```
puts "[fi_readTxtFileHeader "am15g.txt"]"
==> Wavelength [um] Intensity [W*cm^-2]
```

gr_axis

```
gr_axis axis title {xmin ""} {xmax ""} {scale lin}
```

Action Sets the attributes of the x-axis and y-axis.

Input axis, specifies axis to be modified: x, y, or y2

title, axis label

xmin, xmax, sets the range of the axis, where {} specifies automatic scaling

scale, specifies the scaling to apply: lin (default) or log

Returns None

```
gr_axis x {voltage [V]}
gr_axis y {current [A]} {} {} log
```

gr_resetAxis

gr_resetAxis

Action Resets all the axis attributes and, in particular, switches off the y2-axis.

Input None

Returns None

Example

```
gr_axis x {voltage [V]}
gr_axis y {current [A]} {} {} log
gr_resetAxis
```

gr_setStyle

gr_setStyle mode

Action Sets the style of the plot area.

Input *mode*, specifies the mode:

- "screen" (default) is used for the interactive mode.
- "presentation" uses larger font sizes suitable for copying plots into presentations.

Returns None

```
gr_setStyle "presentation"
```

Idiff

```
ldiff list1 list2 {symmetric ""}
```

Action Returns all items of *list1* that are not in *list2*.

Input 1ist1, 1ist2, lists to be compared

symmetric, if specified, indicates that the returned list will also contain all items of

list2 that are not in list1

Returns List

Example

```
set 11 {1 2 3 4}
set 12 {1 2 5}
puts "[ldiff $11 $12]"
==> {3 4}
puts "[ldiff $11 $12 1]"
==> {3 4 5}
```

lintersect

lintersect list1 list2

Action Returns all items that are members of both *list1* and *list2*.

Input 1ist1, 1ist2, lists to be compared

Returns List

```
set l1 {1 2 3 4}
set l2 {1 2}
puts "[lintersect $11 $12]"
==> {1 2}
```

Chapter 8: Working With Script Libraries

The extend Library

Itranspose

ltranspose *list*

Action Transposes a list.

Input list, list to transpose

Returns List

Example

```
set 1 {{1 2} {3 4} {5 6}}
puts "[ltranspose $1]"
==> {{1 3 5} {2 4 6}}
```

lunion

lunion list1 list2

Action Returns a list of unique items that are members of *list1* or *list2*.

Input 1ist1, 1ist2, lists to be compared

Returns List

```
set 11 {1 2 3 4}
set 12 {1 2 5}
puts "[lunion $11 $12]"
==> {1 2 3 4 5}
```

The extend Library

proj_check

proj_check proj

Action Checks all datasets in a project to see whether all entries are valid.

Input proj, project name of the loaded .plt file

Returns List of dataset names containing invalid data (nonnumeric values)

Example

```
proj load n5 des.plt
proj_check n5_des
```

proj_datasetExists

```
proj_datasetExists proj datasetName {groupName ""}
```

Checks whether a project contains data with the specified dataset and group name. Action

Input proj, project name of the loaded .plt file

datasetName, name of dataset

groupName, group name of dataset; if no group name is given and the dataset name

contains a space, the first word of datasetName, is taken as the group name

Returns 1 (dataset exists) or 0 (dataset does not exist)

```
proj_load n5_des.plt
if {[proj_datasetExists n5_des "anode OuterVoltage"]}
   {puts "anode OuterVoltage exists"}
if {[proj_datasetExists n5_des "OuterVoltage" "anode"]}
   {puts "anode OuterVoltage exists"}
if {[proj_datasetExists n5_des "NO_NODE time"]} {puts "time exists"}
```

proj_getGroups

proj_getGroups proj

Action Returns a sorted list containing all group names of the project.

Input proj, project name of the loaded .plt file

Returns List of strings

Example

```
proj_load n5_des.plt
puts "all group names: [proj_getGroups n5_des]"
```

proj_groupExists

proj_groupExists proj groupName

Action Checks whether a project contains a particular group.

Input proj, project name of the loaded .plt file

groupName, name of group

Returns 1 (group exists) or 0 (group does not exist)

```
proj_load n5_des.plt
if {[proj_groupExists n5_des "anode"]} {puts "group anode exists"}
```

proj_loadPlx

```
proj_loadPlx fileName {curveName} {appendDatasetName}
```

Action

Opens a .plx file, and creates a curve without displaying it.

Input

fileName, name of .plx file from which to load data curveName, name of curve; if not specified, the dataset name is used appendDatasetName, if set to 1, it appends the dataset name to the curve name:

- If curveName is empty, then the dataset name is used.
- If a simple curve name is given, then the dataset name is appended in parentheses, for example, <code>cname(data)</code>.
- If the curve name contains parentheses, then the dataset name is appended in the parentheses, for example, <code>cname(cval,data)</code>.

Returns

None

```
Content of test.plx:
"data"
0 0
1 2.8
...
proj_loadPlx test.plx
puts "visible: [cv_isVisible data]"
==> visible: 0
proj_loadPlx test.plx c(1) 1
puts "visible: [cv_isVisible c(1,data)]"
==> visible: 0
```

The PhysicalConstants Library

This library defines a set of variables of major physical constants [1].

To load the library, use the command:

load_library PhysicalConstants

Table 6 Variables defined in PhysicalConstants library

Name of variable	Value	Unit
AtomicMassConstant	1.660540210e-27	kg
AvogadroConstant	6.022136736e23	mol^{-1}
BohrMagneton	9.274015431e-24	J/T
BoltzmannConstant	1.38065812e-23	J/K
ElectronMass	9.109389754e-31	kg
ElectronVolt	1.6021773349e-19	J
ElementaryCharge	1.6021773349e-19	С
FaradayConstant	9.648530929e4	C/mol
FineStructureConstant	7.2973530833e-3	1
FreeSpaceImpedance	376.730313462	Ω
GravitationConstant	6.6725985e-11	m ³ /kg/s ²
MagneticFluxQuantum	2.0678346161e-15	Wb
MolarVolume	22.4141019e-3	m ³ /mol
Permeability	12.566370614e-7	H/m
Permittivity	8.854187817e-12	F/m
Pi	3.141592653589793	1
PlanckConstant	6.626075540e-34	Js
ProtonMass	1.672623110e-27	kg

IC-CAP Model Parameter Extraction Library

Table 6 Variables defined in PhysicalConstants library (Continued)

Name of variable	Value	Unit
RydbergConstant	1.097373153413e7	mol ⁻¹
SpeedOfLight	299792458	m/s
StefanBoltzmannConstant	5.6705119e-8	$W/m^2/K^4$

All variables are defined in the namespace ::const::. To access a variable, use \$::const::<varName> or \$const::<varName>, where <varName> must be replaced by a particular variable name. For example:

```
load_library PhysicalConstants
puts "c=$const::SpeedOfLight"
```

The function getVarNames returns a list of all variable names. For example:

```
set varlist [const::getVarNames]
puts "all variables: $varlist"
==> all variables: AtomicMassConstant AvogadroConstant BohrMagneton ...
```

To see a list of all variables, the function printvarNames prints directly the names of all available variables:

```
const::printVarNames
==>
AtomicMassConstant
AvogadroConstant
BohrMagneton
```

IC-CAP Model Parameter Extraction Library

The commands of this library are used to export device simulation results to the Integrated Circuit Characterization and Analysis Program (IC-CAP) model extraction tool. These commands can create files that can be later imported by IC-CAP.

To load the library, use the command:

```
load_library ise2iccap
```

Exporting Data

```
iccap_Write fileName headerInfo data
```

Action Exports data to a file using the IC-CAP data management file data format [2].

Input fileName, file name

headerInfo, header information (see Header Information on page 119)

data, array of curve data (see Array Data on page 121)

Returns None

Header Information

The header information <code>headerInfo</code> is a list formed by the sublists <code>userInput</code>, <code>iccapInput</code>, and <code>output</code>.

A detailed description of the header section is presented in the literature [2]. You can use the following examples as guides.

userInput

This sublist contains information about variables that cannot be swept in a traditional IC-CAP setup.

In the following example, no user sweeps are considered:

```
userInput: {}
```

iccapInput

This sublist contains information about variables that can be swept in an IC-CAP setup. For example:

In this example, there are three IC-CAP input variables, where:

- The first element is the name of the input variable.
- · The second element is the mode.

IC-CAP Model Parameter Extraction Library

- The third and fourth elements are the names of the positive and negative nodes for the corresponding input variable.
- The fifth element is a list that describes the sweep. The first element of this list is the sweep type, which can be LIN, LIST, CON, LOG, or SYNC.

The sweep information for the first input variable (vg) is a list where:

- LIST indicates that all sweep values are explicitly defined.
- 1 is the sweep order (1 is the innermost or fastest varying sweep).
- 26 is the number of values.
- 0.0...2.5 indicate all values that the particular variable can take.

The sweep information for the second input variable (vb) is a list where:

- LIN indicates that the sweep values are a set of values defined in a linear scale.
- 2 is the sweep order.
- -0.1 is the start value.
- -0.5 is the end value.
- 3 is the number of values.

The sweep information for the third input variable (vd) is a list where:

- CON indicates that there is only one value for this variable.
- 0.0 is a constant value.

output

This sublist contains information about output variables that can be recognized in an IC-CAP setup. For example:

```
output is {{id I D GROUND}}}
```

In this example, there is only one output variable, which is the drain current. The first element is the name of the output variable, the second element is the mode, and the third and fourth elements are the names of the positive and negative nodes for the corresponding output variable.

Array Data

The array data must contain, at least, the following information:

```
data(<input tuples>,<output>)
```

There is one array cell for each pair formed by a tuple of input variable values and an output variable. The <input tuples> order is the inverse of the sweep order.

For example, using the example in Header Information on page 119, the array data contains the following information:

```
data(<vb>,<vg>,id)
```

In this case, each cell stores the drain current (id) for a particular combination of substrate voltage value (<vb>) and gate voltage value (<vg>).

For example, the tuple data(-0.1,1.0,id) stores the drain current for vb = -0.1 V and vq = 1.0 V.

Curve Comparison Library

The commands of this library compare two curves by computing the square difference between the two curves within a given domain.

Computes the square difference between two curves within a given domain (window)

To load the library, use the command:

```
load_library curvecomp
```

cvcmp_CompareTwoCurves

cvcmp_CompareTwoCurves curve1 curve2 windowX use_log n

using either linear scale or logarithmic scale.

Input curve1, curve2, curves to compare

windowX, window in the x-axis

use_log, true if logarithmic scale is usedn, base name for the internal curves

Returns Square difference between two curves

Action

cvcmp_DeltaTwoCurves

cvcmp_DeltaTwoCurves exp_file sim_file minX maxX use_log name

Action

Writes the square difference between two curves within a given domain (window) to the standard output. This difference can be computed using either a linear or logarithmic scale. Both curves are read from files. This command uses the ft_scalar command to export the computed difference to the Family Tree of Sentaurus Workbench.

Input

exp_file, sim_file, files where the two curves are stored

minX, maxX, window in the x-axis

use_log, true if a logarithmic scale is used

name, name of the column of the Family Tree of Sentaurus Workbench where the

computed difference is stored

Returns

None

References

- [1] G. Woan, *The Cambridge Handbook of Physics Formulas*, Cambridge: Cambridge University Press, 2000.
- [2] IC-CAP Data Management File Format Specification: Final IC-CAP 5.0 file specification, E. Arnold and M. Peroolmal (eds.), HP-EESOP document archive, March, 1997.



Elements of User Interface

This appendix lists the toolbar buttons and menus available from the Inspect user interface.

Toolbar Buttons

The toolbar provides quick access to commonly used operations that are also available from the menus.

Table 7 Inspect toolbar buttons

Button	Description	Button	Description
<u> </u>	Loads a dataset file	0:0 0:0	Shows or hides the grid
=	Prints the current plot	-	Moves selected curve to the front of all curves
3	Reloads the dataset file	 -	Moves selected curve to the back of all curves
<u>~</u>	Applies recent plotting actions made on the previous dataset to the current dataset	•	Moves selected curve forward
<u>"</u>	Removes all curves, and cleans up the plot area	-	Moves selected curve backward
€ (Zooms in to a selected area	•	Runs or continues executing script
Q	Zooms out of an area		Stops executing script
×	Displays the entire plot area	X	Switches on or switches off logarithmic scale on the x-axis

Table 7 Inspect toolbar buttons (Continued)

Button	Description	Button	Description
	Centers the view in the plot area (applies to a zoomed plot only)	₽°°l	Switches on or switches off logarithmic scale on the left y-axis
×	Zooms in to one selected curve	Ÿ2	Switches on or switches off logarithmic scale on the right y-axis
	Shows or hides the legend text		

File Menu

Table 8 File menu commands

Command	Toolbar button	Shortcut keys	Description
Load Dataset	=	Ctrl+L	Opens dataset file.
Update Datasets	2	Ctrl+U	Reloads datasets from opened files and updates related curves.
Automatically Update Datasets			Automatically reloads datasets from opened files.
Delete Datasets			Deletes selected projects and the curves that use data from them.
Load Setup			Loads preferences stored in setup file.
Save Setup			Saves preferences to setup file.
Restore All			Loads a previously saved project from a .sav file.
Save All			Saves current state of Inspect to a .sav file.
Export			Saves current curves to different file formats.
Write Bitmap		Ctrl+W	Creates a bitmap file of plot area image in PNG format.
Write EPS			Creates an EPS file of plot area image.

Edit Menu

Table 8 File menu commands (Continued)

Command	Toolbar button	Shortcut keys	Description
Write PS			Creates a PostScript file of plot area image.
Print		Ctrl+P	Opens the Printer Setup dialog box.
Preferences			Opens the Preferences dialog box.
Exit		Ctrl+Q	Exits Inspect.

Edit Menu

Table 9 Edit menu commands

Command	Toolbar button	Shortcut keys	Description
Redo Last Plot	<u>~</u>	Ctrl+E	Applies the last plotting actions to selected datasets.
Plot Area		Ctrl+G	Opens the Plot Area dialog box to change attributes of plot area.
Clean Plot Area	<u></u>		Cleans up the plot area.
Axes		Ctrl+A	Opens the Axes dialog box to change attributes of axes.
Labels			Displays options to add, edit, and remove labels from the plot area.
Define Macros			Opens the Macro Editor.

Curve Menu

Table 10 Curve menu commands

Command	Toolbar button	Shortcut keys	Description
Transform			Displays the following options:
			Abs X: Maps x-value of all data points of selected
			curves to its absolute value and redisplays the curve Abs Y : Maps y-value of all data points of selected curves to its absolute value and redisplays the curve
			Reflect X: Reflects curve about x-axis.
			Reflect Y: Reflects curve about y-axis.
			Suppress Backtrace: Data points of a selected curve where the x values are not monotonically increasing (where the current x-value is less than the previous one) indicate the start of a new line. In this case, no line connects the previous point to the current point.
Curve Data		Ctrl+D	Opens a dialog box that shows the points of the dataset corresponding to the selected curve.
Restore Data			Undoes all changes to selected curves.
DeltaX (X)			Creates a deltaX curve for each selected curve. The deltaX curve is obtained by taking the x-dataset of the original curve as the x-dataset of the new curve and computing the y-dataset at every point by subtracting the x-value at the current point from the x-value at the next point.
Intersect X ?			Opens a dialog box displaying the x-coordinate at which the selected curve crosses the x-axis. If more than one curve is selected, no action is taken.
Inspector			Opens the Inspector dialog box.

Table 10 Curve menu commands (Continued)

Command	Toolbar button	Shortcut keys	Description
Drawing Order			Opens a submenu to rearrange order of curves. Options are:
	-		Move to Front : Moves the selected curve to the front of all curves.
	 -		Move to Back : Moves the selected curve to the back of all curves.
	-		Move Forward : Moves the selected curve one step closer to the front.
	-		Move Backward : Moves the selected curve one step closer to the back.

Script Menu

Table 11 Script menu commands

Command	Toolbar button	Shortcut keys	Description
Run Script	•	Ctrl+R	Opens a dialog box to select the script file to be run. The default filter for the script file is * . cmd.
Record			Creates a script file. Options are:
			Start : Opens the Record Script File dialog box for selecting the output file and starts to record a sequence of operations.
			Add Pause: Adds a sleep command to the script. The length of the pause is selected from the submenu. Add Break: Adds a break command to the script.
			Stop: Stops the recording.
Continue Script	•	Ctrl+C	When a break command is encountered in a script, the execution is suspended and user input is possible. This option reactivates the execution of the script.
Abort Script	•	Ctrl+N	When script execution is suspended by a break command, this command omits the remaining part of the script.

Extensions Menu

Extensions Menu

Table 12 Extensions menu command

Command	Toolbar button	Shortcut keys	Description
Two-Port Networks		Ctrl+T	Opens the RF Parameter Extraction dialog box.

Help Menu

Table 13 Help menu command

Command	Toolbar button	Shortcut keys	Description
About		Ctrl+B	Provides version information.

Known Limitations

This appendix describes known limitations that affect working with the Inspect tool.

The diff(...formula...) and integr(...formula...) Operators

The diff() and integr() operators require a *curve only* argument, which can be defined as a curve that contains more than one point, since a curve that contains only one point is treated as a scalar. When a formula is used as an argument for these operators, the parser cannot always decide if the argument curve for the diff() or integr() operators will have more than one point. Therefore, an error message is generated.

For example, to obtain proper results, diff(log10(...formula...)) must be performed in two steps:

- 1. Create the curve log10(...formula...).
- 2. Apply the diff() operator to the resulting curve.

The vecvalx(...formula...) and vecvaly(...formula...) Operators

It is advisable to compute the curve defined by $\dots formula...$ before applying the vecvalx() or vecvaly() operators. In addition, if the curve displays exponential behavior, better results are obtained if the curve is transformed to logarithmic scale before applying these operators.

For example, suppose you want to compute the value:

```
vecvalx(diff(<c1>), 1e-7)
```

and the curve defined by diff(<cl>) has an exponential behavior. In this case, to obtain more precise results, create a curve <cl>2>, which will be equal to log(diff(<cl>)), and then compute the required value:

```
vecvalx(<c2>, log(1e-7))
```

No Support for Right Y-Axes

The Inspector dialog box works only for the x-axis and left y-axis.