The Plane Fuel System Runs

First Run below is when the system is used correctly which becomes safe.

```
C:\Windows\system32\cmd.exe - main
C:\Users\2341373\Downloads\Fuel2\Fuel2>main
Start from Europe
Please type the fuel you want for your flight from Europe to Asia?
Please type from 1001 between 2000
1001
The system is currently ON after the flight from  1
Please type the necessary fuel you want for your flight from Asia to Oceanic?
Please type from 2001 between 3500
2001
The system is currently ON after the flight from  2
Please type the necessary fuel you want for your flight from Oceanic to America?
For Oceanic flights please type from 3500 between 5000
4000
The system is currently ON after the flight from  3
Fuel Status =         1001
Plane_System = Plane System ON
Fuel Status 2nd flight =         2001
Plane_System 2nd flight = Plane System ON
Fuel Status 3rd flight =         4000
Plane_System 3rd flight = Plane System ON
Start from Europe
Please type the fuel you want for your flight from Europe to Asia?
Please type from 1001 between 2000
```

The Second Run below is when the system is used incorrectly which becomes unsafe.

```
C:\Windows\system32\cmd.exe - main
C:\Users\2341373\Downloads\Fuel2\Fuel2>main
Start from Europe
Please type the fuel you want for your flight from Europe to Asia?
Please type from 1001 between 2000
4
The system is currently OFF after the flight from  1
Please type the necessary fuel you want for your flight from Asia to Oceanic?
Please type from 2001 between 3500
100
The system is currently OFF after the flight from  2
Please type the necessary fuel you want for your flight from Oceanic to America?
For Oceanic flights please type from 3500 between 5000
12
The system is currently OFF after the flight from  3
Fuel Status =            4
Plane_System = Plane System OFF
Fuel Status 2nd flight =          100
Plane_System 2nd flight = Plane System OFF
Fuel Status 3rd flight =           12
Plane_System 3rd flight = Plane System OFF
Start from Europe
Please type the fuel you want for your flight from Europe to Asia?
Please type from 1001 between 2000
```