## C9: Determination of "Samsung Galaxy Buds Pro" earbuds point of failure under the water (IPX7 protection)

	ructive omation Type	<b>Priority</b> Low	Estimate None	References None	
Preconditions					
Environment: Android 5 or higher					
1) Earbuds: Samsung Galaxy Buds Pro (100 % charged)					
2) Smartphone (at least 50 % charged)					
3) Earbuds are connected to the smartphone via Bluetooth					
4) 0.5 container filled with water					
5) Nulled timer on another device					
Steps					
1	Start the timer and immerse e at once	earbuds in the container for 32 minutes		The Bluetooth connection between earbuds and the smartphone is severed within the period from 30:00 min. to 32:00 min	
2	Remove the earbuds from the container		Earbuds are out of the container	Earbuds are out of the container	
3	Connect the smartphone to the earbuds via Bluetooth		The smartphone is not connecte	The smartphone is not connected to the earbuds	

