C1: Detection of the last connected "Samsung Galaxy Buds Pro" earbuds location by the "Find" service

TypePriorityEstimateReferencesFunctionalMediumNoneNone

Automation Type

None

Preconditions

Environment: Android 8 or higher

- 1) Earbuds: Samsung Galaxy Buds Pro (at least 30 % charged)
- 2) Charging case: Samsung Galaxy Buds Pro (at least 30 % charged)
- 3) Smartphone: Samsung Galaxy (at least 30 % charged)
- 4) Earbuds are connected to the smartphone via Bluetooth
- 5) Earbuds are in the "Find" service of the "SmartThings" application (installed by default on the smartphone)
- 6) The "Find" service is open in the "SmartThings" application

Steps

1	Place earbuds in the charging case	Earbuds are not connected to the smartphone via Bluetooth
2	Tap the icon with earbuds	The "Galaxy Buds Pro" pop-up window is displayed
3	Tap the "Navigate" icon	The last connected location of the earbuds is displayed on the map

