C2: Duration of the beep sound played by "Samsung Galaxy Buds Pro" earbuds when using the "Ring" option in the "Find" service

TypePriorityEstimateReferencesFunctionalMediumNoneNone

Automation Type

None

Preconditions

Environment: Android 8 or higher

- 1) Earbuds: Samsung Galaxy Buds Pro (at least 30 % charged)
- 2) Smartphone: Samsung Galaxy (at least 30 % charged)
- 3) Earbuds are connected to the smartphone via Bluetooth
- 4) Earbuds are in the "Find" service of the "SmartThings" application (installed by default on the smartphone)
- 5) The "Find" service is open in the "SmartThings" application
- 6) Nulled timer on another device

Steps

1	Tap the icon with earbuds	The "Galaxy Buds Pro" pop-up window is displayed
2	Tap the "Ring" icon	The "Ring your Galaxy Buds Pro" pop-up window is displayed
3	Tap the "Start" button and start the timer at once	The beep sound is played by earbuds for one minute

