C1: Detection of the last connected "Samsung Galaxy Buds Pro" earbuds location by the "Find" service

TypePriorityEstimateReferencesFunctionalMediumNoneNone

Automation Type

None

Preconditions

Environment: Android 8 or higher

- 1) Earbuds: Samsung Galaxy Buds Pro (at least 30 % charged)
- 2) Charging case: Samsung Galaxy Buds Pro (at least 30 % charged)
- 3) Smartphone: Samsung Galaxy (at least 30 % charged)
- 4) Earbuds are connected to the smartphone via Bluetooth
- 5) Earbuds are in the "Find" service of the "SmartThings" application (installed by default on the smartphone)

Steps

| 1 | Place earbuds in the charging case | Earbuds are not connected to the smartphone via Bluetooth |
|---|------------------------------------|----------------------------------------------------------------|
| 2 | Open the "SmartThings" application | The "My Home" page is open |
| 3 | Tap the "Life" tab | Service cards are displayed |
| 4 | Tap the "Find" card | Tracked devices are displayed |
| 5 | Tap the icon with earbuds | The "Galaxy Buds Pro" pop-up window is displayed |
| 6 | Tap the "Navigate" icon | The last connected location of earbuds is displayed on the map |

