## C2: Duration of the beep sound played by "Samsung Galaxy Buds Pro" earbuds when using the "Ring" option in the "Find" service

TypePriorityEstimateReferencesFunctionalMediumNoneNone

**Automation Type** 

None

## Preconditions

Environment: Android 8 or higher

- 1) Earbuds: Samsung Galaxy Buds Pro (at least 30 % charged)
- 2) Smartphone: Samsung Galaxy (at least 30 % charged)
- 3) Earbuds are connected to the smartphone via Bluetooth
- 4) Earbuds are in the "Find" service of the "SmartThings" application (installed by default on the smartphone)
- 5) Nulled timer on another device

## Steps

1	Open the "SmartThings" application	The "My Home" page is open
2	Tap the "Life" tab	Service cards are displayed
3	Tap the "Find" card	Tracked devices are displayed
4	Tap the icon with earbuds	The "Galaxy Buds Pro" pop-up window is displayed
5	Tap the "Ring" icon	The "Ring your Galaxy Buds Pro" pop-up window is displayed
6	Tap the "Start" button and start the timer at once	The beep sound is played by earbuds for one minute

