26.09.2023, 18:12 Master - TestRail

### **Test Cases**

### SmartThings Find

# C1: Detection of the last connected "Samsung Galaxy Buds Pro" earbuds location by the "Find" service

Туре	Priority	Estimate	References
Functional	Medium	None	None
Automation Type			
None			

### Preconditions

Environment: Android 8 or higher

- 1) Earbuds: Samsung Galaxy Buds Pro (at least 30 % charged)
- 2) Charging case: Samsung Galaxy Buds Pro (at least 30 % charged)
- 3) Smartphone: Samsung Galaxy (at least 30 % charged)
- 4) Earbuds are connected to the smartphone via Bluetooth
- 5) Earbuds are in the "Find" service of the "SmartThings" application (installed by default on the smartphone)
- 6) The "Find" service is open in the "SmartThings" application

# Steps

1	Place earbuds in the charging case	Earbuds are not connected to the smartphone via Bluetooth
2	Tap the icon with earbuds	The "Galaxy Buds Pro" pop-up window is displayed
3	Tap the "Navigate" icon	The last connected location of the earbuds is displayed on the map

26.09.2023, 18:12 Master - TestRail

C2: Duration of the beep sound played by "Samsung Galaxy Buds Pro" earbuds when using the "Ring" option in the "Find" service

Туре	Priority	Estimate	References
Functional	Medium	None	None
Automation Type			
None			

### Preconditions

Environment: Android 8 or higher

- 1) Earbuds: Samsung Galaxy Buds Pro (at least 30 % charged)
- 2) Smartphone: Samsung Galaxy (at least 30 % charged)
- 3) Earbuds are connected to the smartphone via Bluetooth
- 4) Earbuds are in the "Find" service of the "SmartThings" application (installed by default on the smartphone)
- 5) The "Find" service is open in the "SmartThings" application
- 6) Nulled timer on another device

#### Steps

1	Tap the icon with earbuds	The "Galaxy Buds Pro" pop-up window is displayed
2	Tap the "Ring" icon	The "Ring your Galaxy Buds Pro" pop-up window is displayed
3	Tap the "Start" button and start the timer at once	The beep sound is played by earbuds for one minute

26.09.2023, 18:12 Master - TestRail

# C3: The "Ring" option in the "Find" service for the "Samsung Galaxy Buds Pro" earbuds in a closed charging case

Туре	Priority	Estimate	References
Functional	Medium	None	None
Automation Type			
None			

#### Preconditions

Environment: Android 8 or higher

- 1) Earbuds: Samsung Galaxy Buds Pro (at least 30 % charged)
- 2) Charging case: Samsung Galaxy Buds Pro (at least 30 % charged)
- 3) Smartphone: Samsung Galaxy (at least 30 % charged)
- 4) Earbuds are paired with the smartphone
- 5) Earbuds are in the "Find" service of the "SmartThings" application (installed by default on the smartphone)
- 6) The "Find" service is open in the "SmartThings" application
- 7) Earbuds are in the closed charging case
- 8) The Bluetooth on the smartphone is on

# Steps

1	Tap the icon with earbuds	The "Galaxy Buds Pro" pop-up window is displayed
2	Tap the "Ring" icon	The "Ring your Galaxy Buds Pro" pop-up window is displayed
3	Tap the "Start" button	The beep sound is not played by the earbuds