

# REFRIGERATORS AND HEAT PUMPS

The transfer of heat from a low-temperature region to a high-temperature one requires special devices called **refrigerators**.

Another device that transfers heat from a low-temperature medium to a high-temperature one is the **heat pump**.

Refrigerators and heat pumps are essentially the same devices; they differ in their objectives only.


$$ext{COP}_{ ext{R}} = rac{ ext{Desired output}}{ ext{Required input}} = rac{ ext{Cooling effect}}{ ext{Work input}} = rac{Q_L}{W_{ ext{net,in}}}$$
 $ext{COP}_{ ext{HP}} = rac{ ext{Desired output}}{ ext{Required input}} = rac{ ext{Heating effect}}{ ext{Work input}} = rac{Q_H}{W_{ ext{net,in}}}$ 

The objective of a refrigerator is to remove heat  $(Q_L)$  from the cold medium; the objective of a heat pump is to supply heat  $(Q_H)$  to a warm medium.

$$COP_{HP} = COP_R + 1$$
  
for fixed values of  $Q_L$  and  $Q_H$ 

### THE REVERSED CARNOT CYCLE


The reversed Carnot cycle is the *most efficient* refrig. cycle operating between  $T_i$  and  $T_{H}$ . It is not a suitable model for refrigeration cycles since processes 2-3 and 4-1 are not practical because Process 2-3 involves the compression of a liquid-vapor mixture, which requires a compressor that will handle two phases, and process 4-1 involves the expansion of highmoisture-content refrigerant in a turbine.



$$COP_{R,Carnot} = \frac{1}{T_H/T_L - 1}$$

$$ext{COP}_{HP,Carnot} = rac{1}{1 - T_L/T_H}$$
 two temperatures decreases, that is rises or  $T_H$  falls.


Both COPs increase as the difference between the two temperatures decreases, that is, as  $T_{I}$ 




Schematic of a Carnot refrigerator and *T-s* diagram of the reversed Carnot cycle.

# THE IDEAL VAPOR-COMPRESSION REFRIGERATION CYCLE

The **vapor-compression refrigeration cycle** is the ideal model for refrigeration systems. Unlike the reversed Carnot cycle, the refrigerant is vaporized completely before it is compressed and the turbine is replaced with a throttling device.



1-2 Isentropic compression in a compressor
2-3 Constant-pressure heat rejection in a condenser
3-4 Throttling in an expansion device
4-1 Constant-pressure heat absorption in an evaporator



This is the most widely used cycle for refrigerators, A-C systems, and heat pumps.

Schematic and *T-s* diagram for the ideal vapor-compression refrigeration cycle.

The ideal vapor-compression refrigeration cycle involves an irreversible (throttling) process to make it a more realistic model for the actual systems.


Replacing the expansion valve by a turbine is not practical since the added benefits cannot justify the added cost and complexity.

Steady-flow energy balance 
$$(q_{\rm in}-q_{\rm out})+(w_{\rm in}-w_{\rm out})=h_e-h_i$$
  $COP_R=\frac{q_L}{w_{\rm net,in}}=\frac{h_1-h_4}{h_2-h_1}$ 


$$COP_R = \frac{q_L}{w_{\text{net,in}}} = \frac{h_1 - h_4}{h_2 - h_1}$$

$$COP_{HP} = \frac{q_H}{w_{\text{net,in}}} = \frac{h_2 - h_3}{h_2 - h_1}$$

 $h_1 = h_{g@P_1}$  and  $h_3 = h_{f@P_3}$  for the ideal case



An ordinary household refrigerator.




The *P-h* diagram of an ideal vaporcompression refrigeration cycle.

## ACTUAL VAPOR-COMPRESSION REFRIGERATION CYCLE


An actual vapor-compression refrigeration cycle differs from the ideal one owing mostly to the irreversibilities that occur in various components, mainly due to fluid friction (causes pressure drops) and heat transfer to or from the surroundings.

The COP decreases as a result of irreversibilities.



#### **DIFFERENCES**

Non-isentropic compression
Superheated vapor at evaporator exit
Subcooled liquid at condenser exit
Pressure drops in condenser and evaporator



Schematic and *T-s* diagram for the actual vapor-compression refrigeration cycle.

## SECOND-LAW ANALYSIS OF VAPOR-COMPRESSION REFRIGERATION CYCLE

The maximum COP of a refrigeration cycle operating between temperature limits of  $T_I$  and  $T_H$ 

$$COP_{R,max} = COP_{R,rev} = COP_{R,Carnot} = \frac{T_L}{T_H - T_L} = \frac{1}{T_H/T_L - 1}$$


Actual refrigeration cycles are not as efficient as ideal ones like the Carnot cycle because of the irreversibilities involved. But the conclusion we can draw from Eq. 11–9 that the COP is inversely proportional to the temperature difference  $T_H$  -  $T_L$  is equally valid for actual refrigeration cycles.

The goal of a second-law or exergy analysis of a refrigeration system is to determine the components that can benefit the most by improvements.

This is done identifying the locations of greatest exergy destruction and the components with the lowest exergy or second-law efficiency.

Exergy destruction in a component can be determined directly from an exergy balance or by using

$$\dot{X}_{\rm dest} = T_0 \dot{S}_{\rm gen}$$



#### FIGURE 11–9

The vapor-compression refrigeration cycle considered in the second-law analysis.

Note that when  $T_H = T_0$ , which is often the case for refrigerators,  $\eta_{II,cond} = 0$  since there is no recoverable exergy in this case.

Compressor:

$$\begin{split} \dot{X}_{\text{dest},1-2} &= T_0 \dot{S}_{\text{gen},1-2} = \dot{m} T_0 (s_2 - s_1) \\ \eta_{\text{II,Comp}} &= \frac{\dot{X}_{\text{recovered}}}{\dot{X}_{\text{expended}}} = \frac{\dot{W}_{\text{rev}}}{\dot{W}_{\text{act,in}}} = \frac{\dot{m} [h_2 - h_1 - T_0 (s_2 - s_1)]}{\dot{m} (h_2 - h_1)} = \frac{\psi_2 - \psi_1}{h_2 - h_1} \\ &= 1 - \frac{\dot{X}_{\text{dest},1-2}}{\dot{W}_{\text{act,in}}} \end{split}$$

Condenser:


$$\begin{split} \dot{X}_{\text{dest,2-3}} &= T_0 \dot{S}_{\text{gen,2-3}} = T_0 \bigg[ \dot{m} (s_3 - s_2) + \frac{\dot{Q}_H}{T_H} \bigg] \\ \eta_{\text{II,Cond}} &= \frac{\dot{X}_{\text{recovered}}}{\dot{X}_{\text{expended}}} = \frac{\dot{X}_{Q_H}}{\dot{X}_2 - \dot{X}_3} = \frac{\dot{Q}_H (1 - T_0 / T_H)}{\dot{X}_2 - \dot{X}_3} \\ &= \frac{\dot{Q}_H (1 - T_0 / T_H)}{\dot{m} [h_2 - h_3 - T_0 (s_2 - s_3)]} = 1 - \frac{\dot{X}_{\text{dest,2-3}}}{\dot{X}_2 - \dot{X}_3} \end{split}$$

Expansion valve:

$$\dot{X}_{\rm dest,3-4} = T_0 \dot{S}_{\rm gen,3-4} = \dot{m} T_0 (s_4 - s_3)$$

$$\eta_{\rm II,ExpValve} = \frac{\dot{X}_{\rm recovered}}{\dot{X}_{\rm expended}} = \frac{0}{\dot{X}_3 - \dot{X}_4} = 0 \quad \text{or}$$

$$\eta_{\rm II,ExpValve} = 1 - \frac{\dot{X}_{\rm dest,3-4}}{\dot{X}_{\rm expended}} = 1 - \frac{\dot{X}_3 - \dot{X}_4}{\dot{X}_3 - \dot{X}_4} = 0$$



#### FIGURE 11-9

The vapor-compression refrigeration cycle considered in the second-law analysis.

#### Evaporator:

$$\begin{split} \dot{X}_{\text{dest},4-1} &= T_0 \dot{S}_{\text{gen},4-1} = T_0 \bigg[ \dot{m} (s_1 - s_4) - \frac{\dot{Q}_L}{T_L} \bigg] \\ \eta_{\text{II,Evap}} &= \frac{\dot{X}_{\text{recovered}}}{\dot{X}_{\text{expended}}} = \frac{\dot{X}_{Q_L}}{\dot{X}_4 - \dot{X}_1} = \frac{\dot{Q}_L (T_0 - T_L) / T_L}{\dot{X}_4 - \dot{X}_1} \\ &= \frac{\dot{Q}_L (T_0 - T_L) / T_L}{\dot{m} \big[ h_4 - h_1 - T_0 (s_4 - s_1) \big]} = 1 - \frac{\dot{X}_{\text{dest},4-1}}{\dot{X}_4 - \dot{X}_1} \end{split}$$


$$\dot{X}_{\dot{Q}_L} = \dot{Q}_L \frac{T_0 - T_L}{T_L}$$

 $\dot{X}_{\dot{Q}_L} = \dot{Q}_L \frac{T_0 - T_L}{T_c}$  The exergy rate associated with the withdrawal of heat from the low-temperature medium at  $T_i$  at a rate of  $Q_i$ 

This is equivalent to the power that can be produced by a Carnot heat engine receiving heat from the environment at  $T_0$  and rejecting heat to the low temperature medium at  $T_i$  at a rate of  $Q_i$ .

$$\dot{W}_{\rm rev,in} = \dot{W}_{\rm min,in} = \dot{X}_{\dot{Q}_L}$$

Note that when  $T_L = T_0$ , which is often the case for heat pumps,  $\eta_{II,evap} = 0$  since there is no recoverable exergy in this case.



#### FIGURE 11–9

The vapor-compression refrigeration cycle considered in the second-law analysis.

$$\dot{X}_{\rm dest,total} = \dot{X}_{\rm dest,1-2} \, + \, \dot{X}_{\rm dest,2-3} \, + \, \dot{X}_{\rm dest,3-4} \, + \, \dot{X}_{\rm dest,4-1}$$

$$\dot{X}_{\mathrm{dest,total}} = \dot{W}_{\mathrm{in}} - \dot{X}_{\dot{Q}_L}$$
 Total exergy destruction

#### Second-law (exergy) efficiency

$$\eta_{\rm II,cycle} = \frac{\dot{X}_{\dot{Q}_L}}{\dot{W}_{\rm in}} = \frac{\dot{W}_{\rm min,in}}{\dot{W}_{\rm in}} = 1 \, - \, \frac{\dot{X}_{\rm dest,total}}{\dot{W}_{\rm in}}$$

$$\dot{W}_{\rm in} = \frac{\dot{Q}_L}{\rm COP_R} \qquad \dot{X}_{\dot{Q}_L} = \dot{Q}_L \frac{T_0 - T_L}{T_L}$$

$$T_0 = T_H$$
 for a refrigeration cycle

$$\eta_{\rm II,cycle} = \frac{\dot{X}_{\dot{Q}_L}}{\dot{W}_{\rm in}} = \frac{\dot{Q}_L(T_0 - T_L)/T_L}{\dot{Q}_L/{\rm COP_R}} = \frac{{\rm COP_R}}{T_L/(T_H - T_L)} = \frac{{\rm COP_R}}{{\rm COP_{R,rev}}}$$


This second-law efficiency definition accounts for all irreversibilities associated within the refrigerator, including the heat transfers with the refrigerated space and the environment.

### SELECTING THE RIGHT REFRIGERANT

- Several refrigerants may be used in refrigeration systems such as chlorofluorocarbons (CFCs), ammonia, hydrocarbons (propane, ethane, ethylene, etc.), carbon dioxide, air (in the air-conditioning of aircraft), and even water (in applications above the freezing point).
- R-11, R-12, R-22, R-134a, and R-502 account for over 90 percent of the market.
- The industrial and heavy-commercial sectors use ammonia (it is toxic).
- R-11 is used in large-capacity water chillers serving A-C systems in buildings.
- R-134a (replaced R-12, which damages ozone layer) is used in domestic refrigerators and freezers, as well as automotive air conditioners.
- R-22 is used in window air conditioners, heat pumps, air conditioners of commercial buildings, and large industrial refrigeration systems, and offers strong competition to ammonia.
- R-502 (a blend of R-115 and R-22) is the dominant refrigerant used in commercial refrigeration systems such as those in supermarkets.
- CFCs allow more ultraviolet radiation into the earth's atmosphere by destroying the
  protective ozone layer and thus contributing to the greenhouse effect that causes
  global warming. Fully halogenated CFCs (such as R-11, R-12, and R-115) do the
  most damage to the ozone layer. Refrigerants that are friendly to the ozone layer
  have been developed.
- Two important parameters that need to be considered in the selection of a refrigerant are the temperatures of the two media (the refrigerated space and the environment) with which the refrigerant exchanges heat.

10

### **HEAT PUMP SYSTEMS**



A heat pump can be used to heat a house in winter and to cool it in summer.

The most common energy source for heat pumps is atmospheric air (air-to-air systems).

Water-source systems usually use well water and ground-source (geothermal) heat pumps use earth as the energy source. They typically have higher COPs but are more complex and more expensive to install.

Both the capacity and the efficiency of a heat pump fall significantly at low temperatures. Therefore, most airsource heat pumps require a supplementary heating system such as electric resistance heaters or a gas furnace.

Heat pumps are most competitive in areas that have a large cooling load during the cooling season and a relatively small heating load during the heating season. In these areas, the heat pump can meet the entire cooling and heating needs of residential or commercial buildings.


11

# INNOVATIVE VAPOR-COMPRESSION REFRIGERATION SYSTEMS

- The simple vapor-compression refrigeration cycle is the most widely used refrigeration cycle, and it is adequate for most refrigeration applications.
- The ordinary vapor-compression refrigeration systems are simple, inexpensive, reliable, and practically maintenance-free.
- However, for large industrial applications efficiency, not simplicity, is the major concern.
- Also, for some applications the simple vapor-compression refrigeration cycle is inadequate and needs to be modified.
- For moderately and very low temperature applications some innovative refrigeration systems are used. The following cycles will be discussed:
  - Cascade refrigeration systems
  - Multistage compression refrigeration systems
  - Multipurpose refrigeration systems with a single compressor
  - Liquefaction of gases

### **Cascade Refrigeration Systems**


Some industrial applications require moderately low temperatures, and the temperature range they involve may be too large for a single vapor-compression refrigeration cycle to be practical. The solution is **cascading.** 



## **Multistage Compression Refrigeration Systems**


Warm environment Condense Expansion High-pressure compressor valve Flash chamber Expansion Low-pressure compressor valve Evaporator A two-stage compression refrigeration Cold refrigerated space system with a flash chamber.

When the fluid used throughout the cascade refrigeration system is the same, the heat exchanger between the stages can be replaced by a mixing chamber (called a flash *chamber*) since it has better heat transfer characteristics.




## Multipurpose Refrigeration Systems with a Single Compressor

Some applications require refrigeration at more than one temperature. A practical and economical approach is to route all the exit streams from the evaporators to a single compressor and let it handle the compression process for the entire system.




### **Liquefaction of Gases**



Many important scientific and engineering processes at cryogenic temperatures (below about -100°C) depend on liquefied gases including the separation of oxygen and nitrogen from air, preparation of liquid propellants for rockets, the study of material properties at low temperatures, and the study of superconductivity.


The storage (i.e., hydrogen) and transportation of some gases (i.e., natural gas) are done after they are liquefied at very low temperatures. Several innovative cycles are used for the liquefaction of gases.





Linde-Hampson system for liquefying gases.

## **GAS REFRIGERATION CYCLES**

The reversed Brayton cycle (the gas refrigeration cycle) can be used for refrigeration.









The gas refrigeration cycles have lower COPs relative to the vapor-compression refrigeration cycles or the reversed Carnot cycle.

The reversed Carnot cycle consumes a fraction of the net work (area 1*A*3*B*) but produces a greater amount of refrigeration (triangular area under *B*1).






An open-cycle aircraft cooling system.

Despite their relatively low COPs, the gas refrigeration cycles involve simple, lighter components, which make them suitable for aircraft cooling, and they can incorporate regeneration

Without regeneration, the lowest turbine inlet temperature is  $T_0$ , the temperature of the surroundings or any other cooling medium.

With regeneration, the high-pressure gas is further cooled to  $T_4$  before expanding in the turbine.

Lowering the turbine inlet temperature automatically lowers the turbine exit temperature, which is the minimum temperature in the cycle.



Gas refrigeration cycle with regeneration.

## **Summary**

- Refrigerators and Heat Pumps
- The Reversed Carnot Cycle
- The Ideal Vapor-Compression Refrigeration Cycle
- Actual Vapor-Compression Refrigeration Cycle
- Second-law Analysis of Vapor-Compression Refrigeration Cycle
- Selecting the Right Refrigerant
- Heat Pump Systems
- Innovative Vapor-Compression Refrigeration Systems
- Gas Refrigeration Cycles
- Absorption Refrigeration Systems