AVIATESAIR

CN

Company NOTAMs

Current operational notices. Read and acknowledge before you fly.

REVISION	EFFECTIVE	DOCUMENTS	ISSUED BY
0	24 SEP 2026	3	AviatesAir Flight Operations

This copy is uncontrolled once printed or saved. The current revision is always in the AviatesAir EFB (Manuals).
For flight simulation use only. Not for real-world aviation.

List of effective documents

DOCUMENT	TITLE	REV	EFFECTIVE
CN-001	Aircraft Registrations: Fleet-Wide Use	0	24 SEP 2026
CN-002	Boeing 737 NG / MAX Takeoff Flap Restriction	0	24 SEP 2026
CN-003	Minimum Landing Flap for the Boeing 737 and Airbus A320 Family	0	24 SEP 2026

Contents

CN-001 Aircraft Registrations: Fleet-Wide Use
- Notice
- The one condition: routes for your type
- What does not change

CN-002 Boeing 737 NG / MAX Takeoff Flap Restriction
- Restriction
- Why
- How the tools apply it

CN-003 Minimum Landing Flap for the Boeing 737 and Airbus A320 Family
- Restriction
- Why
- How the tools apply it

Aircraft Registrations: Fleet-Wide Use

Any AviatesAir registration may be used from any airport, as often as you like and even while another pilot is flying it. The only condition is that your departure airport has routes for the type.

> NOTE Status: **ACTIVE** until cancelled. Applies to every AviatesAir, CityHopper and Skycargo type.

Notice

AviatesAir does not assign airframes to individual pilots or stations. You may fly **any registration in the AviatesAir fleet**:

- from **any airport** in the network,
- **as many times as you like**, and
- **even if another pilot is flying the same registration at the same time.**

Maintaining a unique registration for every position in a shared virtual fleet would add administration without adding anything to the operation, so the whole fleet is pooled.

The one condition: routes for your type

Your departure airport must have AviatesAir **routes for the aircraft type you intend to fly**. Before booking, check the route list in the Tracker (**Routes**) for your departure airport and filter by type.

> NOTE Example: East Midlands (EGNX) has Boeing 737-800 routes, so a B738 departure from EGNX with any B738 registration is valid.

If the departure airport has no routes for your type, choose another type that is served there, or reposition to an airport that has routes for the type you want (see OM-A 1, Repositioning).

What does not change

- Your **booking** still defines the flight: route, flight number, aircraft **type** and schedule. The registration you pick must be of the booked type.
- File the registration you are actually flying in your SimBrief OFP and your network flight plan so ATC, the OFP and the Tracker agree.
- Company callsigns are unaffected. See OM-A 1, Callsigns.

Boeing 737 NG / MAX Takeoff Flap Restriction

FLAPS 5 is the minimum takeoff flap setting for every 737 in the fleet, even where performance would allow FLAPS 1. Purpose: tail-strike prevention.

WARNING Status: **ACTIVE** until cancelled. Applies to the **B736, B738, B739ER and B38M**.

Restriction

FLAPS 5 is the minimum flap setting for takeoff. FLAPS 1 is **not permitted**, even when the runway, weight and weather would make it performance-legal.

Use FLAPS 5 as the normal setting and FLAPS 10, 15 or 25 when performance requires more flap (short or limiting runways, obstacles, high density altitude).

Why

A lower flap setting means higher rotation and lift-off speeds and a **higher body attitude at lift-off**, which reduces tail clearance. The 737-800, -900ER and MAX 8 are long-bodied and particularly sensitive to this.

A tail strike is never a small event: the aircraft must **return to the departure airport** for inspection. That means a long delay to your flight, disruption to the rest of the rotation and the risk of further problems with the airframe later.

How the tools apply it

- **EFB Departure Perf** only offers FLAPS 5 and above for 737 types, and **OPT** only chooses between permitted settings. If a restricted setting is ever requested, the result is flagged with this notice.
- Rotate at the normal rate (about 2–3° per second) towards the target pitch attitude. Don't rotate early or aggressively. See OM-B 737, Handling notes.
- A tail strike, or a takeoff flown with a prohibited setting, is a reportable occurrence. Tell staff via the PIREP review comment (see OM-A 6).

Minimum Landing Flap for the Boeing 737 and Airbus A320 Family

737 NG/MAX land with FLAPS 25 minimum (FLAPS 30 standard). A319/A320neo land with CONF 3 minimum (CONF FULL standard). Using the minimum is fully permitted and never counts against a PIREP.

WARNING Status: **ACTIVE** until cancelled. Applies to the **B736, B738, B739ER, B38M, A319 and A320neo**.

Restriction

FLEET	MINIMUM LANDING FLAP	STANDARD LANDING FLAP	ALSO PERMITTED
Boeing 737 NG / MAX	**FLAPS 25**	**FLAPS 30**	FLAPS 40 (short, wet or contaminated runways)
Airbus A319 / A320neo	**CONF 3**	**CONF FULL**	None

Landing with **less** than the minimum (for example a 737 at FLAPS 15, or an A320 at CONF 2) is not permitted except when a non-normal procedure in the QRH/ECAM requires it.

NOTE Using the **minimum** configuration (FLAPS 25 / CONF 3) is a normal, fully accepted choice. It **never** results in a deduction or any action against your PIREP. The Tracker's landing review treats both as the landing configuration.

Why

Less landing flap means a **higher approach speed** (VREF / VLS). The consequences:

- more energy to dissipate: a **longer landing distance** and more braking,
- a **longer runway occupancy** before you can vacate, which disrupts traffic on busy online events, and
- a greater tendency towards a **firm touchdown**, which puts stress on the airframe and may call for an inspection.

The standard settings (FLAPS 30 / CONF FULL) give the lowest approach speed and the most margin. Choose the minimum only for a reason, such as expected windshear, a go-around performance limit or noise, and brief it.

How the tools apply it

- **EFB Arrival Perf** offers only permitted settings and defaults to the standard one.
- The **landing review** in the Tracker judges "landing configuration by 1,000 ft" against the company minimum for your type (see OM-A 6).
- Fly the approach speed for the flap you have selected. The stabilised-approach criteria are in OM-A 5.