

DEEP MOBILE REPAIR TRAINING MANUAL (ZIONTECH)

POWER → RESET → CLOCK → CPU → NAND → RF

CASE STUDIES:

1. Dead Phone (0.00A): Check VDD_MAIN, charging IC.
2. 0.02A Stuck: Check RESET & CLOCK lines.
3. Boot Loop: NAND or CPU communication issue.
4. No Service: Baseband or RF fault.
5. High Current: Shorted capacitor or IC.

TECHNICIAN RULE:

Always diagnose step-by-step, never jump to CPU replacement.

TOOLS REQUIRED:

- DC Power Supply
- Multimeter
- Microscope
- Soldering Station

ZIONTECH PRO TIP:

Most CPU faults are actually power, reset, or clock issues.