


Lecture 23

Module 8:

Virtual Work, Part 1



ME 370 - Mechanical Design 1

"Colibri" by Derek Hugger

* www.youtube.com/watch?v=1scj5sotD-E

Lecture 23: Virtual Work - 1


Today Module 8, Part 1 Virtual Work (Reading, Norton Chapter 10.14-10.15 and 11.10)

Activities & Upcoming Deadlines

- **Week 12:**
 - **HW 11 (Motor, Cam, Motion 2):** posted and due Tuesday 11/11/18
 - **Lab 11 (Dynamic Force Analysis with Python) –** Post-lab due the night before your lab section during the week of Nov 19 (delayed by 2 weeks due to P2D2 during Lab 12).
 - **Lab 12:** Meet in 1001 MEL for P2D2 presentation
- **Project 2:**
 - If you need a shaft cut, ask a MakerWorks member for help for free. Do not use a MechSE machinist who charge \$67/hour.
 - **Project 2 Description** - Follow this document for expected deliverables for P2D2. Submit materials to Gradescope prior to lab 12 (slides + PVA appendix + CAD animation). Demonstration of prototype of entire robot (walker + dispensing mechanism together), grade will depend on level of function
 - **Complete CATME peer evaluation after finishing P2D2.** - Team Member evaluation & self
- **Next lecture:** Module 6, Part 4: Motion Control 2 (Chapter 8).

Recall: Class Exercise 1: Piston (slider-crank)

For a given time-varying force applied to link 4 ($\vec{F}_P(t)$), we want to know the output torque with respect to time ($\vec{T}_{12}(t)$). Assume (a) each link has mass m_i and length l_i , (b) the PVA analysis for this mechanism is already solved, including piston kinematics (d, \dot{d}, \ddot{d}), and (c) there is friction at link 4, so: $F_{14x} = \pm \mu F_{14y} = -\text{Sign}(\dot{d}) \mu F_{14y}$
Solve for output torque \vec{T}_{12} via Dynamic Force Analysis (perform steps 1-3)



Recall: Convert to matrix format $[A] \{B\} = \{C\}$

Link 2:

$$\begin{aligned} 1 & F_{12x} + F_{32x} = m_2 a_{CG2x} \\ 2 & F_{12y} + F_{32y} = m_2 a_{CG2y} \\ 3 & T_{21} + (R_{12x}F_{12y} - R_{12y}F_{12x}) \\ & + (R_{32x}F_{32y} - R_{32y}F_{32x}) = I_{CG2}\alpha_2 \end{aligned}$$

Link 3:

$$\begin{aligned} 4 & F_{43x} - F_{32x} = m_3 a_{CG3x} \\ 5 & F_{43y} - F_{32y} = m_3 a_{CG3y} \\ 6 & (R_{43x}F_{43y} - R_{43y}F_{43x}) - (R_{32x}F_{32y} \\ & - R_{32y}F_{32x}) = I_{CG3}\alpha_3 \end{aligned}$$

Link 4: $N \not\in \mathcal{T}$

$$\begin{aligned} 7 & F_{14x} - F_{43x} + F_{px} = m_4 a_{CG4x} \\ 8 & F_{14y} - F_{43y} + F_{px} = m_4 a_{CG4y} = 0 \\ 9 & F_{14x} = \pm \mu F_{14y} = -\text{sign}(d) \mu F_{14y} \end{aligned}$$

9 unknowns, 8 equations (matrix)

$\{B\}$ unknowns + 1 equation ($F_{14x} = \pm \mu F_{14y}$)

$$\left[\begin{array}{ccccccccc} 1 & 0 & 1 & 0 & 0 & 0 & 0 & 0 \\ 0 & 1 & 0 & 1 & 0 & 0 & 0 & 0 \\ -R_{12y} & R_{12x} & -R_{32y} & R_{32x} & 0 & 0 & 0 & 1 \\ 0 & 0 & -1 & 0 & 1 & 0 & 0 & 0 \\ 0 & 0 & 0 & -1 & 0 & 1 & 0 & 0 \\ 0 & 0 & R_{23y} & -R_{23x} & -R_{43y} & R_{43x} & 0 & 0 \\ 0 & 0 & 0 & 0 & -1 & 0 & -\mu SGN(\dot{d}) & 0 \\ 0 & 0 & 0 & 0 & 0 & -1 & 1 & 0 \end{array} \right] \times \left[\begin{array}{c} F_{12x} \\ F_{12y} \\ F_{32x} \\ F_{32y} \\ F_{43x} \\ F_{43y} \\ F_{14y} \\ T_{12} \end{array} \right] = \left[\begin{array}{c} m_2 a_{G2x} \\ m_2 a_{G2y} \\ I_{G2}\alpha_2 \\ m_3 a_{G3x} \\ m_3 a_{G3y} \\ I_{G3}\alpha_3 \\ m_4 a_{G4x} - F_{Px} \\ -F_{Py} \end{array} \right]$$

Virtual Work Topics

- Energy Method
 - Principle of Virtual Work
 - Total power for system of n moving links
 - Vector equation for estimating external applied forces and torques
- Examples of solving for input torque
 - Four-bar linkage
 - Simple gear set

(Reading, Norton Ch 10.14-15, 11.10)

What method could we use if we only wanted to determine external forces and torques (not also internal reaction terms)?

- Use energy (virtual work) methods

Energy Methods (or Virtual Work Methods)

We have seen how to use a Newton's second law or 'Force Balance Equations' to analyze the forces or torques on links in a mechanism.

We will now use an Energy/Work balance approach

- Based on principle of virtual work
- Only for determining external forces and torques that produce work (e.g., T_{12} or F_p)
- Not suitable if we also need internal reactions.
- Requires knowledge of accelerations and velocities ← PVA
- Does not require simultaneous solution of large systems of equations

Recall definition of dot product

$$\text{If } \vec{\mathbf{B}} = b_x \hat{i} + b_y \hat{j} + b_z \hat{k}$$

$$\vec{\mathbf{C}} = c_x \hat{i} + c_y \hat{j} + c_z \hat{k}$$

$$\text{then } \vec{\mathbf{B}} \cdot \vec{\mathbf{C}} = b_x c_x + b_y c_y + b_z c_z$$

\Rightarrow scalar!

Definitions

- Work = dot product of force (or torque) and displacement

$$W = \vec{F} \cdot \vec{R} \quad \text{or} \quad W = \vec{T} \cdot \vec{\theta}$$

- Power = dot product of force (or torque) and velocity

$$\begin{aligned} P &= \vec{F} \cdot \vec{v} & \text{or} & \quad P = \vec{T} \cdot \vec{\omega} \end{aligned}$$

$\textcircled{1}$ $\textcircled{2}$

← \vec{F} and \vec{T} are only
external values
that do work

Also,

- Power = time rate of change of energy

$$P = \frac{dE}{dt}$$

Assumption

For low-friction pin joints and high-speed mechanisms

- Assume negligible energy loss due to heat, friction, noise, etc.
- Assume negligible potential energy

\Rightarrow total E = KE only

$$P = \frac{dE}{dt}$$

What are
expressions for
 KE_{trans} and KE_{rot} ?

$$P = \frac{d}{dt}(KE_{trans}) = \frac{d}{dt}\left(\frac{1}{2} m \vec{v}_{CG}^2\right) = m \vec{A}_{CG} \cdot \vec{v}_{CG}$$

$$= \frac{1}{2} m v_{CG}^2$$

$$= \frac{1}{2} I_{CG} \vec{\omega}^2$$

$$P = \frac{d}{dt}(KE_{rot}) = \frac{d}{dt}\left(\frac{1}{2} I_{CG} \vec{\omega}^2\right) = I_{CG} \vec{\alpha} \cdot \vec{\omega}$$

③ $P = m \vec{A}_{CG} \cdot \vec{v}_{CG}$

Instantaneous change in energy

④ $P = I_{CG} \vec{\alpha} \cdot \vec{\omega}$

Virtual work

- Called “virtual work” from concept of work done due to forces causing an infinitesimal, or virtual, displacement ($\delta \vec{R}$) such that :

$$\delta W = \vec{F} \cdot \delta \vec{R}$$

- If applied over infinitesimal delta time (δt) then get instantaneous power of the system:

$$P = \frac{\delta W}{\delta t} = \vec{F} \cdot \frac{\delta \vec{R}}{\delta t} = \vec{F} \cdot \vec{V}$$

- At any instant, the rate of change of energy in the system must balance the rate of work done on the system

$$\underbrace{\vec{F} \cdot \vec{V} + \vec{T} \cdot \vec{\omega}}_{\text{①} \quad \text{②} \quad \text{Rate of work by ext F \& T}} = \underbrace{m \vec{A}_{CG} \cdot \vec{V}_{CG} + I_{CG} \vec{\alpha} \cdot \vec{\omega}}_{\text{③} \quad \text{④} \quad \text{Rate of change of (kinetic)energy}}$$

Virtual work

- Total power for system of n moving links:
- Assuming fixed link is link 1

Due to ext forces or torques

$$\sum_{i=2}^n (\vec{F}_i \cdot \vec{v}_i) + \sum_{i=2}^n (\vec{T}_i \cdot \vec{\omega}_i) = \sum_{i=2}^n (\vec{m}_i \vec{A}_{CGi} \cdot \vec{v}_{CGi}) + \sum_{i=2}^n (I_{CGi} \vec{a}_i \cdot \vec{\omega}_i)$$


*velocity at point of application
of force, not of CG*

due to inertial props of links

Dot products \rightarrow sum of scalar values

Exercise 1

4-bar linkage where link 2 is a disk that is driven by a **constant-velocity motor**, solve for motor torque T_{12}



$$\omega_2 = -24 \text{ k rad/s}$$

Given:

Link	m_i (kg)	I_{CGi} (kg m ²)	ω_i (rad/s)	α_i (rad/s ²)	\vec{v}_{CGi} (m/s)	\vec{a}_{CGi} (m/s ²)
2	4.53	0.023	-24 k	?	?	?
3	1.81	0.008	4.9 k	241 k	1.585 i - 0.418 j	-24.40 i - 13.58 j
4	3.63	0.035	7.8 k	-129 k	0.997 i + 0.323 j	-18.95 i + 2.46 j

1. Draw in angular and translational velocities and accelerations for each link
2. Use virtual work derived power equation to solve for T_{12}

$$\sum_{i=2}^4 (\vec{F}_i \cdot \vec{v}_i) + \sum_{i=2}^4 (\vec{T}_i \cdot \vec{\omega}_i) = \sum_{i=2}^4 (\vec{m}_i \vec{a}_{CGi} \cdot \vec{v}_{CGi}) + \sum_{i=2}^4 (I_{CGi} \vec{\alpha}_i \cdot \vec{\omega}_i)$$

$$T_{12} \omega_2 - m_3 \vec{A}_{CG3} \cdot \vec{V}_{CG3} + m_4 \vec{A}_{CG4} \cdot \vec{V}_{CG4} + I_{CG3} \vec{\alpha}_3 \cdot \vec{\omega}_3 + I_{CG4} \vec{\alpha}_4 \cdot \vec{\omega}_4$$

solve for $T_{12} = 6.3 \hat{k} = 63 \text{ Nm (ccw)}$

Class Exercise

Create a kinematic diagram of your Project 2 robot leg (if working with a team, select one member's design for this exercise).

1. Number all links—**excluding any redundant or passive links**—and label their centers of gravity.
2. **Assume that the position, velocity, and acceleration (PVA) of the links at the drawing configuration are known.**
3. Draw the angular and translational velocities and accelerations for each link.
4. **Assume that the foot contact forces are known** (sufficient to support the walker's weight and sustain forward acceleration while overcoming friction).
5. Using the **virtual work-derived power equation**, relate the **power done by the external forces and torques**—the **input torque at the effective crank and the contact forces at the foot**—to the **rate of change of the mechanical system's kinetic energy.**

$$\sum_{i=2}^4 (\vec{F}_i \cdot \vec{v}_i) + \sum_{i=2}^4 (\vec{T}_i \cdot \vec{\omega}_i) = \sum_{i=2}^4 (\vec{m}_i \vec{A}_{CGi} \cdot \vec{v}_{CGi}) + \sum_{i=2}^4 (I_{CGi} \vec{a}_i \cdot \vec{\omega}_i)$$