

## **User Guide for DGECALIB Library**

Zhilong (Dgelom) Su

Aug/16/2020

## **System Requirement:**

- (1) System Platform: Windows 10
- (2) DGECALIB supports Intel 64 architecture and compatible architectures. The library is optimized for the systems based on
  - Intel<sup>©</sup> Core(TM) processor 5th, 6th, 7th, and 8th generation
  - Intel<sup>©</sup> Xeon (R) processor E5 v3 family (formerly Haswell)

and compatible processors.

## **IDE Requirement:**

- (1) Platform Toolset: Visual Studio 2017 (v141)
- (2) C/C++ Language/OpenMP Support: Yes
- (3) C/C++ Language/Standard: ISO C++ 17 Standard and above
- (4) C/C++ Code Generation: Multi-threaded Debug DLL
- (5) C/C++ Preprocessor: USE OCV

## Lib Configuration:

- ➤ Navigate to "VS/xxx Property Pages/Configuration Properties";
- ➤ Go to "VC++ Directories/Include Directories", add the path
  - "[ur cd location]/dgecalib/include";
  - If OpenCV required, add the path "[ur\_cd\_location]/dgecalib/addin/ocv/include";
- ➤ Go to "Linker/General/Additional Library Directories", add the path "[ur cd location]/dgecalib/lib/Debug [or Release]";
- > Go to "Linker/input/Additional Dependencies", add library
  - "dgelom\_calibrator\_x64d.lib";
- ➤ Build the project, copy the required \*.dll files to the folder the \*.exe located. All required \*.dll files can be found in folder "[ur cd\_location]/dgecalib/regist".
- > End here, congrats and enjoy it now!