

# Slicing guide for Multi Color Printer

(Base on Prusa Slicer 2.3.1)

V1.0

## **Contents**

- Download and install Prusa Slicer
- Import Printer Settings
- •Slicing mullti colors 3d object




#### Download and install Prusa slicier


Download Prusa Slicer from the below link and install it to your PC:

https://www.prusa3d.com/prusaslicer/

• About how to install and use *Prusa Slicer*, please refer to this link:

https://help.prusa3d.com/en/category/about-prusaslicer\_205










### Import printer settings


#### Open Prusa Slicer and import the printer settings




1. File>Import>Import config Bundle










4. Check print settings / Filament settings / Printer settings




# Slicing Multi color 3d object

#### Choose the settings




#### •Load mutli-color 3d object






# Slicing Multi color 3d object

●Move/Rotate/Zoom the 3d object if need




•Move the *color switch tower* to right place






## Slicing Multi color 3d object

#### •Slicing and Preview





#### •Store gcode file to SD card and the print it

