Z8PM4-MK2 Video Tutorial



1. Some videos are filmed using machines other than the Z8PM4Pro, but the operating steps are identical to those of the Z8PM4Pro.

2. Please directly click on the image below to watch the video



Installation and Operation

Installation







Power On/OFF

Bed leveling





Load filament

Print from SD card

Installation


Wiring





Gradient mix color printing

Random mix color printing






Install slicer software

Slicing guide - one color







Slicing guide - mulit color

Slicing guide - combine 3d model

Installation

Wiring





Slicing guide - painting color

Print and install a cover on the PSU





Advance Features

Power auto shutdown

Bed auto leveling





Power auto shutdown

Bed auto leveling

Power loss recovery

Fast printing





4 Maintenance and Repair

Machine Auto testing guide

How to replace a nozzle





<!--

How to upload firmware

Machine Auto testing guide

How to replace a nozzle



<!--

<!--

How to open control box


<!--



<!--

How to replace Titan extruder

<!--



<!--

How to replace heat sticker

Machine Auto testing guide

How to replace a nozzle

<!--

