

Chapter 7 Assembly Language

Human-Readable Machine Language

Computers like ones and zeros...

0001110010000110

Humans like symbols...

ADD R6, R2, R6; increment index reg.

Assembler is a program that turns symbols into machine instructions.

- ISA-specific: close correspondence between symbols and instruction set
 - > mnemonics for opcodes
 - > labels for memory locations
- additional operations for allocating storage and initializing data

An Assembly Language Program

```
Program to multiply a number by the constant 6
       .ORIG \times 3050
       LD R1, SIX
       LD R2, NUMBER
       AND R3, R3, #0 ; Clear R3. It will
                          ; contain the product.
; The inner loop
     ADD R3, R3, R2
AGATN
       ADD R1, R1, #-1; R1 keeps track of
                         ; the iteration.
       BRp
             AGAIN
       HALT
NUMBER
      .BLKW 1
       .FILL x0006
SIX
       . END
```


LC-3 Assembly Language Syntax

Each line of a program is one of the following:

- an instruction
- an assember directive (or pseudo-op)
- a comment

Whitespace (between symbols) and case are ignored. Comments (beginning with ";") are also ignored.

An instruction has the following format:



Opcodes and Operands

Opcodes

- reserved symbols that correspond to LC-3 instructions
- listed in Appendix A

```
>ex: ADD, AND, LD, LDR, ...
```

Operands

- registers -- specified by Rn, where n is the register number
- numbers -- indicated by # (decimal) or x (hex)
- label -- symbolic name of memory location
- separated by comma
- number, order, and type correspond to instruction format

```
➤ ex:
    ADD R1,R1,R3
    ADD R1,R1,#3
    LD R6,NUMBER
    BRz LOOP
```

Labels and Comments

Label

- placed at the beginning of the line
- assigns a symbolic name to the address corresponding to line

Comment

- anything after a semicolon is a comment
- ignored by assembler
- used by humans to document/understand programs
- tips for useful comments:
 - > avoid restating the obvious, as "decrement R1"
 - > provide additional insight, as in "accumulate product in R6"
 - > use comments to separate pieces of program

Assembler Directives

Pseudo-operations

- do not refer to operations executed by program
- used by assembler
- look like instruction, but "opcode" starts with dot

Opcode	Operand	Meaning
.ORIG	address	starting address of program
. END		end of program
.BLKW	n	allocate n words of storage
.FILL	n	allocate one word, initialize with value n
STRINGZ	n-character string	allocate n+1 locations, initialize w/characters and null terminator

Trap Codes

LC-3 assembler provides "pseudo-instructions" for each trap code, so you don't have to remember them.

Code	Equivalent	Description
HALT	TRAP x25	Halt execution and print message to console.
IN	TRAP x23	Print prompt on console, read (and echo) one character from keybd. Character stored in R0[7:0].
OUT	TRAP x21	Write one character (in R0[7:0]) to console.
GETC	TRAP x20	Read one character from keyboard. Character stored in R0[7:0].
PUTS	TRAP x22	Write null-terminated string to console. Address of string is in R0.

Style Guidelines


Use the following style guidelines to improve the readability and understandability of your programs:

- 1. Provide a program header, with author's name, date, etc., and purpose of program.
- 2. Start labels, opcode, operands, and comments in same column for each line. (Unless entire line is a comment.)
- 3. Use comments to explain what each register does.
- 4. Give explanatory comment for most instructions.
- 5. Use meaningful symbolic names.
 - Mixed upper and lower case for readability.
 - ASCIItoBinary, InputRoutine, SaveR1
- 6. Provide comments between program sections.
- 7. Each line must fit on the page -- no wraparound or truncations.
 - Long statements split in aesthetically pleasing manner.

Sample Program

Count the occurrences of a character in a file.

Remember this?



Char Count in Assembly Language (1 of 3)

```
Program to count occurrences of a character in a file.
; Character to be input from the keyboard.
 Result to be displayed on the monitor.
 Program only works if no more than 9 occurrences are found.
 Initialization
        .ORIG x3000
               R2, R2, #0
        AND
                              ; R2 is counter, initially 0
               R3, PTR
                              ; R3 is pointer to characters
        LD
                              ; R0 gets character input
        GETC
                              ; R1 gets first character
               R1, R3, #0
        LDR
 Test character for end of file
        ADD
               R4, R1, \#-4; Test for EOT (ASCII x04)
TEST
                              ; If done, prepare the output
        BRz
               OUTPUT
```

Char Count in Assembly Language (2 of 3)


```
Test character for match. If a match, increment count.
       NOT
              R1, R1
       ADD
              R1, R1, R0; If match, R1 = xFFFF
              R1, R1; If match, R1 = x0000
       NOT
       BRnp GETCHAR ; If no match, do not increment
       ADD
              R2, R2, #1
 Get next character from file.
              R3, R3, #1; Point to next character.
GETCHAR ADD
              R1, R3, #0; R1 gets next char to test
        LDR
       BRnzp
               TEST
 Output the count.
      {f L}{f D}
              RO, ASCII; Load the ASCII template
OUTPUT
              R0, R0, R2; Covert binary count to ASCII
       ADD
                          ; ASCII code in R0 is displayed.
       OUT
                          : Halt machine
       HALT
```

Char Count in Assembly Language (3 of 3)

```
; ; Storage for pointer and ASCII template ; ASCII .FILL x0030 PTR .FILL x4000 .END
```

Assembly Process

Convert assembly language file (.asm) into an executable file (.obj) for the LC-3 simulator.



First Pass:

- scan program file
- find all labels and calculate the corresponding addresses;
 this is called the <u>symbol table</u>

Second Pass:

 convert instructions to machine language, using information from symbol table

First Pass: Constructing the Symbol Table

- 1. Find the .ORIG statement, which tells us the address of the first instruction.
 - Initialize location counter (LC), which keeps track of the current instruction.
- 2. For each non-empty line in the program:
 - a) If line contains a label, add label and LC to symbol table.
 - b) Increment LC.
 - NOTE: If statement is .BLKW or .STRINGZ, increment LC by the number of words allocated.
- 3. Stop when .END statement is reached.

NOTE: A line that contains only a comment is considered an empty line.

Practice

Construct the symbol table for the program in Figure 7.1 (Slides 7-11 through 7-13).

Symbol	Address
TEST	x3004
GETCHAR	x300B
OUTPUT	x300E
ASCII	x3012
PTR	x3013

Second Pass: Generating Machine Language

For each executable assembly language statement, generate the corresponding machine language instruction.

 If operand is a label, look up the address from the symbol table.

Potential problems:

Improper number or type of arguments

```
➤ ex: NOT R1,#7
ADD R1,R2
ADD R3,R3,NUMBER
```

Immediate argument too large

```
>ex: ADD R1,R2,#1023
```

• Address (associated with label) more than 256 from instruction

can't use PC-relative addressing mode


Practice

Using the symbol table constructed earlier, translate these statements into LC-3 machine language.

Statement		Machine Language
LD	R3,PTR	0010 011 000010001
ADD	R4,R1,#-4	0001 100 001 1 11100
LDR	R1,R3,#0	0110 001 011 000000
BRnp	GETCHAR	0000 101 000000001

LC-3 Assembler

Using "assemble" (Unix) or LC3Edit (Windows), generates several different output files.




Object File Format

LC-3 object file contains

- Starting address (location where program must be loaded), followed by...
- Machine instructions

Example

Beginning of "count character" object file looks like this:



Multiple Object Files

An object file is not necessarily a complete program.

- system-provided library routines
- code blocks written by multiple developers

For LC-3 simulator, can load multiple object files into memory, then start executing at a desired address.

- system routines, such as keyboard input, are loaded automatically
 - ➤ loaded into "system memory," below x3000
 - > user code should be loaded between x3000 and xFDFF
- each object file includes a starting address
- be careful not to load overlapping object files

Linking and Loading

Loading is the process of copying an executable image into memory.

- more sophisticated loaders are able to <u>relocate</u> images to fit into available memory
- must readjust branch targets, load/store addresses

Linking is the process of resolving symbols between independent object files.

- suppose we define a symbol in one module, and want to use it in another
- some notation, such as .EXTERNAL, is used to tell assembler that a symbol is defined in another module
- linker will search symbol tables of other modules to resolve symbols and complete code generation before loading