## **CMOS Fabrication and Layout**

- Transistors are fabricated on a thin silicon wafer that serve as both a mechanical support and electrical common point called substrate
- Fabrication process (a.k.a. Lithography) is similar to printing press
  - On each step, different materials are deposited or etched
- Easiest way to understand physical layout is to look at the wafer from two perspectives:
  - Top-section
  - Cross-section

## **Photo Lythography**

"Carving pictures in stone using light"





FIG 3.1 Photomasking with a negative resist (lens system between mask and wafer omitted to improve clarity and avoid diffracting the reader ©)

#### **Inverter Cross Section**


 $V_{DD}$ 

- Typically use p-type substrate for nMOS transistors
- Requires n-well for body of pMOS transistors



### Well and Substrate Taps

- Substrate must be tied to GND and n-well to V<sub>DD</sub>
- Metal to lightly-doped semiconductor forms poor connection (parasitic diode)
- Use heavily doped well and substrate contacts









FIG 1.34 Inverter cross-section with well and substrate contacts. Color version on inside front cover.

#### Let's add some color ...





Transistors and wires are defined by masks




**GND** 

#### Inverter Mask Set

#### Six masks:

- n-well
- poly silicon
- n+ diffusion
- p+ diffusion
- Contact
- Metal



## **Fabrication Steps**

- Start with blank wafer
- Build invert from bottom up

p substrate

#### n-well Formation


- First step will be to form the n-well
  - Cover wafer with protective layer of SiO<sub>2</sub> (oxide)
    to grow SiO<sub>2</sub> on top of Si wafer put the Si with H<sub>2</sub>O or O<sub>2</sub> in oxidation furnace at 900 1200 C
  - (Remove layer where n-well should be built)
  - (Implant or diffuse n dopants into exposed wafer)
  - (Strip off SiO<sub>2</sub>)

p substrate

SiO,

## Deposit silicon-oxide and photoresist


- Photoresist is a light-sensitive organic polymer
- Softens where exposed to light



NOTE: The silicon oxide is just to protect the wafer

## **Photo-Lithography**

- Expose photoresist through n-well mask
- Strip off exposed photoresist




## **Etching**

- Etch oxide with hydrofluoric acid (HF)
  - Seeps through skin and eats bone: nasty stuff!!!
- Only attacks oxide where resist has been exposed

	Photor	esist
	SiO <sub>2</sub>	
p substrate		


#### The n-well

- n-well is formed with diffusion or ion implantation
- Diffusion
  - Place wafer in furnace with arsenic gas
  - Heat until As atoms diffuse into exposed Si
- Ion Implantation
  - Blast wafer with beam of As ions
  - lons blocked by SiO<sub>2</sub>, only enter exposed Si




## Strip protective oxide

- Strip off the remaining oxide using HF
- Back to bare wafer with n-well
- Subsequent steps involve similar series of steps




## Gate oxide and Polysilicon

- Deposit very thin layer of gate oxide
  - < 20 Å (6-7 atomic layers)
- Chemical Vapor Deposition (CVD) of silicon layer
  - Place wafer in furnace with Silane gas (SiH<sub>4</sub>)
  - Forms many small crystals called polysilicon
  - Heavily doped to be good conductor




## Polysilicon patterning

Use same lithography process to pattern polysilicon




# Self-aligned polysilicon gate process

- The polysilicon gate serves as a mask to allow precise alignment of the source and drain with the gate
- Use oxide and masking to expose where n+ dopants should be diffused or implanted
- n-diffusion forms nMOS source, drain, and n-well contact




#### Formation of the n-diffusions

- Pattern oxide and form n+ regions
- Self-aligned process (poysilicon gate) "blocks" diffusion under the gate
- Polysilicon is better than metal for self-aligned gates because it doesn't melt during later processing




#### The n-diffusions

- Historically dopants were diffused
- Usually ion implantation today (but regions are still called diffusion)




Strip off oxide to complete patterning step




## The p-diffusions

 Similar set of steps form p+ diffusion regions for pMOS source and drain and substrate contact




#### **Contacts**

- Now we need to create the devices' terminals
- Cover chip with thick field oxide (FOX)
- Etch oxide where contact cuts are needed




#### Metallization


- Sputter on aluminum over whole wafer, filling the contacts as well
- Pattern to remove excess metal, leaving wires



## Fabrication Steps Summary (1/3)



## Fabrication Steps Summary (2/3)



## Fabrication Steps Summary (3/3)




FIG 1.38 Cross-sections while manufacturing p-diffusion, contacts, and metal

## Basic Fabrication Steps in a nutshell

- Though a mask transfer an "image" of the design to the wafer
- Do something to imaged parts of the wafer
  - Implant add impurities to change electrical properties
  - Deposit deposit metal, insulator or other layers
  - Grow Oxide place silicon in oxidizing ambient
  - Etch Cut into surface of topmost layer(s)
  - Polish Make surface of wafer flat
- Strip Off imaging material (resist) and proceed to next step

## Layout Design

- Chips are specified with set of masks
- Minimum dimensions of masks determine transistor size (and hence speed, cost, and power)
- Feature size f = distance between source and drain
  - Set by minimum width of polysilicon
- Feature size improves 30% every 3 years or so
- Normalize for feature size when describing design rules
- Express rules in terms of  $\lambda = f/2$ 
  - E.g.  $\lambda$  = 0.3 μm in 0.6 μm process

## Layout Design Rules Conservative rules to get started!




FIG 1.39 Simplified  $\lambda$ -based design rules for layouts with z-metal layers (MOSIS)

## **Design Rules Summary**


- Metal and diffusion have minimum width and spacing of 4λ
- Contacts are 2λ x 2λ and must be surrounded by 1λ on the layers above and below
- Polysilicon uses a width of 2λ
- Polysilicon overlaps diffusions by 2λ where a transistor is desired and has spacing or 1λ away where no transistor is desired
- Polysilicon and contacts have a spacing of 3λ from other polysilicon or contacts
- N-well surrounds pMOS transistors by 6λ and avoid nMOS transistors by 6λ

## Logic Gates layout

- Layout can be very time consuming
- Design gates to fit together nicely
- Build a library of standard cells
- Standard cell design methodology
  - V<sub>DD</sub> and GND should abut (standard height)
  - Adjacent gates should satisfy design rules
  - nMOS at bottom and pMOS at top
  - All gates include well and substrate contacts

## The power and ground lines are called supply rails

## **Inverter Layout**



Transistor dimensions specified as W / L ratio

Minimum size is 4λ / 2λ, sometimes

called 1 unit





FIG 1.40 Inverter with dimensions labeled


• In  $f = 0.6 \mu m$  process, this is 1.2  $\mu m$  wide, 0.6  $\mu m$  long

## Inverter Standard Cell Layout




Usually the pMOS has width 2 or 3 times the width of the nMOS


### Inverter Standard Cell Area (1/2)



### **Inverter Standard Cell Area (2)**



## 3-input Standard Cell NAND



## Stick Diagrams

- Stick diagrams help plan layout quickly
  - Need not be to scale
  - Draw with color pencils or dry-erase markers





FIG 1.43 Stick diagrams of inverter and 3-input NAND gate. Color version on inside front cover.


## Wiring Tracks

- A wiring track is the space required for a wire
  - 4λ width, 4λ spacing from neighbor =  $8\lambda$  pitch
  - Transistors also consume one wiring track



## Well Spacing

- Wells must surround transistors by 6λ
  - Implies 12λ between opposite transistor flavors
  - Leaves room for one wire track



#### **Area Estimation**

- Horizontal 4×8 = 32
- Estimate area by counting wiring tracks
- Vertical 5×8 = 40

- Multiply by 8 to express in  $\lambda$ 

