



ESP32 MODULE




RESET





BOOT



IO_FUNC SELECT SPI LCD SELECT




EX IO




Title: ATK_DNESP32S3.PrjPcb		
Author: ALIENTEK	Size: A4	
Date: 2024/2/28	File: CORE.SchDoc	
Revision: 0	Version: V1.0	


CAMERA




ATK MODULE




SPI LCD(WIRELESS)




RGBLCD




LED




KEY




TEMP&HUMI SENSOR




BEEP




REMOTE IN




REMOTE OUT




ADC&REMOTE_OUT




TF CARD




3 AXIS ACCELEROMETER



EEPROM



ALS&PS SENSOR




Title:
ATK_DNESP32S3.PrjPcb
Author:
ALIENTEK
Date:
2024/2/28
Revision:
0


Size:
A4
File:
DEVICE1.SchDoc
Version:
V1.0




IO EXPANDER




LDO




USB & POWER



I2S DAC&ADC



USB USART



Title: ATK_DNESP32S3.PrjPcb		 正点原子
Author: ALIENTEK	Size: A4	
Date: 2024/2/28	File: DEVICE2.SchDoc	
Revision: 0	Version: V1.0	