

BUILD DIAGRAM

ALL components should be soldered to the FRONT of the board, with the exception of the optional hot swaps (d).

We recommend soldering components in the alphabetical sequence shown.

Look for letters "a" through "j" – You'll notice the letter sequence is scattered, and not always in clockwise order.

This recommended sequence is based on the height of components and is designed to help maintain better grip and balance of the board.

