


## **Zer⊗** U | **Battery Connector Polarity Indication**

-Nikhil Jali 22<sup>nd</sup> September 2016


This document indicates the battery connector polarity on the PCB. Kayo Battery uses JST-SHR-02 as a male connector from the battery. Given that information, we are currently using the connector SM02B-SRSS-TB(LF)(SN)[Product Link] [Datasheet Link]. The images below show the required polarity from the battery wire terminals.

Kindly ensure proper polarity of battery male connector using the info below.

**Side View of Battery Female Connector on PCB** 



## **Side View Enlarged**



## **Top View**

