
Linux 系统安装 USB 转串口线驱动指导

Linux 内核 5.5 及以上已经包含内置的 PL2303 驱动程序, 如果您的 Linux 内核是 v2.6.15 ~v5.4 版本请按照以下方式更新 PL2303 Linux 驱动并找到对应版本内核的文件进行安装:

3.6.15_ok	2021-04-16 15:57
3.6.23_ok	2021-04-16 15:57
1 2.6.24_ok	2021-04-16 15:57
2.6.28_ok	2021-04-16 15:57
3.6.32_ok	2021-04-16 15:57
2.6.35.2_ok	2021-04-16 15:57
3.6.35.2_ok2	2021-04-16 15:57
3.0.35_ok	2021-04-16 15:57
3.3_ok	2021-04-16 15:57
3.4.113_ok	2021-04-16 15:57
3.10_ok	2021-04-16 15:57
3.13_ok	2021-04-16 15:57
3.16_ok	2021-04-16 15:57
3.18_ok	2021-04-16 15:57
3 4.0.2_ok	2021-04-16 15:57
1 4.4_ok	2021-04-16 15:57
4.9.113_ok	2021-04-16 15:57
3 4.9_ok	2021-04-16 15:57
3.14_ok	2021-04-16 15:57
鷆 4.15_ok	2021-04-16 15:57
3 4.18_OK	2021-04-16 15:57
3 4.19_ok	2021-04-16 15:57
3 4.20_ok	2021-04-16 15:57
<u>→</u> 5.0_ok	2021-04-16 15:57
№ 5.2_ok	2021-04-16 15:57
3.4.51_ok	2021-04-16 15:57

1. 键入命令"terminal"打开终端 AP: 如下图




2. 键入命令"uname-r"首先找出最近的 Linux 内核版本:如下图

3. 键入命令"make all"如果在编译内核驱动过程中遇到错误信息:如下图


```
charlesyeh522@charlesyeh522: ~/PL2303G_Linux_Driver_v1.0.5/4.18_OK
File Edit View Search Terminal Help
charlesyeh522@charlesyeh522:~/PL2303G_Linux_Driver_v1.0.5/4.18_OK$ make all
make -C /lib/modules/4.18.0-10-generic/build M=/home/charlesyeh522/PL2303G Linux
Driver v1.0.5/4.18 OK modules
make[1]: Entering directory '/usr/src/linux-headers-4.18.0-10-generic'
Makefile:982: "Cannot use CONFIG_STACK_VALIDATION=y, please install libelf-dev,
libelf-devel or elfutils-libelf-devel"
         /home/charlesyeh522/PL2303G Linux Driver v1.0.5/4.18 OK/pl2303.o
  Building modules, stage 2.
  MODPOST 1 modules
          /home/charlesyeh522/PL2303G_Linux_Driver_v1.0.5/4.18_OK/pl2303.mod.o
  CC
         /home/charlesyeh522/PL2303G Linux Driver v1.0.5/4.18 OK/pl2303.ko
make[1]: Leaving directory '/usr/src/linux-headers-4.18.0-10-generic'
charlesyeh522@charlesyeh522:~/PL2303G Linux Driver v1.0.5/4.18 OK$
```

4. 编译有错误后可将新驱动程序复制到内核"sudo cp pl2303.ko /lib/modules/\$(uname -r)/kernel/drivers/usb/serial"的目录下:如下图


5.键入命令 "sudo gedit /etc/modules" 编辑模块: 如下图



6. 键入命令"pl2303"添加 pl2303,保存,关闭模块:如下图



7.键入命令 "reboot" 现在重新启动系统: 如下图



8.最后插入产品 USB 电缆就可以使用了