





















8	7	6	5	4	3	2	1
POWER AMPLIFIER							
D							
C							
B							
A							
TITLE: COVER PAGE							
DATE: 2025/11/19							
ENGINEER:							
PAGE: 01							
8	7	6	5	4	3	2	1

SHEET#	DESCRIPTION
01	COVER PAGE
02	SA9227_USB_AUDIO
03	USB_CONNECTOR
04	SA9227_CLOCK&RESET
05	POWER
06	DAC_CS43198
07	STM32
08	LOWPASS&EQ
09	
10	
11	
12	
13	
14	
15	
16	







D



D



B



B



1

