

Oct. 25, 2023 13:59:13

Tech: CV

File: O2 快速.bin

Init E (V) = 0.65 High E (V) = 1.1 Low E (V) = -0.287

Init P/N = P

Scan Rate (V/s) = 0.1

Segment = 8

Smpl Interval (V) = 0.001

Quiet Time (s) = 2

Sensitivity (A/V) = 5e-6

— O2 快速.bin

— O2 低速.bin

— O2 停止.bin

— 空白N2 1.bin

Potential / V