



TRCC Installation and Uninstallation Guide


1. Extract all files from the downloaded program archive.



2. Double-click to run the installer




3. Installation and run



This is where you can display and enter the installation path. The default is C:\Program Files.


Click to select a custom installation path

Click this button to begin installation.



Installation progress is 100%. Click "OK" to complete the installation.


After TRCC is installed, a TRCC shortcut will be created on the desktop. Simply double-click to run TRCC.





4. Install or repair .NET Runtime

After TRCC is installed, the .NET Runtime installer will run automatically. **Please be sure to install.**

If your computer does not have .NET Runtime installed, a .NET Runtime installation interface will pop up; select to *install*.



If your computer has .NET Runtime installed, a .NET Runtime repair interface will pop up; select *Repair*.



.NET Runtime installation or repair complete. Click *Close*.

5. Uninstall TRCC

The installed software is a completely portable application. To uninstall the software, simply exit the software and delete the folder.

The program directory is located in the path selected during TRCC installation (step 3), and the folder name is "TRCCCAP".

The default path is "C:\Program Files\TRCCCAP".

The data directory is located in the root directory of the system disk, and the folder name is "TRCCCAP".

The default path is "C:\TRCCCAP".