




SERIES EG SWITCHES

SLIDE SWITCHES


TACT
SWITCHESNAVIGATION
SWITCHESPUSHBUTTON
SWITCHESTOGGLE
SWITCHESROCKER
SWITCHESSLIDE
SWITCHESSNAP-ACTION
SWITCHESDIP
SWITCHESKEYLOCK
SWITCHESROTARY
SWITCHESDETECTOR
SWITCHESCAP
OPTIONS

FEATURES & BENEFITS

- ▶ Variety of package styles & sizes
- ▶ Up to 6 poles
- ▶ Variety of functions
- ▶ Positive detent
- ▶ SMT options

APPLICATIONS/MARKETS

- ▶ Computer servers/peripherals
- ▶ Consumer electronics
- ▶ Instrumentation
- ▶ Test & measurement



Example Ordering Number

EG-1201A

SPECIFICATIONS

Contact Resistance:	Less than 20 milliohms
Insulation Resistance:	500VDC – 100 megohms
Dielectric Strength:	500V AC for 1 minute between any terminal and frame
Operating Temperature:	-20°C to +70°C (-4°F to +158°F)

MATERIALS

Contact:	Silver plated copper alloy
----------	----------------------------

HOW TO ORDER





Specifications subject to change without notice.


EG 1201



Model No.	L
EG1201	4
EG1201A	5.5



PANEL MOUNT






SCHEMATIC


EG 1205



Model No.	L
EG1205	4
EG1205A	5.5



PANEL MOUNT



SCHEMATIC






E-SWITCH®


EG 1206



Model No.	L
EG1206	3
EG1206A	6








P.C. MOUNTING




SCHEMATIC

EG 1213






P.C. MOUNTING




SCHEMATIC

EG 1218



P.C. MOUNTING



SCHEMATIC






SERIES EG SWITCHES


SLIDE SWITCHES

TACT
SWITCHESNAVIGATION
SWITCHESPUSHBUTTON
SWITCHESTOGGLE
SWITCHESROCKER
SWITCHESSLIDE
SWITCHESSNAP-ACTION
SWITCHESDIP
SWITCHESKEYLOCK
SWITCHESROTARY
SWITCHESDETECTOR
SWITCHESCAP
OPTIONS

EG 1224







P.C. MOUNTING



SCHEMATIC

EG 1247






P.C. MOUNTING




SCHEMATIC

EG 1248



P.C. MOUNTING





SCHEMATIC




E-SWITCH®

EG 1249



P.C. MOUNTING



SCHEMATIC

TACT
SWITCHESNAVIGATION
SWITCHESPUSHBUTTON
SWITCHESROCKER
SWITCHESSLIDE
SWITCHESSNAP-ACTION
SWITCHESDIP
SWITCHESKEYLOCK
SWITCHESROTARY
SWITCHESDETECTOR
SWITCHESCAP
OPTIONS







SERIES EG SWITCHES

SLIDE SWITCHES

TACT
SWITCHESNAVIGATION
SWITCHESPUSHBUTTON
SWITCHESTOGGLE
SWITCHESROCKER
SWITCHESSNAP-ACTION
SWITCHESDIP
SWITCHESKEYLOCK
SWITCHESROTARY
SWITCHESDETECTOR
SWITCHESCAP
OPTIONS

EG 1270






P.C. MOUNTING




EG 1271





Model No.	L
EG1271	2
EG1271A	4.4




P.C. MOUNTING






EG 1307


P.C. MOUNTING



SCHEMATIC

EG 1313



P.C. MOUNTING




SCHEMATIC

EG 2201

Model No.	L
EG2201	3
EG2201A	6
EG2201B	9
EG2201C	12
EG2201D	4.5



P.C. MOUNTING



SCHEMATIC



SERIES EG SWITCHES





SLIDE SWITCHES

TACT
SWITCHESNAVIGATION
SWITCHESPUSHBUTTON
SWITCHESTOGGLE
SWITCHESROCKER
SWITCHESSLIDE
SWITCHESSNAP-ACTION
SWITCHESDIP
SWITCHESKEYLOCK
SWITCHESROTARY
SWITCHESDETECTOR
SWITCHESCAP
OPTIONS





EG 2205



Model No.	L
EG2205	4
EG2205A	2



EG 2207









E-SWITCH®


EG 2208



Model No.	L
EG2208	4
EG2208A	6



P.C. MOUNTING






SCHEMATIC


EG 2209



Model No.	L
EG2209	2
EG2209A	4



P.C. MOUNTING







SCHEMATIC


EG 2210



Model No.	L
EG2210	6
EG2210A	4
EG2210D	2



P.C. MOUNTING



SCHEMATIC



SERIES EG SWITCHES





SLIDE SWITCHES

TACT
SWITCHESNAVIGATION
SWITCHESPUSHBUTTON
SWITCHESTOGGLE
SWITCHESROCKER
SWITCHESSLIDE
SWITCHESSNAP-ACTION
SWITCHESDIP
SWITCHESKEYLOCK
SWITCHESROTARY
SWITCHESDETECTOR
SWITCHESCAP
OPTIONS


EG 2211



Model No.	L
EG2211	4
EG2211A	2






P.C. MOUNTING




SCHEMATIC

EG 2214



P.C. MOUNTING







SCHEMATIC


EG 2215



Model No.	L
EG2215	3.5
EG2215A	6



P.C. MOUNTING






SCHEMATIC



E-SWITCH®





EG 2219



EG 2301



Model No.	L
EG2301	3
EG2301A	6
EG2301B	9
EG2301C	12





SERIES EG SWITCHES




SLIDE SWITCHES

TACT
SWITCHESNAVIGATION
SWITCHESPUSHBUTTON
SWITCHESTOGGLE
SWITCHESROCKER
SWITCHESSLIDE
SWITCHESSNAP-ACTION
SWITCHESDIP
SWITCHESKEYLOCK
SWITCHESROTARY
SWITCHESDETECTOR
SWITCHESCAP
OPTIONS


EG 2305



Model No.	L
EG2305	4
EG2305A	2



P.C. MOUNTING







SCHEMATIC


EG 2308



Model No.	L
EG2308	4
EG2308A	6



P.C. MOUNTING






SCHEMATIC


EG 2310



Model No.	L
EG2310	6
EG2310A	4



P.C. MOUNTING



SCHEMATIC







E-SWITCH®





EG 2315








Model No.	L
EG2315	3.5
EG2315A	6



EG 2319



EG 2322





SERIES EG SWITCHES






SLIDE SWITCHES

TACT
SWITCHESNAVIGATION
SWITCHESPUSHBUTTON
SWITCHESTOGGLE
SWITCHESROCKER
SWITCHESSLIDE
SWITCHESSNAP-ACTION
SWITCHESDIP
SWITCHESKEYLOCK
SWITCHESROTARY
SWITCHESDETECTOR
SWITCHESCAP
OPTIONS

EG 2325



Model No.	L
EG2325	2
EG2325A	6








E-SWITCH®

TACT
SWITCHESNAVIGATION
SWITCHESPUSHBUTTON
SWITCHESTOGGLE
SWITCHESROCKER
SWITCHESSLIDE
SWITCHESSNAP-ACTION
SWITCHESDIP
SWITCHESKEYLOCK
SWITCHESROTARY
SWITCHESDETECTOR
SWITCHESCAP
OPTIONS


EG 4208



Model No.	L
EG4208	4
EG4208A	6








P.C. MOUNTING




SCHEMATIC

EG 4311



P.C. MOUNTING



SCHEMATIC




SERIES EG SWITCHES





SLIDE SWITCHES

TACT
SWITCHESNAVIGATION
SWITCHESPUSHBUTTON
SWITCHESTOGGLE
SWITCHESROCKER
SWITCHESSLIDE
SWITCHESSNAP-ACTION
SWITCHESDIP
SWITCHESKEYLOCK
SWITCHESROTARY
SWITCHESDETECTOR
SWITCHESCAP
OPTIONS


EG 4319



Model No.	L
EG4319	5
EG4319A	6







P.C. MOUNTING




SCHEMATIC

EG 6201



P.C. MOUNTING



SCHEMATIC